Távirányító segédlet

Varga András Távirányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ALCOR HD-1200							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
ن	Power	Power						
ΑV								
TEXT	TTX	TTX						
TV	TV/Radio	TV/Radio						
Ō								
	Subt	Subt						
≡♦								
Back	Recall	Recall						
≡X Epg ∢I	Schedule	Schedule						
■ •	List	01:						
₩	Decil "	Stop	<u> </u>					
i II	Resolution	Pause	1					
Red Green	Red	Record	1					
Yeilow	Green Yellow	FR	1					
	Blue	Play FF						
Blue ►►								
<u> </u>	Lang	Lang						
Pict	16:9/4:3	16:9/4:3			_	_		
—	10.9/4.3	10.9/4.5	1		+		-	+
OK	ОК	ОК	+		+			+
<u> </u>	OK ►	DIX ►						
MENU	Menu	Menu	+					
▼	▼	V						
EXIT	Exit	Exit						
VOL+	V+	V+						
i +	Info	Info						
CH+	Page+	Next						
	V-	V-						
MUTE	Mute	Mute						
CH-	Page-	Prev						
1	1	1						
2	2	2						
3	3	3						
4	4	4						
5	5	5						
6	6	6						
7	7	7						
8	8	8						
9	9	9						
Guide 1.	Guide	Guide						
0/10	0	0						
Fav 2.	Fav	Fav	<u> </u>					