Távirányító segédlet

Varga András Távirányító Specialista

Tel.: (06-1) 338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ORION DVD5000A v2							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
ப	Power	Open/Close						
ΑV	Source							
TEXT	Prog							
TV	Video SW							
Ō								
	Subtitle							
≡≑	Zoom	Angle						
Back	Repeat	A-B						
≣X Epg∢i	Slow							
≣.º	Step							
¥	Stop							
i II	Play/Pause			1				
Red								
Green	Rev							
Yeilow	Play/Pause							
Blue	Fwd							
日	Audio							
	A							
Pict	Setup							
■	-							
OK	Enter							
NATA III I	N	DDO					-	
MENU	Menu	PBC					-	
TVIT	•							
EXIT	\/ali vaa a							
VOL+	Volume+							
CH+	Display							
	Next							
VOL- MUTE	Volume-							
CH-	Mute							
1	Prev 1							
2	2			+				
3	3			+				
4	4			+				
5	5			+				
6	6			+				
7	7							
8	8			1		-		
9	9			1				
Guide 1.	10+			+				
0/10	0			+				
Fav 2.	Goto							
PIC -	30.0			+	 			