## Távirányító segédlet

Varga András Távirányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ORION HT600 v1							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
ப	Power	Open						
AV	Mode							
TEXT	Title							
TV	Program							
Ģ								
	Subtitle							
≡≑	Zoom	Angle						
Back	Repeat	A-B						
≣X Epg <b>∢</b> I	Clear							
	Shuffle							
<b>■X</b>	Stop							
i II	Play/Pause							
Red								
Green <b>◄</b> ◀	Search-							
Yeilow	Play/Pause							
Blue ▶▶	Search+							
A	Audio	Sound Eff.						
	<b>A</b>							
Pict	Setup							
<b>A</b>	<b>⋖</b>							
OK	Select							
MENU	Menu							
•	•							
EXIT	Return							
VOL+	Volume+							
i +	Display							
CH+	Skip/Frame							
VOL-	Volume-							
MUTE	Mute	Test Tone						
CH-	Skip/Frame							
1	1	Speaker						
	2							
	3							
	4							
	5							
	6							
7	7							
	8							
	9							
Guide 1.	+10							
	0							
Fav 2.	Srch.Mode							