## Távirányító segédlet

## Varga András Távirányító Specialista

Tel.: (06-1) 338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV ORION HT500A v2		VCR/DVD		SAT		AUX	
	ப	Power	Open					
ΑV	Source							
TEXT		Title/Band						
TV	DVD/USB							
Û								
	Subtitle							
≡≑	Zoom/Mem							
Back		Repeat						
≣X Epg∢l								
≣.º	Step	A-B						
<b>₩</b>	Stop							
in	Pause							
Red								
Green	Rev	D						
Yeilow	Play	Direct Play						
Blue	Fwd							
В	Audio	Prologic						
	<b>A</b>							
Pict	Setup							
<b>O</b> 1(								
OK	Enter							
NATALLI.	Manu /DDC							
MENU	Menu/PBC							
EXIT	•	0						
	\/ali vaa a	Сору						
VOL+	Volume+							
CH+	Display	Tunor						
VOL-	Next Volume-	Tuner+	-					
MUTE	Mute		-					
CH-	Prev	Tuner-	-					+
1	1	i uner-						+
2	2		-					
3	3							
4	4							
5	5		-	+				
6	6							
7	7							
8	8							
9	9							
Guide 1.	-/		<u> </u>	+				
0/10	0/10							
Fav 2.	Search							
b/C	5541511							+