Hazard ID	Situational Analysis							Hazard Identification						Hazardous Event Classification						Determination of ASIL and Safety Goals	
	Oncombinate Marks	Operational	Environmental Details	Situation Details	Other Details (ontional)	frunction)	Situation Description	Function	Deviation	Deviation Details	Hazardous Event	ent Event Details	Hazardous Event	Exposure	Rationale	Severity (of notential harm)	Rationale (for severity)	Controllability (of hazardous event)	Rationale (for controllability)	ASIL	Safety Goal
	Operational mode	Scenario									(resulting offeet)		Description	(of situation)	(for exposure)					Determination	Salety Goal
HA-001	OM03 - Normal Driving	OS04 - Highway	EN06 - Rain (slipper)	SD02 - High speed		IU01 - Correctly	Normal driving on a highway during rain	Lane Departure	DV04 - Actor	The Lane Departure	EV00 - Collition with	High haptic feedback can affect	The Lane Departure Warning	E3 - Medium	Driving on a highway with rain	S3 - Life-threatening or	High speed collision	C3 - Difficult to control	It is very difficult for a driver to control the car in	С	The oscillating steering torque from the
HA-002	OM03 - Normal Driving	OS03 - Country Road	EN01 - Normal	SD02 - High speed		IU02 - Incorrectly	Normal driving on a country road during	Lane Keeping	DV03 -	Lane Keeping function is	EV00 - Collition with	Driver misuses the feature as an	The driver do not use the	E2 - Low	Driving on a country road and	S3 - Life-threatening or	High speed collision	C3 - Difficult to control	Since driver's both hands not on the steering	В	The Lane Keeping Assistance function
HA-003	OM03 - Normal Driving	OS04 - Highway	EN01 - Normal	SD02 - High speed		IU01 - Correctly	Normal driving on a country road during	Lane Departure	DV02 -	The camera sensor stop	EV00 - Colltion with	The Lane Departure Warning	The Lane Departure Warning	E3 - Medium	Driving on a highway with rain	S3 - Life-threatening or	High speed collision	C3 - Difficult to control	When the driver loose control of the vechicle is		The Lane Departure Warning function
HA-004	OM03 - Normal Driving	OS03 - Country Road	EN01 - Normal	SD02 - High speed		IU01 - Correctly	Normal driving on a country road during	Lane Keeping	DV02 -	The camera sensor stop	EV00 - Colition with	The Lane Keeping Assistance	The Lane Keeping Assistance	E3 - Medium	Driving on a highway with rain	S3 - Life-threatening or	High speed collision	C3 - Difficult to control	When the driver loose control of the vechicle is	С	The Lane Keeping Assistance function