

REGISTER TRANSFERS

- ❖ In computer architecture, register transfer refers to the process of copying data between registers, which are small, fast storage locations within the CPU.
- ❖ It involves the use of a register transfer language (RTL), a symbolic notation for describing these data movements and the micro-operations (like addition or shift) performed on the data.

-
- ❖ A register transfer statement, such as $R1 \rightarrow R2$, indicates that the contents of register $R1$ are copied into $R2$. This action requires control signals to execute and data lines to facilitate the simultaneous, parallel transfer of bits during a single clock pulse, without altering the source register.

KEY CONCEPTS

❖ **Registers:**

- ❖ Small, high-speed storage units within a processor used to hold data for immediate processing.

❖ **Micro-operations:**

- ❖ The basic operations performed on the data stored in registers, such as data transfer, addition, subtraction, or shifting.

❖ **Register Transfer Language (RTL):**

- ❖ A symbolic language used to describe the micro-operations and the flow of data between registers in a digital system.

❖ **Control Functions:**

- ❖ Control signals that initiate or allow a register transfer to occur only when a specific condition is met (e.g., $P: R1 \rightarrow R2$ only happens when control signal P is 1).

HOW REGISTER TRANSFER WORKS?

- ❖ **Source and Destination:**

A register transfer involves a source register (where data is read from) and a destination register (where data is written to).

- ❖ **Parallel Transfer:**

All bits of data from the source register are copied to the destination register simultaneously during one clock pulse.

- ❖ **Non-Destructive:**

The transfer is non-destructive, meaning the content of the source register remains unchanged after the data is copied.

- ❖ **Hardware Implementation:**

Register transfers require specific hardware logic circuits, including data lines connecting the registers and control lines to manage the transfer process.

- ❖ **Control:**

A control function or signal determines when the transfer takes place, allowing for conditional execution of operations.

EXAMPLE

- ❖ $R2 \leftarrow R1$: This RTL statement signifies that the data stored in register R1 is copied into register R2.
- ❖ $P: R1 \rightarrow R2$: This means that the contents of R1 are transferred to R2 only when the control signal P is active ($P = 1$).









