

网络编程入门篇

利用 socket 实现 TCP 客户端

目录

- 基础知识
- 具体示例
- 示例代码讲解





基础知识

基础知识


- socket 编程一般采用客户端-服务器模式(即由客户进程向服务器进程发出请求,服务器进程执行请求的任务并将执行结果返回给客户进程的模式。)
- 今天我们要讲的就是如何利用 socket 编程实现基于 TCP 协议通信的客户端。
- 首先我们先向大家展示 socket 编程的流程,然后再给出具体的实例,最后讲解一下示例代码。



基础知识

TCP 客户端的 socket 编程流程如右图所示:

- 创建 socket
- 建立连接
- 通信
- 关闭 socket







具体示例

工程配置

- RT-Thread samples 软件包中已有一份该示例代码 tcpclient.c,可以通过 env 配置将示例代码加入到项目中。
- 按照下面的路径即可开启 tcp client 的示例代码


```
RT-Thread online packages --->
miscellaneous packages --->
samples: RT-Thread kernel and components samples --->
network sample options --->
[*] [network] tcp client
```

- 保存并更新软件包 pkgs --update
- 编译工程 scons
- 然后运行qemu



开启TCP服务器

• 在运行示例代码之前需要先在电脑上开启一个 TCP 服务器,这里以网络调试助手 IPOP 为例。





查看本机ip地址

• 在windows系统中打开命令提示符,输入ipconfig即可查看本机ip

```
■ 管理员: 命令提示符
C:\WINDOWS\system32>
C:\WINDOWS\system32>ipconfig
Windows IP 配置
以太网适配器 以太网 2:
                                     2001:470:d:aa9:a945:38e7:1ee2:1119
                                    : 2001:470:d:aa9:14fb:d705:f25a:fb26
                                      fe80::a945:38e7:1ee2:1119%7
                                    : 255, 255, 255, 0
                                      fe80::ce2d:e0ff:fe05:3b5a%7
                                      192, 168, 10, 1
以太网适配器 tap:
                                      fe80::d462:3cb4:193:1998%3
                                      255, 255, 255, 0
```



运行示例代码

• 在qemu运行起来后,在 msh 命令行下输入下面的命令即可让示例代码运行。

msh> tcpclient 192.168.12.44 5000

- tcpclient 有两个参数 URL PORT
- 其中:
- URL 是目标服务器的网址或 IP 地址
- PORT 是目标服务器的端口号

```
msh />tcpclient 192.168.12.44 5000

Received data = Welcome to TcpSrv
```



从服务器发消息给客户端



发送字符 'q' 即可断开连接


```
Received data = hello
Received data = hello
Received data = hello
got a 'q' or 'Q',close the socket.
msh />
```



注意事项

• 电脑需要关闭防火墙





```
#include <rtthread.h>
#include <sys/socket.h> /* 使用BSD socket,需要包含socket.h头文件 */
#include <netdb.h>
#include <string.h>
#define BUFSZ 1024
static const char send_data[] = "This is TCP Client from RT-Thread."; /* 发送用到的数据 */
void tcpclient(int argc, char **argv)
  int ret:
  char *recv_data;
  struct hostent *host;
  int sock, bytes received;
  struct sockaddr in server addr;
  const char *url;
  int port;
  if (argc < 3)
    rt kprintf("Usage: tcpclient URL PORT\n");
    rt kprintf("Like: tcpclient 192.168.12.44 5000\n");
    return;
```



```
url = argv[1];
port = strtoul(argv[2], 0, 10);
/* 通过函数入口参数url获得host地址(如果是域名,会做域名解析) */
host = gethostbyname(url);
/* 分配用于存放接收数据的缓冲 */
recv data = rt malloc(BUFSZ);
if (recv data == RT NULL)
 rt kprintf("No memory\n");
 return;
/* 创建一个socket,类型是SOCKET_STREAM,TCP类型 */
if ((sock = socket(AF INET, SOCK STREAM, 0)) == -1)
 /* 创建socket失败 */
 rt kprintf("Socket error\n");
 /* 释放接收缓冲 */
 rt_free(recv_data);
 return;
```



```
/* 初始化预连接的服务端地址 */
  server addr.sin family = AF INET;
  server_addr.sin_port = htons(port);
  server addr.sin addr = *((struct in addr *)host->h addr);
  rt memset(&(server addr.sin zero), 0, sizeof(server addr.sin zero));
  /* 连接到服务端 */
  if (connect(sock, (struct sockaddr *)&server addr, sizeof(struct sockaddr)) == -1)
    /* 连接失败 */
    rt_kprintf("Connect fail!\n");
    closesocket(sock);
   /*释放接收缓冲 */
    rt free(recv data);
    return;
  while (1)
    /* 从sock连接中接收最大BUFSZ - 1字节数据 */
    bytes received = recv(sock, recv data, BUFSZ - 1, 0);
    if (bytes received < 0)
```



```
/*接收失败,关闭这个连接*/
 closesocket(sock);
 rt kprintf("\nreceived error,close the socket.\r\n");
 /* 释放接收缓冲 */
 rt_free(recv_data);
  break;
else if (bytes received == 0)
 /* 默认 recv 为阻塞模式,此时收到0认为连接出错,关闭这个连接 */
 closesocket(sock);
 rt_kprintf("\nreceived error,close the socket.\r\n");
 /* 释放接收缓冲 */
 rt free(recv data);
  break;
/* 有接收到数据,把末端清零 */
recv_data[bytes_received] = '\0';
if (strncmp(recv_data, "q", 1) == 0 || strncmp(recv_data, "Q", 1) == 0)
```



```
/* 如果是首字母是q或Q, 关闭这个连接 */
     closesocket(sock);
     rt kprintf("\n got a 'q' or 'Q',close the socket.\r\n");
     /* 释放接收缓冲 */
     rt_free(recv_data);
     break;
   else
     /* 在控制终端显示收到的数据 */
     rt kprintf("\nReceived data = %s ", recv data);
   /* 发送数据到sock连接 */
   ret = send(sock, send_data, strlen(send_data), 0);
   if (ret < 0)
     /*发送失败,关闭这个连接 */
     closesocket(sock);
     rt_kprintf("\nsend error,close the socket.\r\n");
     rt_free(recv_data);
     break;
```

```
else if (ret == 0)
{
    /* 打印send函数返回值为0的警告信息 */
    rt_kprintf("\n Send warning,send function return 0.\r\n");
    }
}
return;
}
MSH_CMD_EXPORT(tcpclient, a tcp client sample);
```

