

REV	REVISION DESCRIPTION
A	

CONFIDENTIAL

OPENING FOR TEMPERATURE
AND PRESSURE RELIEF DEVICE.

IMPORTANT

FOLLOW THE MAINTENANCE PROCEDURES
FOR RELIEF VALVES AS DIRECTED IN THE
INSTRUCTION MANUAL. THE TEMPERATURE
AND PRESSURE RELIEF VALVE PROVIDED
BY THE MANUFACTURER SHALL BE
INSTALLED AT THE TIME OF INSTALLATION
OF THE HEATER IN THE LOCATION
SPECIFIED BY THE MANUFACTURER. LOCAL
CODES SHALL GOVERN INSTALLATION OF
RELIEF DEVICES. FOR SAFE OPERATION OF
THE WATER HEATER, THE RELIEF VALVE
MUST NOT BE REMOVED OR PLUGGED.

OUVERTURE POUR LA SOUPAPE DE
DÉCHARGE TEMPÉRATURE ET PRESSION.

IMPORTANT

SIGA LOS PROCEDIMIENTOS DE MANTENIMIENTO
PARA LAS VÁLVULAS DE ALIVIO TAL COMO SE
INDICA EL MANUAL DE INSTRUCCIONES.
LES SOUPAPES DE DÉCHARGE FOURNIES PAR
LE FABRICANT DOIVENT ÊTRE INSTALLÉES EN
MÊME TEMPS QUE LE CHAUFFE-EAU, À
L'ENDROIT INDIQUÉ PAR LE FABRICANT. LES
RÈGLEMENTS LOCAUX RÉGISSSENT
L'INSTALLATION DES SOUPAPES DE DÉCHARGE.
POUR ASSURER LE FONCTIONNEMENT
SÉCURITAIRE DU CHAUFFE- EAU, NE PAS
RETIRER NI OBTURER LA SOUPAPE
DE DÉCHARGE.

FRENCH PORTION ONLY ON
MODELS SOLD IN CANADA

NOTES:

1. TEXT TO BE BLACK ON A WHITE BACKGROUND.

BLANK NO.	SUPPLIER	 BRADFORD WHITE CORPORATION	DRAWING UNITS AND TOLERANCE IN INCHES UNLESS OTHERWISE SPECIFIED FRACTIONAL DECIMAL 0.00 DECIMAL 0.000 ANGLES DO NOT SCALE	DWN BY	RMC	DATE	1/15/25	NAME	LABEL-T & P (ENGLISH & FRENCH)
THICKNESS	MATL			CHK BY		DATE			
INSPECTION CRITERIA	ALL ITEMS IN BRACKETS []			ECO BY		ECO NO.		DWG	AG-42821-00
		PAGE	1 OF 1	SCALE	NONE				