

Omnix Application Workflow Documentation

Operator Training Manual (Step-by-Step)

The Omnix Production Lifecycle (End-to-End Flow)

Understanding the sequence of operations is critical. Omnix is designed as a continuous, unbroken loop:

1. **Inbound Setup:** **Gate Entry** logs incoming shipments, updating **Inventory** (Raw Materials). **BOM** defines the product recipes.
 2. **Demand Creation:** **Purchase Orders** capture client demand, which directly trigger internal **Working Orders**.
 3. **Floor Execution:** **Material Requests** pull raw stock to the line. **Material Transfers** move items between stages. The **WIP Board** monitors this active flow.
 4. **Validation & Outbound:** **QC Check** validates the produced batches. Yields push to **Inventory** (Finished Goods) and are dispatched via **Gate Exit**.
-

Table of Contents

1. Module 1: BOM (Bill of Materials)
 2. Module 2: Purchase Order
 3. Module 3: Working Order
 4. Module 4: WIP Board
 5. Module 5: Material Transfer
 6. Module 6: Material Request
 7. Module 7: QC Check
 8. Module 8: Inventory
 9. Module 9: Gate Entry
 10. Module 10: Gate Exit
 11. System Settings & Administration
-

0. Dashboard & System Overview

The central hub for monitoring production vitals and quick navigation.

Navigation: Click **Dashboard** in the sidebar.

Layout Highlights:

1. **Top Metrics Cards:** View real-time aggregates for **Live Orders** , **Material Shortages** , **Rework Alerts** , and **Work Orders Completed** . (Click the **Refresh** top-right button to pull latest data).
 2. **Quick Actions Panel:** Direct shortcuts to **Plan Materials** (BOMs), **View Orders** , **WIP Board** , and **QC Check** .
 3. **Recent Activity:** A chronological feed of recent system events (e.g., "Material Request Approved: MR-2026-0010").
-

1. Module 1: BOM (Bill of Materials)

Foundational formulation structures mapping raw materials demand buffers.

1.1: Creating a New Bill of Materials

Navigation: Click **BOM** on the sidebar.

Instructions:

1. **Open Modal:** Click the "+ **Create New BOM**" button (Teal) at the top right.
 2. **Fill Identity Header:**
 - Click into the **Product Code** * field and type or select the Product ID (e.g., JK-001).
 - Click into the **Product Name** * field and type the descriptive name label texts.
 3. **Fill Materials Grid** * (Ingredients List):
 - **Item Code:** Click the dropdown index and select target Raw Material configuration setups.
 - **Material:** Click input box and type detailed setup alerts (e.g., "Cotton Fabric").
 - **Quantity:** Click input and type numerical allocation triggers (e.g., 0.00).
 - **Unit:** Click dropdown and choose multipliers bounds indices (**kg** , **pcs** , **meters**).
 - **Unit Cost:** Click input and type budget allocation costs.
 - *Need more rows?* Click the "+ **Add Material**" button at the bottom of the grid.
 4. **Save Action:** Click "**Create BOM**" teal modal footer button to confirm formulation securely.
-

2. Module 2: Purchase Order

Launching Demand limits executing manufacturing triggers anchors.

2.1: Creating a Purchase Order

Navigation: Click **Purchase Orders** on the sidebar.

Instructions:

1. **Open Modal:** Click the "+ **New Order**" blue button (top right).
2. **Fill Select Product:**
 - Click the "**Choose product...**" dropdown indexing target finished Good produce.
 - Click the **Enter Quantity** input value typing ordered counts buffers multipliers.
 - *For multi-item orders:* Click the "+ **Add Another Product**" button for multiple packages loads multipliers.
3. **Fill Order Settings:**
 - Click the **Due Date** * Calendar icon select target timeline calendar shifts boundaries.
 - Click the **Order Priority** dropdown set limits (e.g., Normal, High).
4. **Append Details:**
 - Click **Order Notes** and type special instruction remark lists alerts.
5. **Save Action:** Click "**Create Order**" button footer overlays bottom setup updates directly logging demand.

2.2: Managing Purchase Orders & Actions

Navigation: Click **Purchase Orders** in the sidebar to view the main grid.

Instructions:

1. **Search & Filter:** Use the **Search orders...** bar to locate specific POs, or click **Refresh** to update the grid.
2. **View Status:** Observe columns such as **Order Priority** (e.g., Medium, High), **Status** (e.g., Planned), **Progress**, and **Days Until Due**.
3. **Action Menu (Bridging to Work Orders):** Click the **Three Dots ("⋮")** icon under the **Actions** column to access order-specific tools. Available features include:
 - **View Details**, **Edit Order**, **Duplicate Order**, **Print Order Sheet**
 - **Track Progress**, **Production Plan Timeline**, **Assign to Team**
 - **Create Working Order** (Clicking this directly bridges you to Module 3, initiating manufacturing execution).
 - **Add Notes**, **Download BOM**, **Export to Excel**, **Generate QR Code**, **Send to Production**, **Request Materials**.

3. Module 3: Working Order

Setting operation activation shifts sequences trigger loops.

3.1: Creating a Work Order (Manufacturing execution)

Navigation: Click **Working Order** on the sidebar.

Instructions:

1. **Open Modal:** Click "+ **New Work Order**" green action button.
2. **Fill Identity Details:**
 - Click **Purchase Order** * dropdown list index target PO header ID benchmarks.
3. **Fill Stage Configuration:**
 - Click **WIP Stage Configuration** * dropdown choosing defaults (e.g., "Auto-assign Based on Product/Rules").
4. **Fill Shifts & Timelines:**
 - Click **Shift** dropdown select target hours multipliers bounds (e.g., "MIDNIGHT Shift - 3").
 - Click **Start Date & Time** inputs and select calendar limits.
5. **Fill Quantities buffers:**
 - Click **Quantity** * and type total produce target count.
6. **Add Details:**
 - Click into **Notes** textareas type remark sequences setup dialogs.
7. **Save Action:** Click "**Create Work Order**" green button.

3.2: Tracking Work Order Progress

Navigation: Click a specific Work Order from the active lists views.

Instructions:

1. **Header Details:** View the current badge status (e.g., **In Progress**), **Medium Priority**, and the Assigned shift (e.g., **Assigned to: Morning**).
2. **Operation Progress:** View individual stage tracking cards (e.g., **cutting**, **Packing**) to see counts for **Transferred** versus **In Process / Remaining** units.
3. **Overall Progress Bar:** Track the holistic completion percentage (e.g., **0 of 100 units (0%)**).
4. **Bottom Action Bar:** Click the "**|| Pause**" button to temporarily halt the tracking timer, or the "**Complete**" green button to finalize the operation run.

4. Module 4: WIP Board

Real-time interactive monitoring of manufacturing order progression and bottlenecks.

4.1: WIP Live Board Monitoring

Navigation: Click **WIP Board** in the sidebar.

Instructions:

1. Click the **Select PO / WO...** dropdown (top right) to pick an active manufacturing order.

2. Once selected, the board populates four key live metric cards: **Total Orders**, **Total Units**, **Avg Cycle Time**, and alerting **Bottleneck** identifiers (e.g., **Cutting**).

5. Module 5: Material Transfer

WIP Floor logistics for moving active materials between operational stages.

5.1: Transfer Material (WIP Stage Transfer)

Navigation: Click **Material Transfer** in the sidebar.

Instructions:

1. **Open Transfer View:** Select or initiate a transfer view layout.
2. **Fill Order reference & Layout View Stocks:**
 - Click **Work Order (Optional)** dropdown lists target setup benchmarks. Notice *Available Stock* text strings.
3. **Fill Transfer Layout:**
 - View **From Location / From Stage** limits labels text list.
 - Click **To Location / To Stage *** dropdown assigning destinations.
 - Click **Transfer Quantity *** and type numeric constraints.
 - Click **Priority** and set specific tracking layers (**Normal** , etc.).
 - Click **Transfer Reason *** setups texts text descriptors.
4. **Save Action:** Click "Confirm Transfer" green buttons footer.

6. Module 6: Material Request

Requesting raw materials from inventory locations to the production floor.

6.1: Material Requisition Form

Navigation: Click **Material Request** in the sidebar.

Instructions:

1. **Fill Order Details Header:**
 - Click **Work Order** dropdown.
 - Click **Department** dropdown (**Select Department / Stage**).
 - Click **Shift Number** and select active hours setups (**MIDNIGHT (Shift - 3)**).
2. **Fill Personnel:**
 - Click **Requested By** and input operator descriptors.
 - Click **Reviewed By** and input supervisor credentials.

3. Fill Material Items List:

- Click **RM Code** dropdown.
- Notice **Material Description** and **Unit of Measure** populate automatically.
- Click **Quantity** and input transfer bounds setup sets.
- Click **Location** typing destination layout constraints.
- Click **Priority** and set urgency targets (**Normal** , **High**).
- *Need more rows?* Click the "+ **Add Item**" button.

4. Add details & Submit Action:

- Click into **Delivery Instructions** text area and type setup dialogue context limits.
- Click the "**Submit Requisition**" blue button.

6.2: Managing Material Requests (Notifications Panel)

Navigation: Triggered from active screens, an overlay panel titled **Material Request Notifications** appears (via the blue bell alert icon).

Instructions:

1. Navigate between the **Pending Requests** and **Approved Requests** tabs at the top.
2. Review incoming requests mapping the source department and the exact status badge (**Pending** or **Approved**).

7. Module 7: QC Check

Auditing Finished Goods completions before dispatch setup.

7.1: Inspecting Completed Batches (QC Check)

Navigation: Click **QC Check** in the sidebar.

Instructions:

1. **Select Target Order:** Use the **Search order number...** input bar, or sequentially click the **Select Purchase Order** > or **Select Work Order** > dropdowns to target the finished goods. Alternatively, click **Scan QR**.
2. **Log Inspection Failures:** Under the **Defect Library** (left panel), click the explicit defect categories (**Cracks** , **Dimensions** , **Scratches** , **Color Defects** , **Stitching Issues**) to accurately record structural or cosmetic flaws discovered during audit.
3. **Monitor Live Analytics:** On the right panel, observe the three circular dials automatically calculating real-time ratios for the order (**Pass** , **Rework** , and **Scrap** percentages).
4. Below the dials, view the **7-Day Yield Trend** line chart to gauge performance stability over the week.

5. **Export Logs:** Click the **Export Report** button (top right of Analytics) to generate an external audit trail document.
-

8. Module 8: Inventory

Viewing real-time physical allocation locks status alerts.

8.1: Add New Material

Navigation: Click **Inventory** in the sidebar.

Instructions:

1. **Open Modal:** Click "Add New Material" button overlays constraints.
 2. **Fill Material Information:**
 - Click into the **Material Code *** text field.
 - Click into the **Material Name *** text field.
 3. **Fill Quantity & Measurement:**
 - Click **Available Quantity ***.
 - Click **Unit of Measurement ***.
 4. **Fill Location & Stock Levels:**
 - Click **Reorder Level ***.
 - Click **Unit Cost ***.
 - Click **Storage Location ***.
 - Click **Status *** dropdown.
 5. **Save Action:** Click "Add Material" green button directly configurations setup.
-

9. Module 9: Gate Entry

Logging incoming logistics.

9.1: Logging Vendor Arrivals (Gate Entry)

Navigation: Click **Gate Entry** in the sidebar.

Instructions:

1. **Open Screen:** The default view is the **New Entry** tab. (To view past logs, click the **Entry History** tab).
2. **Fill Logistics Details:**
 - Click the **Entry Type *** dropdown (e.g., **Material Delivery**).
 - Click into **Vendor / Source *** and type the supplier name.

- Click into **Vehicle Number** and type license plates.
- Click into **Driver Name** and type the operator's name.
- Click into **Linked Document** and type the **PO/Invoice/DC number**.
- Click the **Destination Department *** dropdown and select the target area.

3. Fill Materials / Items *:

- Click **Enter code** text input.
- Click **Enter material name** text input.
- Click the **Quantity** numerical input (defaults to **0**).
- Click the **Unit** dropdown (**kg** , **pcs** , **meters** , etc.).
- Click the **"Add Material"** button to append additional row limits.

4. Add Remarks & Media:

- Click into the **Remarks** text area and type notes or observations.
- Click into **Photos (URLs)** to paste image links, and click "+" to attach.

5. Save Action: Click "Create Entry" (purple button) at the modal footer to log securely.

9.2: Viewing Gate Entry History

Navigation: Click **Gate Entry** in the sidebar.

1. Click the **Entry History** tab at the top.
2. Use the **Search entries...** bar and click the **"Search"** blue button to filter logs.
3. View the grid columns for context: **ID** , **Entry Type** , **Vendor / Source** , **Vehicle Number** , **Materials / Items** , **Destination Department** , **Status** , **Date & Time** , and **Actions**.

10. Module 10: Gate Exit

Logging dispatch outbounds.

10.1: Logging Dispatch Outbound (Gate Exit)

Navigation: Click **Gate Exit** in the sidebar.

Instructions:

1. **Open Modal:** Click the **"Create Gate Exit"** purple button to open the dispatch modal overlay.
2. **Fill Outbound Details:**
 - Click the **Exit Type *** dropdown (e.g., **Finished Goods Dispatch**).
 - Click into **Destination *** and type the target location.
 - Click into **Customer / Party** and type the client's name.
 - Click into **Vehicle Number** and type the license plates.
 - Click into **Driver Name** and type the operator's name.

- Click into **Linked Document *** and type the **SO/DC/Challan number** .

3. Fill Materials / Items *:

- Click **Enter code** text input.
- Click **Enter material name** text input.
- Click the **Quantity** numerical input (defaults to **0**).
- Click the **Unit** dropdown (**pcs** , etc.).
- Click the **"Add Material"** button to append additional row limits.

4. Add Remarks:

- Click into the **Remarks** text area and type dispatches context notes.

5. Save Action: Click **"Create Exit"** (purple button) to finalize the outbound logs tracking limits securely.

10.2: Viewing Gate Exit History

Navigation: Click **Gate Exit** in the sidebar.

1. Similar to the entry stream, navigate to the **History** tab (or historical views) to view past outbound logs grids columns.

11. System Settings & Administration

A. Managing User Profile

Navigation: Click the **User Profile Icon** (e.g., Administrator **A**) at the bottom left of the sidebar, then click **View Profile** in the popover menu.

1. **View Details:** Review account parameters such as **Email** (e.g., **admin@omnix.com**), **Mobile** , **Department** (e.g., **Production**), and **Employee ID** (e.g., **ADMIN**).
2. **Edit:** Click the **"Edit Profile"** green button to update contact details. Or click **"Close"** to dismiss the modal.

B. General Settings (Language & Theme)

Navigation: Click the **User Profile Icon** -> **Settings**.

1. **Language:** Under **General Settings**, select your preferred interface localization (**English** , **Hindi** , **Kannada** , **Tamil** , **Telugu** , **Marathi** , **Gujarati** , **Punjabi**).
2. **Theme:** Toggle the visual display mode between **Light** or **Dark** .

C. Preferences & Localization

Navigation: Within **Settings**, view the **Preferences** panel.

1. **Default Location:** Click the dropdown to set the default warehouse location (e.g., **Main Warehouse**).
2. **Date Format:** Click the dropdown to choose how dates are displayed (e.g., **DD/MM/YYYY**).
3. **Time Zone:** Click the dropdown to set your operational time zone (e.g., **Asia/Kolkata (IST)**).

D. Notification Preferences

Navigation: Within **Settings**, scroll to the **Notifications** section.

1. Use the green switches to toggle alerts on/off for: **Email Notifications** , **Push Notifications** , **Order Updates** , **Inventory Alerts** , and **Production Alerts** .

E. Worker Module Access Control

Navigation: Within **Settings**, scroll to the **Worker Module Access** section.

Instructions:

1. **Granting Access:** The grid displays all accessible modules against individual worker accounts (e.g., **worker one** , **Worker two**). Check the specific box to grant module permissions.
2. **Note:** The **Dashboard** is **Always On** and cannot be disabled.
3. **Future Upgrade (User Scaling):** Currently, workers are displayed in columns. In future iterations to handle large numbers of users, an **Account ID Dropdown Menu** will be introduced. Administrators will choose a specific Worker account from this dropdown before checking off their granted modules.
4. Optionally, click the **Refresh** button (top right).

F. WIP Stage Configurations

Navigation: Within **Settings**, scroll down to **WIP Stage Configurations**.

Instructions:

1. **Review existing Flows:** View operational tracking flow cards, such as **Default** (Standard production flow), **Type 2** (Secondary flow), or **Type 3** (Tertiary flow).
2. **View Stages:** Each flow lists operations procedurally (e.g., **1 Sewing (SEWING)** , **2 Cutting (CUTTING)**). Use the **edit (pencil)** or **delete (trash)** icons for existing stages.
3. **Add New Stage:** Click the "+" green button at the top right of a flow card to open the **Add New Stage** modal.
 - o Enter **Name** (e.g., **Enter stage name**).
 - o Enter **Code** (e.g., **CODE**).
 - o Enter **Target Time (min)** (e.g., **30**).
 - o Select **Color** using the hex code picker (e.g., **#3B82F6**).
 - o Toggle **Active** on/off.
 - o Click **"Save"**.

4. **Assign SKU/WO:** At the bottom of each flow card, assign operations directly to product chains by using the "Add SKU or WO#" input and clicking **Assign**. Existing assignments (e.g., SKU FG00009) are listed above the input.

G. Shift Configuration

Navigation: Within **Settings**, scroll to the **Shift Configuration** section.

Instructions:

1. **Review active shifts:** View current manufacturing operation allocations, such as:
 - MIDNIGHT (Shift - 3) from 01:00 - 09:00
 - MORNING (Shift - 1) from 09:00 - 17:00
 - EVENING(Shift - 2) from 17:00 - 01:00
2. Use the **Active toggle**, **Edit (pencil)**, or **Delete (trash)** actions for each row.
3. **Add New Shift:** Click the "+ Add Shift" blue button (top right).
 - On the *New Shift* block, fill the **Shift Name** (e.g., e.g. Night Shift).
 - Click **Start Time** and **End Time** to select operational bounds.
 - Click **"Save Shift"**.
4. **Save Changes:** At the bottom right corner of the screen, click the sticky **"Save Changes"** green button to finalize updates configuration-wide.