Scale Channel

- + hwTarget: String
- + app-module: String
- + dutBoard: String
- + channel_name: String
- + rpn: String
- + scale: float
- + offset: float
- + unit: char
- + description: String
- +From serial form
- +To serial form

scaling: Scale Channel

- + hwTarget: String
- + app-module: String
- + dutBoard: String
- + channel_name: String
- + rpn: String
- + scale: float
- + offset: float
- + unit: char
- + description: String
- +From serial form
- +To serial form

Scale HW Targets

- +date
- +scaling
- +From serial form
- +To serial form