

BOOST LOP – Train 2

Centrifuge Test For Oil BS&W Cut

PURPOSE: Provide steps to collect sample and analyze.

OBJECTIVE: Safely collect sample and use Centrifuge to analyze.

SCOPE: Safety run a sample method.

1 CLASSIFICATION DATA:

Approved: *September 4, 2017*

Review Cycle: [3] year

Reviewers: Local SMEs

Curt Bourgeois

Approver: Operations Supervision

Carmen Berry

Craft:

Process Engineer

Man-hours:

20 min

SAFETY, ENVIRONMENTAL, AND ASSET CONSEQUENCES

<u>RAM Rating</u>	<u>Severity & Likelihood</u>	<u>Rating</u>
Safety Consequence	Slight Injury, Heard of in industry	P1B
Environmental Consequence	No Impact, Never heard of in industry	E0A
Asset Consequence	Slight damage less than \$10,000, Heard of in industry	A1B

Permits and plans (those checked are required)			
	JSA		Hot Work Permit
	Safe Work Permit		Fall Rescue Plan
	Safe Work Plan		Confined Space Entry
	Lock Out/Tag Out		Leadership Walkthrough
	Isolated work is allowed		Trip Tricky Tasks
	Step Sign off Required (High Rating)		Statement of Fitness (may be required)
Special PPE Required (those checked are required)			
	Chemical Resistant Gloves		Additional Hearing Protection-Ear Muffs
	Face Shield		Respirator
	Chemical Resistant Goggles		Fresh Air Pack
	Chemical Resistant Apron		

TOOLS/EQUIPMENT REQUIRED

- Radios
- Hand tools
- Proper PPE

2 CONSUMABLES (MMR IF APPLICABLE)

MMR #	Consumables Description	Qty
	N/A	

3 PARTS (MMR IF APPLICABLE)

MMR #	Parts Description	Qty
	N/A	

SPECIAL EXECUTION CONSIDERATION

1. All procedures require sign off upon completion each step.

WORK INSTRUCTION

Signoff	Operation Step
1. _____	Take a sample from the oil outlet of the bulk oil treater. The sample tap is located just upstream of LCV – 301A/302A/303A. (Last number correlates to train number).
2. _____	Samples should be taken in two 200 ml certified centrifuge tubes. Fill tubes to the 100 ml mark. Vapors may ignite, causing flashing fire. Wear proper PPE (Gloves and safety glasses). <i>Note: Vapors may ignite, causing flashing fire. Use Gas Monitor to detect LEL.</i>
3. _____	Place tubes into heater and let the samples heat to 115-120 degrees. Ensure applied heat does not exceed the vapor temperature of the oil and water.
4. _____	Place tubes onto opposite sides of the centrifuge to maintain balance.
5. _____	Spin the centrifuge for five minutes tests at 70 percent power. Flammable vapors possibly present. Ensure applied heat does not exceed the vapor temperature of the oil and water.
6. _____	Obtain readings of combined basic sediment and water in percentages from the tube to the nearest 0.1 ml. <i>Note: Read the bottom of meniscus.</i>
7. _____	Average the results from the two different tubes.
8. _____	If your results are questionable, take two more samples. <i>Note: Samples that are further than .3 ml apart are questionable.</i>