

### **IPC@CHIP CLIB**

## How to integrate the CLIB

into

**Borland C++ 5.02** 

and

# Paradigm C/C++ Beck IPC Edition



© 2000-2007 Beck IPC GmbH Page 1 of 11



### **Table of Contents**

1 IN	TRODUCTION	3
_	OW TO INTEGRATE THE CLIB BINARIES AND CLIB/RTOS DOCUMENTATION INTO	4
2.1	STEP 1 – CALL THE SETUP	4
3 HC	OW TO INTEGRATE THE CLIB IN A BORLAND C 5.02 PROJECT	4
3.2 3.3 3.4 3.5	STEP 1 - INSTALL THE CLIB STEP 2 - CREATE YOUR PROGRAM DIRECTORY STEP 3 - CREATE THE BORLAND C 5.02 PROJECT STEP 4 - ADJUST THE PROJECT SETTINGS. STEP 5 - ADD THE CLIB TO THE PROJECT STEP 6 - WRITE YOUR PROGRAM.	4 5 7
4 CI	IB API DOCUMENTATION AND @CHIP-RTOS API DOCUMENTATION	11



#### 1 Introduction

The libraries provide an easy access to the IPC@CHIPs operating system using the programming language C. In addition to the binary library files, documentation in HTML format is also provided.

The CLIB software package comes in two versions:

- The setup "UpdateDocuxxxxxx\_CLIBxxx.exe" integrates the CLIB binaries and complete RTOS and CLIB documentation into the Paradigm C/C++ Beck Edition compiler, if the Paradigm compiler is installed.
  - If you are a Borland user, the setup will ask for the installation paths of the library and the documentation.
- The archive "CLIBVXXXSRC.ZIP" holds the source code of the CLIB libraries.

#### This document describes how to:

- Integrate the CLIB into your Paradigm C/C++ Beck IPC Edition compiler
- Integrate the CLIB into your Borland C 5.02 project
- Use the CLIB and @CHIP-RTOS API documentation

The library is available in 5 different models. One model for every compiler memory model:

- CLIBxxxH.lib Huge
- CLIBxxxL.lib Large
- CLIBxxxM.lib Medium
- CLIBxxxC.lib Compact
- CLIBxxxS.lib Small

#### Note:

For inexperienced users, we advise to use compiler memory model Large.

There is NO correlation between the names of the compiler memory models (Small, Compact, Medium, Large, Huge) and those of the available SC1x @CHIP-RTOS variants (Tiny, Small, Medium, Medium PPP, Large, Large PPP)!

© 2000-2007 Beck IPC GmbH Page 3 of 11



# 2 How to integrate the CLIB binaries and CLIB/RTOS documentation into Paradigm C/C++ Beck IPC Edition

#### 2.1 Step 1 – Call the Setup


Call the setup "UpdateDocuxxxxx\_CLIBxxx.exe". The setup installs/updates the CLIB binaries and the CLIB and RTOS documentation in the Paradigm installation path provided that the compiler is installed.

To use the CLIB in your Paradigm projects, include the header file "clib.h" into your C files. The library should NOT be manually added to the project (like on the Borland compiler). The Paradigm compiler automatically integrates the CLIB library file, according to the selected memory model.

### 3 How to integrate the CLIB in a Borland C 5.02 project

#### 3.1 Step 1 - Install the CLIB

First you have to call the setup "UpdateDocuxxxxxx\_CLIBxxx.exe". Choose a path where the CLIB should be copied, e.g. "C:\Projects\Clib".



You should now have a directory, e.g. "C:\Projects\Clib" with the CLIB contents.

#### 3.2 Step 2 - Create your program directory


Make a directory inside your project directory for storing your program files. For example, you now have a directory C:\Projects\Hello which is empty.

© 2000-2007 Beck IPC GmbH Page 4 of 11



### 3.3 Step 3 - Create the Borland C 5.02 project

Open the Borland C 5.02 program and create a new project.



In the field "Project Path and Name" choose the new directory, which you have created for the program followed by the project name, e.g. C:\Projects\hello\hello.ide

Make the correct project settings.

• Target Type: Application [.exe]

• Platform: DOS (Standard)

• Target Model: Large

Frameworks: Deselect Class Library


Math Support: NoneLibraries: No Exceptions

© 2000-2007 Beck IPC GmbH Page 5 of 11





Click now the "Advanced" button and choose the \*.c node type.




Close the "Advanced Options" dialog and the "New Target" dialog with "OK".

© 2000-2007 Beck IPC GmbH Page 6 of 11



#### 3.4 Step 4 - Adjust the project settings


Open the menu "Options" and select "Project...".



Select "Directories" and change the include path and the library path to:

Include: \$env(bcroot)\include;..\clib<sup>1</sup>

Library: \$env(bcroot}\lib




<sup>&</sup>lt;sup>1</sup> The expression "\$env(bcroot)" is translated to the installation directory of the Borland 5.02 compiler

© 2000-2007 Beck IPC GmbH Page 7 of 11



Now select "16-bit Compiler" and choose the "80186" instruction set for compiling.




Close the dialog with the "OK" button.

© 2000-2007 Beck IPC GmbH Page 8 of 11




#### 3.5 Step 5 - Add the CLIB to the project

Go to the project window. Use the right mouse button to click on the project node. Choose "Add node" from the popup menu.



Change the path to the CLIB directory.




Select the file extension type \*.lib or \*.\* from the lower listbox. Open the CLIB with the name "CLIBxxxL.LIB" for the Large memory model library.

© 2000-2007 Beck IPC GmbH Page 9 of 11



#### 3.6 Step 6 - Write your program

Include the header file "CLIB.H" in your C files. After this you can use all CLIB functions inside your code.



© 2000-2007 Beck IPC GmbH Page 10 of 11



### 4 CLIB API documentation and @CHIP-RTOS API documentation

The "UpdateDocuxxxxxx\_CLIBxxx.exe" setup already includes the complete CLIB and RTOS documentation.


**Paradigm users:** The documentation can be accessed from the Paradigm Help menu or by pressing the F1 key when the cursor is over a CLIB function.

**Borland users:** The documentation is copied to a user defined path during the setup. The Windows start menu will contain a link to the documentation index page.

At the @CHIP-RTOS API index page is a link to the CLIB index page.



Each documented CLIB function has an HTML link to the invoked RTOS API software interrupt, which is described in the @CHIP-RTOS HTML documentation.



© 2000-2007 Beck IPC GmbH Page 11 of 11