Digital Intake

Asset code: PUMP-A17.

Printed page 90

Equipment Maintenance

Disconnect power before maintenance.

Do not service while power is on.

Inspect every 30 days.

Equipment	Interval
Pump	Monthly
Valve	Quarterly

Restart after inspection.

Digital Release

Torque setting: 12 Nm.

Printed page 12

Inspection Limits

Temperature must not exceed 60 C.