Equipment Maintenance

Disconnect power before maintenance.

Do not service while power is on.

Inspect every 30 days.

Equipment	Interval
Pump	Monthly
Valve	Quarterly

Restart after inspection.

Inspection Limits

Temperature must not exceed 60 C.