# Installation

## Q: KP occurs on PM981.

A: Currently there's no solution for PM981 on macOS 10.13.3+. You could install macOS on another hard disk.

NOTE: PM981 SSD's model number starts with MZVLB, and PM961 SSD's model number starts with MZVLW.

#### Audio

# Q: Headphones or microphones are not working.

A: If headphones or microphones are not working, please use ALCPlugFix. You may need to replug headphones after every boot. Also, you should avoid hot restart from Windows.

## Bluetooth

## Q: Intel Bluetooth can not connect to many devices.

A: Native Intel Bluetooth has a compatibility issue with Bluetooth 4.x devices below macOS12. You can upgrade to macOS12, or use a USB BT dongle, or solder D+ and D- wires to the WLAN\_LTE slot. See [[Work Around with Bluetooth]].

## Boot

## Q: The screen turns to black and has no response during the updating process.

A: If you have black screen for five minutes and get no response from the device, please force restart your laptop(Long press power button) and choose Boot macOS Install from ~ entry.

## Q: Stuck on Apple logo or fail to boot.

A: A reset of NVRAM is recommended. For Clover users, press Fn+F11 when you are in Clover boot page. For OC users, press Space key when you are in OpenCore boot page and choose Reset NVRAM. If this does not work, you can try to set SecureBootModel to Disabled in config.plist.

## Q: Device is locked by Find My Mac.

A: For Clover users, press Fn+F11 when you are in Clover boot page. Then Clover will refresh nvram.plist, and lock message should be removed.

For OC users, press Esc to enter the boot menu during startup. Then, press Space key and choose Reset NVRAM.

# Q: [Clover] Fail to boot in Windows/Linux by using Clover, but able to boot by pressing F12 and select OS.

A: Many people met this problem by using the new version of AptioMemoryFix.efi. A workaround is to replace /CLOVER/drivers/UEFI/AptioMemoryFix.efi (or OcQuirks.efi, OpenRuntime.efi, and OcQuirks.plist) with an older version.

#### Q: [Clover] FileVault encrypted the macOS partition and the partition does not show up.

A: It is not recommended to enable FileVault. You can press Fn+F3 in the Clover boot page and choose the icon with FileVault. Then you can boot in the system and disable FileVault.

# Q: [OC] Bootpicker does not show icons.

A: Open /EFI/OC/config.plist, and turn off UEFI - Output - ProvideConsoleGop.

## Q: [OC] How to skip the boot menu and automatically boot into the system?

A: First, in macOS, open SysPref - Startup Disk. Choose the target system.

Then, open /EFI/OC/config.plist, and turn off ShowPicker.

When you want to switch OS, press Esc during startup to call the boot menu.

# Q: [OC] How to not make the OpenCore the default bootloader?

A: Open config.plist and change value of LauncherOption from Full to System.

# Q: [OC] How to enable startup chime? (TM1701 & TM1707)

A: Change #AudioDxe.efi to AudioDxe.efi in config.plist - UEFI - Drivers.

Enable AudioSupport in config.plist - UEFI - Audio.

If you are using macOS Big Sur, go to SysPref - Sound and turn on Play sound on startup.

For macOS version < Big Sur, open Terminal.app and run sudo nvram StartupMute=%00.

## Q: [OC] Can't use Boot Camp.

A: Disable CustomSMBIOSGuid in /OC/config.plist - Kernel - Quirks and change PlatformInfo - UpdateSMBIOSMode to Create. You may lose Windows and software's activation.

For Clover users, open /EFI/CLOVER/config.plist and delete DisableDrivers - ExFatDxe.

For OC users, open /EFI/OC/config.plist and change #ExFatDxe.efi to ExFatDxe.efi in UEFI - Drivers.

#### Camera

## Q: My system can't find the camera device.

A: Run sudo kextcache -i / in Terminal.app and then restart.

# Graphics

# Q: Glitches happen when I use Chrome to play video in full screen, but Safari is good.

A: Go to System Preferences - Displays - Color, uncheck Show profiles for this display only, and choose sRGB IEC61966-2.1.

## **HDMI**

## Q: External screen does not respond.

A: You have to re-plug it, or close the lid for about five seconds and reopen the lid.

# Trackpad

# Q: Trackpad is not working.

A: You need to rebuild the kext cache after every system update. Use Kext Utility.app or type sudo kextcache -i / in Terminal.app. Then restart. If this still doesn't work, try to press F9 or warm reboot from Windows.

Also, make sure to uncheck Ignore built-in trackpad when ... in SysPref - Accessibility - Pointer Control

## Q: I can't click to drag or right click using the trackpad.

A: Starts from VoodooI2C v2.4.1, the click down action is emulated to force touch, which causes the failure of click down and drag and right click gestures. You can turn off Force Click in SysPref - Trackpad, and I recommend enabling three finger drag in SysPref - Accessibility - Mouse & Trackpad - Trackpad Options.

# **Keyboard**

## Q: Caps Lock is not working.

A: Add Pinyin - Simplified in SysPref- Keyboard - Input Sources. Then, uncheck Use the Caps Lock key to switch to and from ABC. Finally, delete Pinyin - Simplified and done.

# SSD

## Q: Frequent KPs on some NVMe SSDs.

A: For OC users, they can adjust SetApfsTrimTimeout to set trim timeout. See dortania/bugtracker#192 for more information.

Also, if you see kernel panic messages like NVMe Kernel Panic CSTS=0xffffffff, add forceRenderStandby=0 in config - NVRAM - Add - 7CXXX - boot-args (OpenCore) or config - Boot - Arguments (Clover).

# Wi-Fi

## Q: Wi-Fi is not working.

A: For macOS version below Big Sur, please use Hackintool to rebuild kextcache and restart. If you have a bad network experience, you can turn to use a USB WiFi dongle or insert a supported wireless card into M.2 slot. More information can be viewed in Xiaomi Mi Notebook Pro High Sierra 10.13.6.

## Q: Location Service/AirDrop/Handoff is not working.

A: Location Service/AirDrop/Handoff needs a supported internal wireless card to work(A few USB dongles can use location service, I don't know why). AirDrop and Handoff also need stable Bluetooth connection, see [[Work Around with Bluetooth]].

# Q: New internal wireless card's speed is low after wake.

A: Open SysPref - EnergySaver - PowerAdapter, and uncheck Wake for Wi-Fi network access.

# Other

## Q: Can not receive OEM update.

A: For OC users, on macOS11+, SecureBootModel has to be Default to get OEM update from SysPref. However, some machines can not boot when SecureBootModel = Default. In this case, go to App Store and search Monterey (or newer macOS).