

RENO COMPASS BLUEPRINT PLAN

Dossier ID: reno_s_ea710f5a36fbd4771de4b82bc4d12344

Generated At: 2026-07-07 02:10:15 UTC

Schema Version: 1.0.0

1. Project Summary

Project: Bathroom Remodel (bathroom_remodel)

Goal: removing a partition wall between vanity and bathroom, it is load bearing wall and merging the vanity into bathroom with single door.

Property: Zip 95120, independent house, 50 sqft

Chosen design: preferred (est. \$70,000-\$85,000)

2. Safety & Permit (review this first)

- Removal of Load-Bearing Wall: TIER 1 PROFESSIONAL (source: IRC (International Residential Code))
Requires a licensed professional. Verify with your AHJ.
- Relocation and Installation of New Plumbing Fixtures (Floating Vanity, Wall-Mounted Toilet, Alcove Bathtub/Shower Combo): TIER 2 PERMITTED (source: IRC)
- Installation of New Electrical Lighting (Recessed LEDs, LED Sconces): TIER 2 PERMITTED (source: NEC 210.8(A)(1))
- Waterproofing for Alcove Bathtub/Shower Combo: TIER 3 PROCEED (source: IRC P2705.1 and P2709)
- Installation of a New Exhaust Fan (Inferred as part of a complete remodel): TIER 2 PERMITTED (source: IRC R303.3 and M1507)

Permits are required. Confirm the full scope with your local AHJ.

3. Budget

Target: \$150,000 Ceiling: \$200,000

Ballpark: \$13,950-\$21,700 (+ contingency \$2,162-\$3,364)

Reality check: plausible

All costs are estimated ranges - verify locally with real quotes.

4. Logistics & Displacement

Can live through it: True

Feasibility verdict: proceed

6. Your DIY Plan

- Relocation and Installation of New Plumbing Fixtures (Floating Vanity, Wall-Mounted Toilet, Alcove Bathtub/Shower Combo) (tier 2 permitted)

1. Permit Acquisition & Initial Planning:

ACTION: Apply for and obtain the necessary plumbing permit from the City of San Jose. Ensure you understand the inspection schedule and requirements.

ACTION: Review your chosen "Preferred Minimalist" design plans to confirm the precise locations for the new floating vanity, wall-mounted toilet, and alcove bathtub/shower combo.

ACTION: Turn off the main water supply to your home and drain the existing lines by opening a lower-level faucet.

2. Demolition of Existing Plumbing:

ACTION: Disconnect the water supply and drain lines from your existing vanity, toilet, and tub. Be prepared for some residual water.

ACTION: Carefully remove the existing plumbing fixtures.

ACTION: Cap off or remove old supply and drain lines that will no longer be used according to your new layout.

3. Rough-in Plumbing ? New Supply and Drain Lines:

ACTION: Based on your approved design, mark the new locations for the hot/cold water supply lines, drain lines, and vent lines for the floating vanity, wall-mounted toilet, and alcove tub/shower.

ACTION: Cut and run new water supply lines (PEX or copper) to these marked locations. Ensure the lines are properly secured within the wall or floor cavities.

ACTION: Install the drain and vent lines according to code, ensuring proper slope for drainage.

ACTION: Install the tub/shower valve (with anti-scald protection) and the tub spout/showerhead rough-in.

ACTION: For the wall-mounted toilet, install the in-wall carrier system according to manufacturer instructions, ensuring it is securely fastened to the framing and at the correct height.

ACTION: For the floating vanity, ensure adequate blocking or reinforcement is installed in the wall where it will be mounted.

4. Bathtub Installation (after rough-in inspection and before final wall/floor coverings):

ACTION: Install the alcove bathtub, ensuring it is level and securely fastened to the wall studs.

ACTION: Connect the tub drain and overflow to the rough-in plumbing. Test the tub for leaks by filling it partially with water.

5. Waterproofing and Wall/Floor Coverings (after bathtub installation and rough-in inspection):

ACTION: Apply the necessary waterproofing membrane to the tub/shower surround area as required by code (this is a Tier-3 DIY task, but integral to the overall plumbing system).

ACTION: Install wall coverings (e.g., drywall) and flooring, leaving access for final fixture connections.

6. Final Fixture Installation (after walls and flooring are complete):

ACTION: Install the floating vanity cabinet, securing it to the wall blocking.

ACTION: Install the quartz countertop and sink onto the vanity.

ACTION: Install the wall-mounted toilet bowl onto its carrier, making all necessary connections.

ACTION: Install the faucets for the vanity and tub, and the showerhead and tub spout.

ACTION: Connect the water supply lines to the vanity faucet and toilet.

ACTION: Connect the drain lines from the vanity sink and toilet.

ACTION: Turn the main water supply back on slowly and carefully inspect all new connections for leaks.

7. Final Inspection:

Once all fixtures are installed and functional, schedule your final plumbing inspection with your AHJ. They will ensure everything is installed correctly and meets code.

Hold point: ROUGH-IN PLUMBING INSPECTION

Hold point: FINAL PLUMBING INSPECTION

Tool: Adjustable Wrenches / Pipe Wrenches - For disconnecting and connecting water supply lines and drain fittings.

Tool: Pliers (e.g., Channel Locks) - Useful for various plumbing connections.

Tool: Tubing Cutter (for PEX or Copper) - To cut new water supply lines if you're using PEX or copper.

Tool: PEX Crimp Tool / Compression Fitting Wrench - Depending on your chosen plumbing connection method.

Tool: Drill/Driver - For mounting vanity cabinets, wall-mounted toilet carrier, and securing tub.

Tool: Level - Essential for ensuring fixtures are installed correctly and plumb.

Tool: Measuring Tape - For accurate placement and pipe lengths.

Tool: Caulk Gun & Silicone Caulk (Kitchen & Bath rated) - For sealing around the tub and vanity.

Tool: Teflon Tape / Pipe Dope - To create watertight seals on threaded pipe connections.

Tool: Buckets and Rags - For catching residual water when disconnecting old fixtures and cleaning up spills.

Tool: Utility Knife - For cutting waterproofing membranes or other materials.

Tool: Hacksaw (optional) - If you encounter old metal pipes that need cutting.

Tool: Safety Glasses and Gloves - For personal protection.

Tool: Shims - For leveling the bathtub or vanity if the floor is uneven.

Tool: Flashlight/Headlamp - For working in dimly lit areas.

6b. Add to Your Contractor's Scope

Eligible work you chose to hand to a professional:

- Installation of New Electrical Lighting (Recessed LEDs, LED Sconces) (tier 2 permitted)
- Waterproofing for Alcove Bathtub/Shower Combo (tier 3 proceed)
- Installation of a New Exhaust Fan (Inferred as part of a complete remodel) (tier 2 permitted)

7. Advisory Checklist

- Insist on an Itemized Bid
- Get Multiple Bids
- Verify Credentials
- Confirm "Invisible" Inclusions
- Payment Schedule
- Hold Final Payment

8. Phase Checklists

Before demolition:

- Order long-lead materials first.
- Confirm permits filed.

After demolition:

- Inspect for hidden conditions before closing walls.

While in progress:

- Keep waterproofing before tile.
- Hit inspection milestones.

Wrap-up:

- Final inspection sign-off before final payment.