

RENO COMPASS BLUEPRINT PLAN

Dossier ID: reno_s_d004d71257f598257d575076195a0a29

Generated At: 2026-07-07 04:58:44 UTC

Schema Version: 1.0.0

1. Project Summary

Project: Bathroom refresh (bathroom remodel)

Goal: Moving a partition wall between vanity and toilet and merging vanity into bathroom. Currently the vanity is outside and next to it there is a entry door to the bathroom, first toilet in bathroom and tub, this wall is a load bearing wall. The goal is to move this load bearing wall to the beginning after this change the load bearing wall and door will be first and vanity, followed by toilet and followed by tub. The only change is relocating load bearing wall and installing porcelain floor tiles in the bath room and changing light fixture. No other change we will not touch plumbing or electrical, no need to remove the vanity or moving. New load bearing wall go up and old load bearing wall will go down and flooring installed.

Property: Zip 95120, independent house, 50 sqft

Chosen design: preferred (est. \$21,700-\$28,000)

2. Safety & Permit (review this first)

- Relocating the load-bearing wall: TIER 1 PROFESSIONAL (source: IRC R502.2)
Requires a licensed professional. Verify with your AHJ.
- Relocating the vanity (and its plumbing): TIER 2 PERMITTED (source: IRC P2603.1)
- Relocating the toilet (and its plumbing): TIER 2 PERMITTED (source: IRC P2603.1)
- Relocating the tub (and its plumbing): TIER 2 PERMITTED (source: IRC P2603.1)
- Installing new porcelain floor tiles: TIER 3 PROCEED (source: Cosmetic finish work)
- Changing the light fixture: TIER 3 PROCEED (source: Cosmetic electrical work)

Permits are required. Confirm the full scope with your local AHJ.

3. Budget

Target: \$17,500 Ceiling: \$20,000

Ballpark: \$13,950-\$21,700 (+ contingency \$2,162-\$3,364)

Reality check: plausible

All costs are estimated ranges - verify locally with real quotes.

4. Logistics & Displacement

Can live through it: True

Feasibility verdict: proceed_with_budget_gap

6. Your DIY Plan

- Relocating the vanity (and its plumbing) (tier 2 permitted)
 1. Obtain Plumbing Permit: Before starting any work, you must obtain the necessary plumbing permit from your local building department for the relocation of plumbing supply and drain lines. This is a regulated activity.
 2. Structural Work Completion (HOLD POINT - Professional Required): Crucially, wait for your licensed structural professional to complete all work related to relocating the load-bearing wall, including the installation of any new structural beams and final structural inspections. Your vanity installation cannot proceed until this critical Tier 1 structural work is safely completed and approved.
 3. Turn Off Water Supply: Locate and shut off the main water supply to your bathroom or the entire house. Open nearby faucets to relieve pressure and drain any remaining water from the lines.

4. Disconnect and Remove Old Vanity (if applicable) / Prepare Area: If there is an existing vanity at the new location, disconnect its plumbing (supply lines and drain) and carefully remove it. Thoroughly clear and clean the area where your new vanity will be installed.
5. Demolition for Plumbing Reroute: Based on the new vanity's placement, you will likely need to open sections of the wall (drywall or plaster) to run new hot and cold water supply lines and a new drain line to the correct height and spacing for your new vanity.
6. Install New Rough-in Plumbing: Run new water supply lines and a new drain line to the exact location where your new vanity's faucet and sink drain will connect. Ensure all piping is securely fastened within the wall cavity and capped or plugged appropriately.
7. Rough-in Plumbing Inspection (Permit Hold Point): Before you close up any walls, schedule and pass the rough-in plumbing inspection with your local Authority Having Jurisdiction (AHJ). Do NOT proceed to the next step until this inspection is passed.
8. Repair Walls: Once your rough-in plumbing inspection has passed, patch and repair any opened sections of the walls, ensuring they are smooth and ready for finishes.
9. Install New Vanity: Position your new vanity cabinet in its designated spot. Use a level to ensure it is perfectly plumb and level, using shims if necessary. Secure the vanity cabinet to the wall studs using screws. Install the countertop and sink if they are separate components.
10. Connect Final Plumbing: Connect the new vanity faucet to the hot and cold supply lines. Connect the sink drain to the P-trap, and then connect the P-trap to the newly installed wall drain pipe. Ensure all connections are tight and use PTFE tape on threaded connections where appropriate.
11. Final Plumbing Inspection (Permit Hold Point): Schedule and pass the final plumbing inspection with your local Authority Having Jurisdiction (AHJ) BEFORE using the new vanity regularly.
12. Restore Water Supply and Check for Leaks: Slowly turn the main water supply back on and carefully inspect all new plumbing connections (under the sink, at the faucet, and behind the wall if accessible) for any signs of leaks.
13. Finish Work: Apply a bead of silicone caulk around the base of the sink, the backsplash (if applicable), and any seams between the vanity and the wall to seal against moisture.

Tool: Adjustable wrenches - various sizes

Tool: Basin wrench - for tightening faucet nuts in tight spaces

Tool: Pipe cutters - if you're cutting new PEX or copper lines

Tool: PTFE tape (Teflon tape) - or pipe thread sealant

Tool: Bucket and rags - for catching water

Tool: Drill/driver - with appropriate bits

Tool: Level - long and short

Tool: Measuring tape - None

Tool: Stud finder - None

Tool: Shims - for leveling the vanity

Tool: Caulk gun and silicone caulk - kitchen/bath grade

Tool: Utility knife - None

Tool: Pencil - None

Tool: Drywall saw or utility knife - None

Tool: Joint compound (spackle) - None

Tool: Taping knife or putty knife - None

Tool: Sandpaper - medium and fine grit

Tool: Safety glasses - None

Tool: Work gloves - None

6b. Add to Your Contractor's Scope

Eligible work you chose to hand to a professional:

- Relocating the toilet (and its plumbing) (tier 2 permitted)
- Relocating the tub (and its plumbing) (tier 2 permitted)
- Installing new porcelain floor tiles (tier 3 proceed)
- Changing the light fixture (tier 3 proceed)

7. Advisory Checklist

- Insist on an itemized bid
- Get multiple bids
- Verify licenses and insurance
- Confirm "invisible" inclusions
- Payment schedule tied to milestones
- Understand warranty terms
- Plan for changes

8. Phase Checklists

Before demolition:

- Order long-lead materials first.
- Confirm permits filed.

After demolition:

- Inspect for hidden conditions before closing walls.

While in progress:

- Keep waterproofing before tile.
- Hit inspection milestones.

Wrap-up:

- Final inspection sign-off before final payment.

9. Budget Gap - Your On-Ramp

Gap to bridge: \$0. This is a plan on-ramp, not a dead end.

- Phase the work over time as budget allows.
- Self-perform eligible non-professional items to reduce labor.
- Shift finishes toward economy bands without changing the layout.