Lumen Ridge T3 Smart Thermostat

User Manual · Model LR-T3 · Firmware 2.4

Getting started

The T3 works with most 24 V heating and cooling systems. It is not compatible with 120 V or 240 V line-voltage systems such as electric baseboard heaters.

Before installation, switch off power to your heating system at the breaker. Installation typically takes 30 minutes.

Connecting to Wi-Fi

The T3 supports 2.4 GHz Wi-Fi networks only; 5 GHz networks are not supported. Open the Lumen Ridge app, tap Add device, and follow the on-screen steps. The display shows a cloud icon when the thermostat is online.

Schedules and eco mode

You can create up to 6 temperature periods per day in the app. Eco mode lowers the setpoint by 3 °C when everyone has left home, using your phone's location.

Holiday mode holds a fixed temperature of 12 °C until the return date you choose, to protect pipes from freezing.

Battery and power

If your system has no common (C) wire, the T3 runs on two AA batteries, which last about 12 months. A battery icon appears when less than 10% remains.

Error codes

- E1: Temperature sensor fault. Restart the thermostat; if the error persists, contact support.
- E2: No power from the heating system. Check the breaker and the R wire connection.
- E3: Wi-Fi connection lost for more than 1 hour. Check your router and that the network is 2.4 GHz.
- E4: Heating did not reach the setpoint within 2 hours. Check that your boiler is working.

Factory reset

To restore factory settings, press and hold the dial for 10 seconds until the display shows RESET, then confirm by pressing the dial once. All schedules and Wi-Fi settings will be erased.

Warranty

The T3 has a limited warranty of 2 years from the date of purchase, covering defects in materials and workmanship. The warranty does not cover damage caused by incorrect installation or by connecting the T3 to a line-voltage system.

To make a claim, contact support@lumenridge.example with your proof of purchase and the serial number shown in Settings > About.