

1. Overview

TerraDry D200 Industrial Dehumidifier - User Manual (Model D200, Revision 2026-A).

The TerraDry D200 is a single-phase, floor-standing industrial dehumidifier intended for small to mid-sized enclosed spaces such as workshops, archives, and equipment rooms. It uses a rotary compressor with R-290 refrigerant and a washable pre-filter.

This manual covers setup, operating limits, and safety exceptions for the D200. For the larger three-phase D400 model, see its separate manual.

2. Setup Steps

1. Place the unit on a level, hard floor with at least 30 cm of clearance on all sides.
2. Connect the unit to a grounded single-phase 220-240V, 10A outlet. Do not use an extension cord longer than 3 meters.
3. Attach the supplied 12mm condensate drain hose to the rear drain port for continuous drainage, or leave the internal tank installed for manual emptying.
4. Press and hold the POWER button for 2 seconds to power on.
5. Select the target humidity (30 percent to 80 percent RH) using the dial and press START.

The unit will begin dehumidifying within approximately 90 seconds.

3. Specifications and Limits

Maximum coverage area: 45 square meters (484 sq ft) at 2.5m ceiling height.

Water removal capacity: up to 20 liters per day at 30C, 80 percent RH.

Internal tank capacity: 10 liters.

Operating temperature range: 5C to 38C.

Operating humidity range: 30 percent to 90 percent RH.

Sound level: 52 dB(A) at 1 meter.

Power consumption: 480W nominal.

4. Exceptions and Safety

Low-Temperature Operation Exception: The D200 must not be operated in ambient temperatures below 5C under standard configuration, as this may cause the evaporator coil to frost and the compressor to stall.

Exception: if the optional Low-Temperature Defrost Kit (LTK-1) is installed by a certified technician, the D200 may be operated down to -5C ambient temperature. The LTK-1 kit adds an automatic hot-gas defrost cycle every 45 minutes.

Do not operate the unit outdoors or in direct rain.