

CoppeliaSim 다운로드 및 설치 가이드







다운로드

https://www.coppeliarobotics.com/







[Connectivity >> WebSocket remote API server@addOnScript:info] WebSocket Remote API server starting (port=23050)... [Connectivity >> ZMQ remote API server@addOnScript:info] ZeroMQ Remote API server starting (rpcPort=23000)...

RemoteAPI 확인

```
from coppeliasim_zmqremoteapi_client import RemoteAPIClient

client = RemoteAPIClient()
sim = client.require('sim')

print('Connected to CoppeliaSim.')
```

Connected to CoppeliaSim.

RemoteAPI 확인

• 설치되지 않았을 때

```
Traceback (most recent call last):
File "c:\개인\01. 강의자료\패스트캠퍼스\강의자료\Source\CoppeliaSim\copptest.py", line 1, in <module>
from coppeliasim_zmqremoteapi_client import RemoteAPIClient
ModuleNotFoundError: No module named 'coppeliasim_zmqremoteapi_client'
```

Zmqremoteapi 설치

```
pip install coppeliasim-zmqremoteapi-client
```

• 연결 테스트

```
from coppeliasim_zmqremoteapi_client import RemoteAPIClient

client = RemoteAPIClient()
sim = client.require('sim')

print('Connected to CoppeliaSim.')
```

Connected to CoppeliaSim.

