## **UVF11 Installation Instruction**

Sediments and particles in the water block UV light and serve as shelters for germs. Thus water coming into the UV sanitizer must be clear (free of particles larger than 20 microns). It is recommended that you install the UV sanitizer after the filters as the last stage.

iSpring UVF11 comes with a Smart Flow Sensor Switch. It is directional. It must be connected in the designated direction to ensure that water flow matches the arrow mark on it.

UVF11 has 2 ports. Either one can be IN or OUT as long as water flow matches the arrow sign on the Flow Sensor.

Please cut the tubing in an appropriate length to avoid kinking. Please make sure the tubing is fully inserted into the quick-fitting about half-inch deep for it to be sealed by the O-ring at the bottom.

Using the 2 plastic clips provided, mount the UV sanitizer on one of the stages on the filter. Do so by clamping the 2 plastic clips onto the stage housing, set the clips about 5 inches apart, then snap the stainless steel UV housing into the clips.

Connect the UV transformer to an electric outlet.

Turn on water supply and faucet. Observe for any leaks and check if water flow activates the UV light.

