
Part 1

CHAPTER 1

Computer Systems Architecture



Alan Clements

These slides are being provided with permission from the copyright for in-class (CS2208B) use only. The slides must not be reproduced or provided to anyone outside of the class.

All download copies of the slides and/or lecture recordings are for personal use only. Students must destroy these copies within 30 days after receipt of final course evaluations.



Music: "Corporate Success" by Scott Holmes, used under <u>Attribution-NonCommercial License</u>

Structure of the Book (5 Parts)

Part I The Beginning

introduces the concepts, history and underlying technology of digital computers.

- 1. Computer Systems Architecture
- 2. Computer Arithmetic and Digital Logic

Part II Instruction Set Architectures (ISAs)

looks at the <u>programming model</u> of a computer and introduces the <u>register model</u> of a computer, its <u>instruction types</u>, and the <u>addressing modes</u> of a typical microprocessor.

- 3. Architecture and Organization
- 4. Instruction Set Architectures Breadth and Depth
- 5. Computer Architecture and Multimedia

Part III Organization and Efficiency

describes how we measure the performance of computers.

- 6. Performance Meaning and Metrics
- 7. Processor Control
- 8. Beyond RISC: Superscalar, VLIW, and Itanium

Structure of the Book

Part IV The System

covers the other parts of a computer required to <u>convert the microprocessor chip</u> <u>into a complete system</u>; for example, <u>peripheral subsystems</u> and the wide range of <u>memory systems</u>, <u>storage devices</u>, and <u>buses</u> available to the computer systems' designer.

- 9. Cache Memory and Virtual Memory
- 10. Main Memory
- 11. Secondary Storage
- 12. Input/output

Part V Processor-Level Parallelism

goes beyond the single-processor computer and introduces the notion of *computers with multiple processors*.

13. Processor-Level Parallelism

Computer Architecture

- \square A computer is characterized by its *instruction set architecture* (*ISA*)
- ☐ An *ISA* is an *abstract entity* because it does not consider the specific design or implementation of a computer
- ☐ An *ISA* is concerned with the computer's *register set*, *instruction set*, and *addressing modes*
- ☐ An *ISA* defines the model of a computer from the programmer viewpoint
- ☐ The computer's assembly language embodies its *ISA*

Computer Organization


- ☐ Computer *organization* is concerned with the implementation of an ISA
- ☐ Any given ISA can have many different organizations
 - Examples

Should be "**organization**", not "**architecture**", as in the original slide.

- ☐ Computer manufacturers regularly *modify the organization* of a processor while *keeping its ISA essentially constant*
- ☐ Today, a computer's organization is often referred to as its *microarchitecture*
- ☐ In **theory**, *architecture* and *organization* are orthogonal; that is, they are entirely independent
- ☐ You could say that
 - architecture tells you what a computer does and
 - *organization* tells you *how* it does it

Computer Structure

- ☐ Figure 1.1 describes the structure of a computer.
- ☐ The term computer describes the entire system.
- ☐ The CPU is the Central Processing Unit that reads instructions and executes them.
- ☐ The CPU is often synonymous with microprocessor.
- ☐ Modern microprocessors usually include cache (high-speed) memory on-chip.
- A key component of computers is the bus (or family of busses) that moves information around the computer between different functional units (data highway).




This slide is modified from the original slide by the author A. Clements and used with permission. New content added and copyrighted by © Mahmoud R. El-Sakka.

Processor Register

- A processor register is a memory element that holds a single unit data (a word of data).
- A processor register is specified in terms of the number of bits it holds, which is typically, 8, 16, 32, or 64.
 - o Currently, most of computers either have 32-bit or 64-bit-wide registers.
- ☐ Each processor has a specified number or registers.
- ☐ There is no fundamental difference between
 - o a register and
 - o a word in memory.
- ☐ The practical difference is that registers are located within the CPU
 - o can be accessed more rapidly than other memories.

Computer Types


- ☐ Computers are either dedicated or general-purpose.
 - o A dedicated computer solves only one class of problems (e.g., a computer in a calculator, a cruise speed control, or washing machine).
 - A general-purpose computer can be programmed to solve any problem.
- ☐ Figure 1.2 describes the structure of a general-purpose computer.
- A key feature of the general-purpose computer is that *the program* and *its data* are held in the same memory.
- ☐ Such a computer is called a **von Neumann machine**.



8

Stored Program Computer

- ☐ Figure 1.3 emphasizes the nature of the stored program computer.
 - The CPU reads instructions from memory and then
 - o carries out operations on input data and data in memory
 - O Data and instructions co-exist in the same memory system




and data in memory.

9

Stored Program Computer

- Figure 1.4 illustrates the operation of a stored program, where the operation Z = X + Y is read from memory, interpreted and used to add X and Y to create Z.
- ☐ A clock (a stream of pulses) sequences all operations in a computer.
- ☐ All events in a computer are triggered by clock pulses.




10

Stored Program Computer

- ☐ LOAD moves data from memory to a register and
- ☐ STORE moves data from a register to memory.
- \square Z = X + Y performs a simple operation on data (addition).
- ☐ Memory is a bottleneck because
 - o instructions have to flow from it.
 - Data has to flow from it to take part in operations and
 - Data has to flow back to store the result.

How many memory access do we need to execute this program?



This slide is modified from the original slide by the author A. Clements and used with permission. New content added and copyrighted by © Mahmoud R. El-Sakka.

The Clock

- ☐ Most digital electronic circuits have a clock that generates a continuous stream of regularly spaced electrical pulses.
- ☐ It's called a clock because the pulses are used to time or sequence all events within the computer; for example, a processor might start executing a new instruction each time a clock pulse arrives.
- ☐ A clock is defined in terms of its *repetition rate* i.e., *frequency*.
- ☐ Typical clock frequencies in computers range from 1 MHz to about 4.5 GHz.
- \square Clocks are also defined in terms of the width of a clock pulse, which is the reciprocal of its frequency; that is f = 1/T;
 - for example a 1 MHz clock has a duration of 1 µs (i.e., 10-6s), and a 1 GHz clock has a duration of 1 ns (i.e., 10-9s).
- \square A 5 GHz clock has a period of 0.2 ns or simply 200 ps (picoseconds)—1 ps = 10⁻¹² s
- \square To feel how a ps is small, light travels approximately 6 cm in 200 ps.