
Computer Organization and Architecture: Themes and Varia

Part 1

CHAPTER 4

Computer
Organization
and
Architecture



Alan Clements

These slides are being provided with permission from the copyright for in-class (CS2208B) use only. The slides must not be reproduced or provided to anyone outside of the class.

All download copies of the slides and/or lecture recordings are for personal use only. Students must destroy these copies within 30 days after receipt of final course evaluations.

CENGAGE Learning

Music: "Corporate Success" by Scott Holmes, used under <u>Attribution-NonCommercial License</u>

ISAs Breadth and Depth

- ☐ This chapter extends the overview of ISAs in both breadth and depth.
 - Yet, we will only cover the depth part in lectures this term
- ☐ In particular, we will look at the role of the stack and architectural support for subroutines and parameter passing.

- ☐ Let's begin by looking at some background issues concerning *data storage*, *procedures*, and *parameter passing*.
- □ Computer programs and subroutines consist of
 - data elements and
 - procedures which operate on these data elements
- ☐ High-level language programmers use variables to represent *data elements*
- □ Variables are declared by:
 - <u>assigning names</u> to them and by <u>reserving storage</u> for them.
- □ *Reserving* memory storage for variables can be performed
 - at compilation time (static memory allocation)
 - at runtime (dynamic memory allocation)
- □ Statically allocated variables will have <u>static addresses</u> which will <u>not be</u> <u>changed during execution</u>
- □ Dynamically allocated variables will have dynamic addresses which will be changed during execution, as they will be allocated at runtime

- ☐ Procedures often require *local workspace* for their <u>temporary</u> variables.
- ☐ The term *local* means that the workspace is private to the procedure and is never accessed by the calling program or by other subroutines.
- ☐ If a procedure is to be made re-entrant or to be used recursively, its local variables must be bounded up not only with the procedure itself, <u>but with</u> the occasion <u>of</u> its use.

create total varieble for all values.

■ Each time the procedure is called, a new workspace must be assigned to it.

- \square A variable has a *scope* associated with it.
 - The scope of a variable defines the range of its <u>visibility</u> or <u>accessibility</u> within a program.
 - o *Global* variables are <u>visible</u> (accessible) from the moment they are loaded into memory to the moment when the program stops running (static memory allocation)
 - Local variables and parameters are visible (accessible) within that procedure but invisible (inaccessible) outside the procedure (dynamic memory allocation)
- ☐ Here, we are interested to learn more about *dynamic memory allocation*

☐ Figure 4.1 illustrates the scope of variables

The <u>duration</u> of local variables and parameters are "automatically"

- allocated when the enclosing function is called and
- deallocated when the function returns

FIGURE 4.1 The concept of scope

The int x, y, z; should be outside any function to be global not as mentioned in page 231.

int X,Y,Z; ← Variables X, Y, and Z can be accessed by lower level modules.

function1(Q)
int Z;

Variable Z has been redefined in this module.

Variables X and Y in the calling program can be accessed in this module.


function2 (R)
int Y, Z;

Variables Y and Z have been redefined in this module.
Global variable X can be accessed in this module.

Storage and the Stack

- ☐ When a language invokes a procedure, it is said to *activate* the procedure.
- Associated with each invocation (activation) of a procedure, there is an *activation record* containing all the information necessary to execute the procedure, including
 - parameters,
 - local variables, and
 - return address,

Storage and the Stack



Storage and the Stack

- ☐ The activation record described by Figure 4.2 is known as a *frame*.
- After an activation record has been used, executing a *return from procedure deallocates* or frees the storage taken up by the record.
 - y the recorα.

 Who should perform this *freeing* process? RISC versus CISC programmer with the core.
- □ Coming next, we will look at how frames are created and managed at the machine level and demonstrate how two pointer registers are used to efficiently implement the activation record creation and deallocation.

Stack Pointer and Frame Pointer

- ☐ The stack provides a mechanism for implementing the dynamic memory allocation.
- ☐ The stack-frame is a region of temporary storage
 - At the beginning of the subroutine, it will be pushed onto the stack.
 - At the end of the subroutine, it will be popped from the stack.
- ☐ The two pointers associated with stack frames are
 - o the Stack Pointer, SP (r13), and
 - o the Frame Pointer, FP (r11).
 - rium LR processor.
- ☐ A CISC processor maintain a hardware SP that is automatically adjusted when a BSR or RTS is executed.
 - DICC Library 1:1- ADM James 1-1-
- □ RISC processors, like ARM, do not have an explicit SP, although **r13** is used as the *ARM's programmer-maintained stack pointer* by convention.
- \square By convention, **r11** is used as a *frame pointer* in ARM environments.


- ☐ The stack pointer always points to the top of the stack.
- \Box The frame pointer always points to the base of the <u>current</u> stack frame.
- ☐ The stack pointer may change during the execution of the procedure, but the frame pointer will not change.
- □ While the data in the stack frame might be accessed with respect to the stack pointer, it is *strongly recommended* to access the data in the stack frame via the stack frame.

12

The Stack Frame and Local Variables

- Assume that the stack that we use grows up towards low addresses and that the stack pointer is always pointing at the item currently at the top of the stack (i.e., FD).

 You need to re-do it yourself using the other stack types.
- \Box Figure 4.3 demonstrates how a *d*-byte stack-frame is created by
 - o moving the stack pointer up by d locations at the start of a subroutine.



This slide is modified from the original slide by the author A. Clements and used with permission. New content added and copyrighted by © Mahmoud R. El-Sakka.

moving the stack pointer up d bytes.

processors locate the return

address at the top of the stack.

☐ Because the FD stack grows towards the low end of memory, the stack pointer is decremented to create a stack frame

You need to re-do it yourself using the other stack types.

☐ Reserving 16 bytes of memory is achieved by

SUB r13, r13, #16 ; move the stack pointer up 16 bytes

☐ Before a return from subroutine is made, the stack-frame is collapsed by restoring the stack pointer with

ADD r13,r13,#16

☐ In general, operations on the stack are <u>balanced</u>; that is, if you put something onto the stack you have to remove it.

□ Consider the following simple example of a subroutine, where it is called using BL.

```
Proc SUB r13, r13, #16 ; move the stack pointer up 16 bytes

Code ; some code

STR r1, [r13, #8] ; store something in the frame 8 bytes
; below TOS

Code ; some more code


ADD r13, r13, #16 ; collapse stack frame
MOV pc, r14 ; restore the PC to return

Bold is not convect in page 235
```

In this example, FP, i.e., R11, is not used.

The problem here is that if anything is pushed onto the stack, you have to manually recalculate the position of the stack frame relative to the SP.

- ☐ In Figure 4.4a variable XYZ is 12 bytes below the stack pointer o we access XYZ via address [r13,#12].
- ☐ Because the stack pointer is free to move as other information is added to the stack, it is better to construct a stack frame with a pointer independent of the stack pointer.




Variable XYZ is at SP + 12, twelve bytes below the top of the stack.

(a) Accessing a variable via the stack pointer

make priver point as the base of the

- ☐ Figure 4.4b illustrates a stack frame with a *frame pointer*, FP, that points to the bottom of the stack frame and is independent of the stack pointer.
- ☐ The XYZ variable can be accessed via the frame pointer at [r11,#-8], assuming that r11 is the frame pointer.



- \square In CISC architecture, a *link* instruction creates a stack frame and an *unlink* instruction collapses it.
- □ ARM lacks such link and unlink instructions
- ☐ To create a stack frame you could
 - push the old *frame pointer* onto the stack (*to save its value*)
 - Make the frame pointer to point to the bottom of the stack frame
 - move up the *stack pointer* by *d* bytes (*to create a local workplace*)

```
SUB sp, sp, #4; move the stack pointer up by a 32-bit word; push the frame pointer onto the stack MOV fp, sp; move the stack pointer to the frame pointer SUB sp, sp, #8; move stack pointer up 8 bytes; (d is equal to 8)

The frame pointer, fp, points at the base of the frame and can be used to access local variables in the frame.
```


- ☐ By convention, register **r11** is used as the *frame pointer*.
- At the end of the subroutine, the stack frame is collapsed by:

```
MOV sp, fp ; restore the stack pointer

LDR fp,[sp] ; restore old frame pointer from the stack


ADD sp,sp,#4; move stack pointer down 4 bytes to
```

- ☐ Figure 4.5 demonstrates how the stack frame grows.
- □ Note that, the FP appears *twice*;
 - as the old/previous stack frame onto the stack and
 - as the current stack frame pointing to the base of the stack frame.



This slide is modified from the original slide by the author A. Clements and used with permission. New content added and copyrighted by @ Mahmoud R. El-Sakka.

☐ The figure below demonstrates how the stack frame collapses.



☐ The following demonstrates how you might set up your program.



call a subroutine,

save at least the frame pointer and link register,

set the frame pointer and create local variables inside the stack

perform the subroutine code

clean the stack from the created local variables

restore saved registers

return to the calling point.

pop the parameter from the stack

subroutine

```
AREA TestProg, CODE, READONLY

ENTRY ; This is the calling environment.

; subroutine code is on the next slide.
```

```
Main ADR sp, Stack ; set up r13 as the stack pointer MOV r0, #124 ; set up a dummy parameter in r0 MOV fp, #123 ; set up dummy frame pointer STR r0, [sp, #-4]! ; push the parameter gall the subroutine LDR r1, [sp] ; pop the parameter ; wait here (endless loop)
```

Missing the post update value in page 237


Bold is not correct in page 237

```
STMFD sp!, {fp, lr} ; push frame-pointer and link-register
Sub
     VOM
            fp, sp
                            ; frame pointer at the bottom of
                            ; the frame
            sp, sp, #4
                            ; create the stack frame (one word)
     SUB
           r2, [fp, #8] ; get the pushed parameter
     LDR
                            ; do a dummy operation on
     ADD
            r2, r2, #120
                            ; the parameter
     STR
            r2,[fp,#-4]
                            ; store it in the stack frame
            sp, sp, #4
     ADD
                            ; clean up the stack frame
     LDMFD sp!, {fp,pc} ;restore frame pointer and return
                            ; clear memory
      DCD
              0 \times 0 \times 0 \times 0
              0 \times 0 0 0 0
      DCD
                                   Bold is not correct in page 238
      DCD
              0 \times 0 0 0 0
      DCD
              0 \times 0 0 0 0
              0x0000
Stack DCD
                            ; start of the stack
```


END


R2 has been changed inside the subroutine. Hence, it should be saved at the beginning of the. subroutine and restored at the end.

□ Figure 4.6 demonstrates the behavior of the stack during the code's execution. Figure 4.6a depicts the stack's initial state. In Figure 4.6b the parameter has been pushed onto the stack. In Figure 4.6c the frame pointer and link register have been stacked by STMFD sp!, {fp,lr}.




☐ In Figure 4.6d a 4-byte word has been created at the top of the stack. Finally, Figure 4.6e demonstrates how the pushed parameter is accessed and moved to the new stack frame using register indirect addressing with the frame pointer.





(d) State of stack after creating 4-byte space on the stack



(e) State of stack after the sequence LDR r2, [fp,#8] ;get parameter

ADD r2, r2, #120 ; add 120

STR r2,[fp,#-4] ;store sum in stack frame

ahmoud R. El-Sakka.