CS3350B Computer Organization Chapter 2: Synchronous Circuits Prelude

Iqra Batool

Department of Computer Science University of Western Ontario, Canada

Monday Janaury 29, 2024

Outline

1 Everything on a Computer is a Number

Radix Representations

Radix is the base number in some numbering system. In a radix r representation digits (d_i) are from the set $\{0, 1, \ldots, r-1\}$

$$x = d_{n-1} \times r^{n-1} + d_{n-2} \times r^{n-2} + \dots + d_1 \times r^1 + d_0 \times r^0$$

- $r = 10 \implies \text{decimal}, \{0, 1, 2, 3, 4, 5, 6, 7, 8, 9\}$
- $ightharpoonup r = 2 \implies \text{binary, } \{0,1\}$
- $r = 8 \implies \text{octal}, \{0, 1, 2, 3, 4, 5, 6, 7\}$
- $r = 16 \implies \text{hexadecimal}, \{0, 1, 2, 3, 4, 5, 6, 7, 8, 9, a, b, c, d, e, f\}$

Refresh: Decimal to Binary

$$(13)_{10} = (1 \times 10^1) + (3 \times 10^0)$$

$$(1101)_2 = (1 \times 2^3) + (1 \times 2^2) + (0 \times 2^1) + (1 \times 2^0) = 8 + 4 + 0 + 1 = (13)_{10}$$

Unsigned Binary Integers

Unsigned Integers ⇒ the normal representation

An *n*-bit number:

$$x = x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- \blacksquare Has a factor up to 2^{n-1} .
- Has a range: 0 to $(2^n 1)$
- Example

$$\begin{array}{ll} 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 1011_2 \\ =\ 0+\cdots+1\times 2^3+0\times 2^2+1\times 2^1+1\times 2^0 \\ =\ 0+\cdots+8+0+2+1=11_{10} \end{array}$$

■ Using 32 bits: 0 to +4,294,967,295



Signed Binary Integers (1/2)

How to encode a negative sign?

One's Complement: Invert unsigned representation to get negative.

- Get value by inverting all bits then multiply by -1.
- Leading bit decides if negative or not.
- All positive numbers have the same representation as unsigned.

In one's compliment:

$$(0101)_2 = (0101)_2 = 5$$

$$(1101)_2 = -1 \times (0010)_2 = -2$$

$$(0000)_2 = (0000)_2 = 0$$

$$(1111)_2 = -1 \times (0000)_2 = -0 ????$$

One's compliment is rarely used:

- Signed zero.
- Weird borrowing required in arithmetic.

Signed Binary Integers (2/2)

How to encode a negative sign?

Two's Complement: Invert all the bits with respect to 2^n

- Same as treating leading bit as negative in expansion.
- Leading bit decides if negative or not.
- All positive numbers have the same representation as unsigned.

In two's compliment:

$$(0101)_2 = (0101)_2 = 5$$

$$(1101)_2 = -1 \times 2^3 + (0101)_2 = -8 + 5 = -3$$

$$(0000)_2 = (0000)_2 = 0$$

$$(1111)_2 = -1 \times 2^3 + (0111)_2 = -1$$

Two's Complement

Advantages:

■ Arithmetic is the same whether positive or negative:

$$\frac{(0101)_2 = 5}{+ (1101)_2 = -3}$$

$$\frac{(0010)_2 = 2}{-3}$$
 (Throw away carry bit)

- No signed 0.
- One extra value represented with same number of bits.

For an n-bit number:

■ Range of values is -2^{n-1} to $2^{n-1} - 1$

Same Bits Different Numbers

It is important to realize that the same bit pattern can represent different numbers.

$$(1001\ 1010)_2 \Longrightarrow (154)_{10}$$
 interpretted as unsigned $\Longrightarrow (-102)_{10}$ interpretted as two's compliment

Can be disastrous in programming!

```
unsigned int a = (1 << 31); // a = 2147483648 int b = a; // b = -2147483648
```

Signed Negation

In two's complement, bit-wise complement then add 1.

$$6 = (0110)_2 = (0 \times 2^3) + (1 \times 2^2) + (1 \times 2^1) + (0 \times 2^0)$$

$$\downarrow \text{ compliment}$$

$$(1001)_2 = (-1 \times 2^3) + (0 \times 2^2) + (0 \times 2^1) + (1 \times 2^0) = -8 + 1$$

$$\downarrow \text{ add one}$$

$$(1001)_2 + (0001)_2 = (1010)_2 = -8 + 0 + 2 + 0 = -6$$

Also works in reverse! (from negative to positive)

$$\rightarrow$$
 -6 = $(1010)_2 \Rightarrow (0101)_2 + 1 \Rightarrow (0110)_2 = 6$

Signed Extension

Signed Extension:

- Represent a number using more bits but keep numerical value.
- Very easy in two's compliment!
- Copy the signed bit to the left until desired number of bits.

Examples: 8-bit to 16-bit

- 2: $0000\ 0010 \Rightarrow 0000\ 0000\ 0000\ 0010$
- -2: 1111 1110 ⇒ 1111 1111 1111 1110
- \blacksquare -10: 1111 0110 ⇒ 1111 1111 1111 0110

Note: Truncation (representing a number using less bits) is tricky and you must know what you're doing.

Logical Shift

Logical Shift:

- Shift the bits left or right a specified number of times.
- Fills the vacancies with 0s on shift left and shift right.
- Throw away any bits that flow out.
- << (shift left) and >> (shift right) in C (unsigned).

Examples (in 8 bits):

- $2 << 3 = (0000\ 0010) << 3 = (0001\ 0000) = 16.$
- \blacksquare 8 >> 2 = (0000 1000) >> 2 = (0000 0010) = 2.
- \blacksquare -4 >> 1 = (1111 1100) >> 1 = (0111 1110) = 126.
 - This last one is ambiguous if it is logical or arithmetic shift. In high-level programming languages the right shift operator is usually an arithmetic shift...

Arithmetic Shift

Arithmetic Shift:

- Shift the bits left or right a specified number of times.
- Fills the vacancies with 0s on shift left.
- Fills the vacancies with 1s on shift right if number is negative.
- Fills the vacancies with 0s on shift right if number is positive.
- Throw away any bits that flow out.
- << (shift left) and >> (shift right) in C (signed).

Examples (in 8 bits):

- $2 << 3 = (0000\ 0010) << 3 = (0001\ 0000) = 16.$
- \blacksquare 8 >> 2 = (0000 1000) >> 2 = (0000 0010) = 2.
- \blacksquare -4 >> 1 = (1111 1100) >> 1 = (1111 1110) = -2.