
Part 3

CHAPTER 2

Computer Arithmetic and Digital Logic



Alan Clements

These slides are being provided with permission from the copyright for in-class (CS2208B) use only. The slides must not be reproduced or provided to anyone outside of the class.


All download copies of the slides and/or lecture recordings are for personal use only. Students must destroy these copies within 30 days after receipt of final course evaluations.



Music: "Corporate Success" by Scott Holmes, used under <u>Attribution-NonCommercial License</u>

Rounding and Errors

- ☐ Floating-point arithmetic can lead to an increase in the number of bits in the fractional part
- ☐ To keep the number of fractional bits constant, rounding is needed
 - o Error will be induced
- ☐ The rounding mechanisms include
 - Truncation (i.e., dropping unwanted bits) by rounding towards zero; a.k.a., rounding down
 - o *Rounding towards positive or negative infinity*, the nearest valid floating-point number in the direction positive or negative infinity, respectively, is chosen to decide the rounding; a.k.a., *rounding up*.
 - o *Rounding to nearest*, the closest floating-point representation to the actual number is used.



41

R. El-Sakka.

Rounding and Errors

☐ Decimal rounding examples:

Rounding towards zero

- +4.7 truncation, i.e., rounded towards zero → +4
- \circ -4.7 truncation, i.e., rounded towards zero \rightarrow -4

In *truncation*, we just get rid of the extra digits (regardless the number is positive or negative). The end result is *rounding towards zero*.

Rounding towards \pm infinity (i.e., rounding up)

It is the opposite of rounding towards zero


- \circ +4.7 rounded towards \pm infinity \rightarrow +5
- \circ -4.7 rounded towards \pm infinity \rightarrow -5

Rounding to nearest

This slide is modif.

- \circ +4.7 rounded to nearest \rightarrow +5
- \circ -4.7 rounded to nearest \rightarrow -5
- \circ +4.3 rounded to nearest \rightarrow +4
- \circ -4.3 rounded to nearest \rightarrow -4





Normalization

☐ A number is normalized when it is written in *scientific notation* with a single non-zero decimal digit before the decimal point (i.e., the integer part consists of a single non-zero digit).

Example 1:

- The number 123.456_{10} is not normalized, as the integer part is not a single non-zero digit.
- To normalize it, you need to move the decimal point two position to the left and to compensate this move by multiplying the number by 100, i.e.,

$$\checkmark 1.23456_{10} \times 10^2$$

Example 2:

- The number 0.00123₁₀ is not normalized, as the integer part is not a single non-zero digit.
- To normalize it, you need to move the decimal point three position to the right and to compensate this move by dividing the number by 1000, i.e.,

$$\checkmark 1.23_{10} \times 10^{-3}$$

□ In base b, a <u>normalized number</u> will have the form $\pm b_0 \cdot b_1 b_2 b_3 \dots \times b^n$ 42 where $\mathbf{b_0} \neq \mathbf{0}$, and $\mathbf{b_0}$, $\mathbf{b_1}$, $\mathbf{b_2}$, $\mathbf{b_3}$... are integers between $\mathbf{0}$ and $\mathbf{b_1}$

Floating-point Numbers

- ☐ Floating-point arithmetic lets you handle the very large and very small numbers found in scientific applications.
- □ Floating-point is also called *scientific notation*, because scientists use it to represent large numbers (e.g., 1.2345×10^{20}) and small numbers that are very close to zero, but not zero (e.g., $0.45679999 \times 10^{-50}$).
- ☐ A floating-point value is encoded as *two* components:

 a number and the *location of the radix point* within the number.
- □ A binary floating-point number is represented by

$mantissa \times 2^{exponent}$

- o for example, 101010.1111110_2 can be represented by $1.010101111110_2 \times 2^5$, where
 - the **significan**t **d**igits (or simply **significand**) is 1.010101111110 and
 - the *exponent* is 5 $(00000101_2 \text{ in 8-bit binary arithmetic})$.
- ☐ The term *mantissa* has been replaced by *significand* to indicate the number of *significant bits* in a floating-point number.
- Because a floating-point number is defined as the *product* of *two values*, a floating-point value is not unique; for example $10.110_2 \times 2^4 = 1.011_2 \times 2^5$.

Normalization of Floating-point Numbers

- ☐ In the *IEEE-754* Standard for Floating-Point Arithmetic, the **significand** term is always <u>normalized</u> (<u>unless</u> it represents a <u>zero</u> or <u>underflow</u>)
- ☐ A <u>normalized</u> binary **significand** always has a leading **1** (i.e., **1** in the MSB)
- ☐ The *normalized* absolute *non-zero* value of the *IEEE-754* FP numbers are always in *the range* The book is missing the -ve sign here

The minimum

The maximum absolute value $0 hinspace 1.000...0_2 imes 2^{-\dot{e}} ext{ to } 1.111...1_2 imes 2^e hinspace absolute value$

- ☐ The *floating-point* normalization leads to the highest available *precision*, as all significant bits are utilized.
 - o the un-normalized 8-bit significand 0.0000101 has only three significant bits, whereas
 - the normalized 8-bit significand 1.0100011 has eight significant bits.

three not four

- If a floating-point calculation is to yield the value $0.110..._2 \times 2^e$, the result would be normalized to give $1.10..._2 \times 2^{e-1}$.
- Similarly, the result $10.1..._2 \times 2^e$ would be normalized to $1.01..._2 \times 2^{e+1}$

Significand and Exponent Encoding

- ☐ The *significand* of an *IEEE-754* floating-point number is *represented in sign and magnitude* form.
- ☐ The exponent is represented in a biased form, by adding a constant to the true exponent.
- □ Suppose an 8-bit exponent is used and all exponents are biased by 127.
 - o If the *true exponent* is 0, it will be encoded as 0 + 127 = 127.
 - o If the *true exponent* is -2, it will be encoded as -2 + 127 = 125.
 - o If the *true exponent* is +2, it will be encoded as +2 + 127 = 129.
- \square A real number such as 1010.1111 is normalized to get +1.01011111 \times 2³.
 - The *true exponent* is +3, which is encoded as a *biased exponent* of 3 + 127; that is 130_{10} or 10000010 in binary form.
- \square Likewise, if a *biased exponent* is 130_{10} , the *true exponent* is 130 127 = 3

.7

i.e., excess-127 code

Significand and Exponent Encoding

□ A 32-bit single-precision *IEEE-754* floating-point number is represented by the bit sequence


- o **S** is the sign bit,
 - 0 means positive significand,
 - 1 means negative significand
- o **E** is an eight-bit biased exponent that tells you how to shift the binary point, and
- o F is a 23-bit <u>fractional</u> significand.
- The leading 1 in front of the significand is <u>omitted when the</u> number is encoded. In this case, B is 127,
- \square A floating-point number X is defined as:

$$1 \le E \le 254 \iff X = (-1)^S \times 2^{(E-B)} \times 1.F$$

FIGURE 2.7

Structure of a 32-bit IEEE floating-point number

When $1 \le E \le 254$, the significand = 1 + the fractional significand



Significand and Exponent Encoding

- \Box If the exponent **EEEEEEEE** > 0, the **significand** of an **IEEE-754** floatingpoint number is *normalized* in the range 1.0000...00 to 1.1111...11,
- \square If the exponent **EEEEEEEE = 0**, the **significand** is ••• Used when it is **impossible** to represented without normalization. normalize the number.
 - o In such case, the floating-point number X is defined as:

$$E = 0 \iff X = (-1)^{S} \times 2^{(0 - (B - 1))} \times 0.F$$

When E = 0, the

gnificand = the fractional significand where,

In this case, B-1 is 126, i.e., excess-126 code

- o S is the sign bit,
 - 0 means positive significand,
 - 1 means negative significand
- $rac{E}=0$
 - the exponent was biased by B-1
- o *F* is the fractional significand
- - As E = 0, the significand was encoded <u>without normalization</u>, i.e., 0.F without an implicit leading one
- □ When E = 0, $F \neq 0$ → ± Denormalized underflow number

Significand and Exponent Encoding

- ☐ The floating-point value of **zero** is represented by
 - $0.00...00 \times 2^{\text{most negative exponent}}$

i.e., the **zero** is represented by


- o a **zero** significand and
- a **zero** exponent

as Figure 2.6 demonstrates.

In this floating-point representation, how many zeros do we have?

FIGURE 2.6

Representing the value zero in floating-point arithmetic



Computer Organization and Architecture: Themes and Variations, 1st Edition

Clements

Significand and Exponent Encoding

TABLE 2.7

IEEE Floating-Point Formats

float type in Java and C

	Single Precision	Double Precision ••• double type in Java and (Single Extended)	C-
Field width in bits		The L value =1, if and only if $E \neq 0$	
S = sign	1	The L value =0, if and only if E = 0	
E = exponent	8	11	
L = leading bit	1 (not stored)	1 (not stored)	
F = fraction	23	If $E \neq 0$, True exponent =	
Total width	32	64 biased exponent – bias	
Exponent Biase value		If E = 0, True exponent =	
Maximum E	255	0 - (bias - 1)	
Minimum E	0	0	
Bias Unbiased	127	1023	
E _{max} values	127	1023	
E_{\min}	-126	$\frac{-1022}{1000}$ book flipped the meaning of S. It is S=0 for +ve and =1 for	

S = sign bit (0 for a negative number, 1 for a positive number)

L = leading bit (always 1 in a normalized, non-zero significand)

F = fractional part of the significand

1 > 254 for NORMALIZED

The range of exponents is from the minimum E + 1 to the maximum E - 1

The number is represented by $-1^5 \times 2^{E-\text{ exponent}} \times \text{L.F}$

Zero is represented by the minimum exponent, L=0, and F=0

The maximum exponent, $E_{\text{max}} + 1$ represents signed infinity

This slide is modified from the original slide

When E = 255

In the IEEE single precision representation,


the <u>largest</u> normalized absolute number is $2^{+127} \times 1.111...1_2 \approx 2^{+128} = 10^{+38.5318394} \approx 3.4 \times 10^{+38.}$

the <u>smallest</u> <u>normalized</u> absolute number is $2^{-126} \times 1.000...0_{2} = 2^{-126} = 10^{-37.9297794} \approx 1.17 \times 10^{-38}$.

Significand and Exponent Encoding

FIGURE 2.8

IEEE floating-point number space for a single-precision number



$$E = 0 \iff X = (-1)^{S} \times 2^{(0 - (B - 1))} \times 0.F$$


- □ *Underflow* occurs when the result of a calculation is a smaller number (in magnitude) than the smallest value representable as a *normalized* floating point number in the target data type.
- □ Replacing an *underflow* case by a **zero** might be *ok* from the *addition* point of view, but it is *not ok* from the *multiplication* point of view.
- □ NaN means *Not a Number*, e.g., $\mathbf{0} \div \mathbf{0}$, $\infty \div \infty$, $\mathbf{0} \times \infty$, or $\infty \infty$
- \square In NaN, the value of \mathbf{F} is ignored by applications.

From Binary to 32-bit IEEE-754 FP

 \square Example 1(a):

Convert -111100001111100.001111100001111₂ into a 32-bit single-precision IEEE-754 FP value.

- The number is negative \rightarrow S=1
- o The *significand* is 11110000111100.00111100001111₂
- \circ The normalized $\underset{1.111000011110000111100001111}{\textit{significand}}$ is
- o To encode the *F* value, we will <u>ignore</u> the leading 1 and we will only consider the first 23 bits after the binary point, i.e., 111000011110000111100001111₂
- o The ignored part of the *significand* is *rounded to the nearest*, hence the value of $F = 11100001111000011110001_2$
- o The *biased exponent* is the *true exponent* plus 127; that is, $13 + 127 = 140_{10} = 1000 \ 1100_2$ Hence, $\textit{E} = 1000 \ 1100_2$
- o The final number is $1100\ 0110\ 0111\ 0000\ 1111\ 0000\ 1111\ 0001_2$, or $C670F0F1_{16}$. Structure of a 32-bit IEEE floating-point number



B = 1011 C = 1100


D = 1101

E = 1110

F = 1111

Rounding and Errors

- When the number to be rounded is midway between two points on the floating-point line, IEEE rounding to the nearest selects the value whose least-significant digit is zero (i.e., rounding to an even binary significand).
 - \square For example:
 - \square 0.11100001111000011110000010002 will be rounded to $0.1110000111100001111000_{9}$
 - \square 0.1110000111100001111000110002 will be rounded to $0.111000011110000111100_{2}$



R. El-Sakka.

From 32-bit IEEE-754 FP to Binary

- □ <u>Example 1(b)</u>: Convert C670F0F1₁₆ from a 32-bit single-precision IEEE-754 FP value into a binary value
 ---This is the same value as in example 1(a)
 - Unpack the number into sign bit, biased exponent, and fractional significand:

 $C670F0F1_{16} \rightarrow 1100\ 0110\ 0111\ 0000\ 1111\ 0000\ 1111\ 0001_2$

- \blacksquare S = 1
- $E = 100 \ 0110 \ 0$
- F =111 0000 1111 0000 1111 0001
- As the sign bit is 1, the number is negative.
- Subtract 127 from the *biased exponent* 100 0110 0_2 to get the *true exponent* → 1000 1100 $_2$ 0111 1111 $_2$ = 0000 1101 $_2$ = 13 $_{10}$.
- \circ The fractional significand is .111 0000 1111 0000 1111 0001₂.
- o Reinserting the *leading one* gives 1.111 0000 1111 0000 1111 0001₂.
- o The number is $-1.111\ 0000\ 1111\ 0000\ 1111\ 0001_2 \times 2^{13} = -1111\ 0000\ 1111\ 00001_2$

Note that the correct answer is: $-1111\ 0000\ 1111\ 00.00\ 1111\ 00001_2$ not $-1111\ 0000\ 1111\ 00.00\ 1111\ 00001111_2$ This is due to the rounding error.

Total length 32 bits

31 30 23 22 0

S E F

8-bit exponent 23-bit fractional significand Sign bit

Structure of a 32-bit IEEE floating-point number

- - Unpack the number into sign bit, biased exponent, and fractional significand.
 - \blacksquare S = 1
 - $E = 1111 \ 1100$
 - $\mathbf{F} = 110\ 0000\ 0000\ 0000\ 0000\ 0000$
 - o As the sign bit is 1, the number is negative.
 - Subtract 127 from the *biased exponent* 1111 1100₂ to get the *true exponent* → 1111 1100₂ 0111 1111₂ = 0111 1101₂ = 125₁₀.
 - \circ The fractional significand is $$110\ 0000\ 0000\ 0000\ 0000\ 0000_2$.$
 - \circ Reinserting the *leading one* gives 1.110 0000 0000 0000 0000 0000₂.
 - o The number is $-1.11_2 \times 2^{125} = -1.75_{10} \times 2^{125}$

```
2^{125} = 10^z \rightarrow \log_{10}(2^{125}) = z \rightarrow z = 125 \times 0.30103 = 37.62875

2^{125} = 10^{37.62875} = 10^{37} \times 10^{0.62875} = 10^{37} \times 4.253535

-1.75 \times 2^{125} = -1.75 \times 10^{37} \times 4.253535 = -7.44368625 \times 10^{37}
```

- - Unpack the number into sign bit, biased exponent, and fractional significand.
 - \blacksquare S = 1
 - \blacksquare **E** = 0000 0000
 - \blacksquare F = 110 0000 0000 0000 0000 0000
 - As the sign bit is 1, the number is negative.
 - As E = 0 → true exponent = 0 (127 1) = -126
- The fractional significand is .110 0000 0000 0000 0000 0000₂.
 - o As E = 0, the fractional significand is <u>not normalized</u>. ••• The L value = 0, as E = 0
 - o As E = 0 and $F \neq 0$, it means that this is an *underflow* case.
 - o The number is $-0.11_9 \times 2^{-126} = -0.75 \times 2^{-126}$

```
2^{-126} = 10^z \rightarrow \log_{10}(2^{-126}) = z \rightarrow z = -126 \times 0.30103 = -37.92978 2^{-126} = 10^{-37.92978} = 10^{-37} \times 10^{-0.92978} = 10^{-37} \times 0.11755
                                                                                                                                      55
-0.75 \times 2^{-126} = -0.75 \times 10^{-37} \times 0.11755 = -0.0881625 \times 10^{-37}
                         = -8.81625 \times 10^{-39} < the smallest normalized value (1.17×10<sup>-38</sup>)
```

- - Unpack the number into sign bit, biased exponent, and fractional significand.
 - S = 0
 - E = 1111111111
 - F =000 0000 0000 0000 0000 0000
 - As the sign bit is 0, the number is positive.
 - o As $E = 255 \rightarrow$ either an infinity case or a NaN case
 - \circ The fractional significand is $000\ 0000\ 0000\ 0000\ 0000\ 0000_2.$
 - O As the *bias exponent* is 255 and the F value is **zero**, it means that this is an **+infinity** case, e.g., a number that is larger than $3.4028235 \times 10^{+38}$

- - Unpack the number into sign bit, biased exponent, and fractional significand.
 - \blacksquare S = 1
 - \blacksquare E = 1111 1111
 - $\mathbf{F} = 110\ 0000\ 0000\ 0000\ 0000\ 0000$
 - As the sign bit is 1, the number is negative.
 - o As $E = 255 \rightarrow$ either an infinity case or a NaN case
 - \circ The fractional significand is $$.110\ 0000\ 0000\ 0000\ 0000\ 0000_2$.$
 - O As the *bias exponent* is 255 and the F value is *NOT zero*, it means that this is a NaN case (*Not a Number*), e.g., the result of a $0 \div 0$, $\infty \div \infty$, $0 \times \infty$, or $\infty \infty$ operation.
 - o In NaN cases, the value of F is ignored.
 - The value –NaN

- □ <u>Example 6:</u> Convert C46C0000₁₆ from 32-bit single-precision IEEE-754 FP value into a decimal value.
 - \circ Convert the hexadecimal number into binary form $C46C0000_{16} = 1100\ 0100\ 0110\ 1100\ 0000\ 0000\ 0000\ 0000_2$.
 - Unpack the number into *sign bit*, *biased exponent*, and *fractional significand*.
 - S = 1
 - $E = 1000 \ 1000$
 - F = 110 1100 0000 0000 0000 0000
 - As the sign bit is 1, the number is negative.
 - We subtract 127 from the *biased exponent* $1000 \ 1000_2$ to get the *true exponent* \rightarrow $1000 \ 1000_2 0111 \ 1111_2 = 0000 \ 1001_2 = 9_{10}$
 - \circ The fractional significand is .110 1100 0000 0000 0000 0000₂.
 - \circ Reinserting the leading one gives 1.110 1100 0000 0000 0000 0000₂.
 - o The number is $-1.110\ 1100\ 0000\ 0000\ 0000\ 0000_2 \times 2^9$, or $-1110\ 1100\ 00.00\ 0000\ 0000\ 0000_2$ (i.e., -944.0_{10}).

1 = 0001 2 = 0010 3 = 0011 4 = 0100 5 = 0101 6 = 0110 7 = 0111 8 = 1000 9 = 1001 A = 1010 B = 1011 C = 1100

it is 9

not 7

= 0000

From Binary to 32-bit IEEE-754 FP

- □ <u>Example 7:</u> Convert $0.0000100000000000000000000111_2 \times 2^{-124}$ into a 32-bit single-precision IEEE-754 FP value.
 - The number is positive $\rightarrow S = 0$
 - \circ The *fractional* part is 0.00001000000000000000000001112 The normalized *fractional* part is 1.00000000000000000001112 \times 2-5
 - $\circ~$ Hence the number will be 1.000 0000 0000 0000 0000 0001 11 $_2$ × 2 $^{\text{-}129}$
 - As the *exponent* is less than −126, the *fractional* part *can NOT be* represented as a *normalized* number (the number is *too small*)
 - o Instead, we will attempt to represent it as an $\underline{un-normalized}$ $\underline{underflow}$ \underline{number} with $\underline{exponent} = -126$
 - $\circ~$ The number = 0.001 0000 0000 0000 0000 0000 0011 $1_2 \times 2^{\text{--}126}$
 - \circ The encoded **F** value (23 bits) will be **001 0000 0000 0000 0000 0000**

rounded

- o As F is <u>un-normalized</u> the <u>biased exponent</u> will be the <u>true exponent</u> plus 127 1; that is, -126 + 127 1 = 0; Hence, $E = 0000 \ 0000_2$

From Binary to 32-bit IEEE-754 FP

- □ <u>Example 8:</u> Convert $0.0000\,0000\,0000\,0000\,0000\,0000\,0001\,11_2 \times 2^{-124}$ into a 32-bit single-precision IEEE-754 FP value.
 - The number is positive $\rightarrow S = 0$
 - o The *fractional* part is $0.0000000000000000000000000111_2$ The normalized *fractional* part is $1.11_2 \times 2^{-28}$
 - Hence the number will be $1.11_2 \times 2^{-152}$
 - As the *exponent* is less than -126, the *fractional* part *can NOT be* represented as a *normalized* number (the number is *too small*)
 - o Instead, we will attempt to represent it as an $\underline{un-normalized}$ $\underline{underflow}$ \underline{number} with $\underline{exponent} = -126$
 - o The number = 0.000 0000 0000 0000 0000 0000 0011 $1_2 \times 2^{-126}$
 - \circ The encoded **F** value (23 bits) will be **000 0000 0000 0000 0000 0000**
 - o As F is <u>un-normalized</u> the <u>biased exponent</u> will be the <u>true exponent</u> plus 127 1; that is, -126 + 127 1 = 0; Hence, $E = 0000 \ 0000_2$
 - The final number is $0000\ 0000\$

I.e., the number is encoded as **ZERO**

rounded

rounded

From Binary to 32-bit IEEE-754 FP

- □ <u>Example 9:</u> Convert $0.000000000000000000000000000011111_2 \times 2^{-124}$ into a 32-bit single-precision IEEE-754 FP value.
 - The number is positive $\rightarrow S = 0$
 - \circ The *fractional* part is 0.00000000000000000000000000111112 The normalized *fractional* part is 1.11112 × 2 -26
 - Hence the number will be $1.1111_2 \times 2^{-150}$
 - As the *exponent* is less than −126, the *fractional* part *can NOT be* represented as a *normalized* number (the number is *too small*)
 - o Instead, we will attempt to represent it as an $\underline{un-normalized}$ $\underline{underflow}$ \underline{number} with $\underline{exponent} = -126$
 - \circ The number = 0.000 0000 0000 0000 0000 0000 1111 $1_2 \times 2^{-126}$
 - o The encoded *F* value (23 bits) will be *000 0000 0000 0000 0000 0001*
 - o As F is <u>un-normalized</u> the <u>biased exponent</u> will be the <u>true exponent</u> plus 127 1; that is, -126 + 127 1 = 0; Hence, $E = 0000 \ 0000_2$
 - o The final number is $0000\ 0000\$

From Binary to 32-bit IEEE-754 FP

- - The number is positive $\rightarrow S = 0$

 - o The *biased exponent* is the *true exponent* plus 127; that is, 127 + 127 = 254; Hence, $E = 1111 \ 1110_2$

 - This number is the *largest absolute* <u>normalized</u> <u>number</u> (3.4028235×10⁺³⁸)

From Binary to 32-bit IEEE-754 FP

- - The number is positive $\rightarrow S = 0$

 - o To encode the *F* value, we will only consider the first 23 bits after the binary point
 - o Note that, the rounding here will add 1 to the fraction to make it $10.000\ 0000\ 0000\ 0000\ 0000\ 0000\ 2^{\times}\ 2^{127}$
 - o As a result of this, the number needs to renormalized again $1.0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 2 \times 2^{128}$
 - The true exponent of the normalized number is > 127, hence the number will be encoded as **+infinity**, i.e.,
 - > the *F* value will be *000 0000 0000 0000 0000 0000*
 - > the **E** value will be 1111 1111₂
 - o The final number is $0111 \ 1111 \ 1000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000_2$, i.e., +infinity $(7F800000_{16})$

From Decimal to 32-bit IEEE-754 FP

- \blacksquare <u>Example 12:</u> Convert 4100.125₁₀ into a 32-bit single-precision IEEE-754 FP value.
 - Convert 4100.125₁₀ into a fixed-point binary
 - $4100_{10} = 1\ 0000\ 0000\ 0100_2$ and
 - $0.125_{10} = 0.001_2.$
 - Therefore, $4100.125_{10} = 1000\ 0000\ 0010\ 0.001_2$.
 - o Normalize 1000 0000 0010 0.001_2 to $1.000 0000 0010 0001_2 \times 2^{12}$.
 - \circ The sign bit, S, is 0 because the number is positive
 - 0 The *biased exponent* is the *true exponent* plus 127; that is, $12_{10} + 127_{10} = 139_{10} = 1000 \ 1011_2$
 - o The fractional significand is 000 0000 0010 0001 **0000 0000**
 - *the leading 1 is stripped* and
 - the significand is **expanded** to 23 bits.
 - o The final number is 0100 0101 1000 0000 0010 0001 0000 0000₂, or 45802100_{16} .

= 0000= 000= 0.010 $= 0.01^{\circ}$ = 0.100 $\delta = 0.10^{\circ}$ $9 = 100^{\circ}$

- □ Consider an example using an *unsigned normalized 8-bit* (1 + 7 *bits*) *significand* and an *unbiased exponent* with $A = 1.010 \ 1001_2 \times 2^4$ and $B = 1.100 \ 1100_2 \times 2^3$
- ☐ To multiply these numbers,
 - you multiply the significands and
 - *add* the exponents

$$\square$$
 A × B= 1.010 1001₂ × 2⁴ × 1.100 1100₂ × 2³
= 1.010 1001₂ × 1.100 1100₂ × 2³⁺⁴
= 10.00 0110 1010 1100₂ × 2⁷

After normalization:

$$= 1.000\ 0110\ 1010\ 1100_2 \times 2^8.$$

After rounding using:

<u>truncation</u>, i.e., <u>rounding towards zero</u>:

$$\rightarrow 1.000\ 0110_2 \times 2^8 = (268_{10})$$

<u>rounding up</u>, i.e., <u>rounding toward infinity</u>:

$$\rightarrow$$
 1.000 0111₂ × 2⁸ = (270₁₀)

How about rounding to the nearest?

 $A = 1.010 \ 1001_2 \times 2^4$ $= 1010 \ 1.001_2$ $= 21.125_{10}$

$$B = 1.100 \ 1100_2 \times 2^3$$

= 1100. 1100₂
= 12.75₁₀

$$A \times B = 269.34375_{10}$$

$$269_{10} = 1\ 0000\ 1101_2$$

 $0.34375_{10} = 0.010\ 1100_2$

$$A \times B = 66$$

1000 0110 1.010 11002

Why is not it rounded to 269₁₀?

- □ Now let's look at the addition.
- ☐ If these two floating-point numbers $(A = 1.010\ 1001_2 \times 2^4 \text{ and } B = 1.100\ 1100_2 \times 2^3)$ were to be added *by hand*, we would *automatically align the binary points* of *A* and *B* as follows.

$$\begin{array}{c} 10101.001_2 \\ + 1100.1100_2 \\ \hline 100001.1110_2 \end{array}$$

```
A = 1.010 \ 1001_2 \times 2^4
   = 1010 \ 1.001_{2}
   = 21.125_{10}
B = 1.100 \ 1100_{2} \times 2^{3}
   = 1100. 1100_{2}
   = 12.75_{10}
A + B = 33.875_{10}
33_{10} = 100001_2
0.875_{10} = 0.111_2
   100001.1112
```

☐ However, as these numbers are held in a *normalized* floating-point format the computer has to carry out the following steps to *equalize exponents*:

$$A = 1.0101001_2 \times 2^4$$

$$B = +1.1001100_2 \times 2^3$$

- 1. *Identify* the number with *the smaller exponent*.
- 2. Make the smaller exponent equal to the larger exponent by dividing the significand of the smaller number by the same factor by which its exponent was increased, i.e., un-normalizing the small number to have the same exponent value as the large number.

 (1.100 $1100_2 \times 2^3 \rightarrow 0.110 \ 0110 \ 0_2 \times 2^4 \rightarrow 0.110 \ 0110_2 \times 2^4$).
- 3. Add (or subtract) the significands.
- 4. If necessary, normalize the result.
- \square We can now add A to the denormalized B.

$$A = 1.010 \ 1001_2 \times 2^4$$

$$B = \underbrace{+ 0.110 \ 0110_2 \times 2^4}_{10.000 \ 1111_2 \times 2^4} \rightarrow 1.000 \ 0111 \ \mathbf{1}_2 \times 2^5 = \mathbf{33.875_{10}}$$

 \square After rounding using <u>truncation</u>, i.e., <u>rounding towards zero</u>:

$$\rightarrow$$
 1.000 0111₂ × 2⁵ = (33.75₁₀)

<u>rounding up</u>, i.e., <u>rounding toward infinity</u>:

→
$$1.000 \ 1000_2 \times 2^5 = (34_{10})$$



□ Consider another example using an *unsigned normalized 8-bit* (1+7 bits) significand and an *unbiased exponent* with $A=1.010\ 1001_2\times 2^4$ & $C=1.100\ 1100_2\times 2^{13}$

$$A = 1.0101001_2 \times 2^4$$

$$C = +1.1001100_2 \times 2^{13}$$

- 1. *Identify* the number with *the smaller exponent*.
- Make the smaller exponent equal to the larger exponent by dividing the significand of the smaller number by the same factor by which its exponent was increased, i.e., un-normalizing the small number to have the same exponent value as the large number.
 (1.010 1001₂ × 2⁴ → 0.000 0000 010101001₂ × 2¹³ → 0.000 0000₂ × 2¹³)
- 3. Add (or subtract) the significands.
- \square We can now add C to the un-normalized A.

$$A = 0.000 \ 0000_2 \times 2^{13}$$

$$C = + 1.100 \ 1100_2 \times 2^{13}$$

$$1.100 \ 1100_2 \times 2^{13} \longrightarrow C$$

□ If the difference between the two exponents of the <u>normalized</u> two numbers is <u>greater than</u> the number of significant bits (i.e., 7 + 1) → the addition result of these two numbers will be the larger of them.

