Quick Start Guide

CONFIDENTIAL

03/11/2005 Nintendo Co., Ltd.

0. Introduction

This document explains how to use the NITRO-SDK development source tree snapshot (This package fixes files at a point in time. This package is used because changes occur frequently during development).

The explanation occurs in the following order:

- 1. Preparing Development Tools
- 2. Expanding the NITRO-SDK Package
- 3. Setting Environment Variables
- 4. Building the NITRO-SDK Tree
- 5. Trying the Samples
- 6. Writing a Simple Program
- 7. Using Build Switch

1. Preparing Development Tools

The build for the current NITRO-SDK has been confirmed on the following Windows environment.

Microsoft Windows 2000 Professional

The following tools are necessary to build (compile, etc.) the Nitro SDK.

- CodeWarrior for NITRO
- Cygwin or MinGW(MSYS Tools)

In addition, one of the following tools must be used for debugging.

- NITRO Simulator ensata
- IS-NITRO-EMULATOR

Generally, these tools will be distributed or sold with this package. However, if this is not the case, please contact the distributors.

See CygwinPackageList.rtf in the NitroSDK/docs/SDKTools directory after unzipping the SDK to learn about installation of Cygwin.

See the documentation for the tools to learn about installation procedures.

2. Expanding the NITRO-SDK Package

Expand the NITRO-SDK package onto a disk. The package is compressed in WinZip format, so use the appropriate tools to decompress the files or expand the files using the unzip command in Cygwin.

Use the following procedure to expand files using the tar command.

```
% cd <directory to expand>
% unzip e:/NITRO-SDK/NitroSDK-2.0-XXXXXX.zip
```

A directory named NitroSDK is created ("%" is the prompt).

NTR-06-0018-002-A Released: April 22, 2005

3. Setting Environment Variables

Set the absolute path of the expanded NITRO-SDK directory as the environment variable NITROSDK_ROOT. If nothing is set, the default value is C:\NitroSDK. This directory is referred to below as \$NitroSDK.

4. Building the NITRO-SDK Tree

Start bash with Cygwin, and make the current directory \$NitroSDK. In \$NitroSDK, enter the following to start the build.

% make

If an error occurs during the process, it is possible that a mistake was made in the settings or that a bug may exist in the package. Review the settings before contacting the distributor.

5. Trying the Samples

Run the samples to verify whether the build has completed successfully. We assume that you have ensata for this example.

- 1) Start ensata.
 - ensata contains both ensata_dx.exe that uses DirectX for the rendering process and ensata.exe that does not use DirectX for the rendering process. Chose the file that is appropriate for your environment. Both of these files use DirectInput8 (DINPUT8.DLL) to support controller input. If your PC does not have DirectInput8 installed, you can obtain it from the Microsoft website.
- Right click on the window and select [Open NITRO file] (indicated with the red circle below).



3) Specify the .srl file in the dialog box.

For this sample, specify the following file that was created by the previous build.

\$NitroSDK/build/demos/gx/UnitTours/3D Pol LightColor/bin/ARM9-TEG/Release/main.srl

4) Press the ensata window execution button [indicated with the red circle in the figure below].



5) The following two cubes should be displayed in the screen window. The color of the cube on the right changes constantly.



6) Press the STOP button [indicated with a red circle in the figure below] to stop the .bin file emulation.



6. Writing a Simple Program

The following describes how to write a simple program.

1) Make an appropriate work directory and copy the following files into it.

\$NitroSDK/build/demos/_template/src/main.c
\$NitroSDK/build/demos/_template/makefile

NTR-06-0018-002-A Released: April 22, 2005 2) Make the following changes to main.c.

Lines numbered 16 and later

3) Execute the make command. The following will be output (slight differences in display may occur due to revisions in the SDK). If an error or warning is displayed, please review step 2 to check for errors.

```
% make
==== /c/NitroSDK/xxx
```

C:/Program\ Files/Metrowerks/CodeWarrior\ for\ NITRO\ V0.3/ARM_Tools/Command_Line _Tools/mwccarm.exe -lang c -proc arm946e -nothumb -nopic -nopid -interworking -O 4 -opt speed -inline on, noauto -g -msgstyle std -w all -enc SJIS -char unsigned -stdinc -enum int -stdkeywords off -avoid_strb all,err -DSDK_CWBUG_INLINE -DSDK _TEG -DSDK_4M -DSDK_ARM9 -DSDK_CW -DSDK_RELEASE -DSDK_CODE_ARM -gccinc -I./inclu de -I./src -Id:/dev/NitroSDK/include -cwd proj -c main.c -o obj/ARM9-TEG/Release/main.o

C:/Program\ Files/Metrowerks/CodeWarrior\ for\ NITRO\ V0.3/ARM_Tools/Command_Line _Tools/mwldarm.exe -proc arm946e -nothumb -nopic -nopid -interworking -g -msgsty le std -w on -stdlib -map closure -main _start -L./lib/ARM9-TEG/Release -Ld:/dev /NitroSDK/lib/ARM9-TEG/Release ./obj/ARM9-TEG/Release/main.o -llibfx.a -llibgx.a -llibos.a -llibirissyscall.a -lcrt0.o d:/dev/NitroSDK/include/Nitro/ARM9-TEG.lcf -o bin/ARM9-TEG/Release/main.nef

C:/Program\ Files/Metrowerks/CodeWarrior\ for\ NITRO\ V0.3/ARM_Tools/Command_Line
_Tools/elftobin.exe bin/ARM9-TEG/Release/main.nef d:/dev/NitroSDK/tools/elftobin/
spIdle.elf d:/dev/NitroSDK/tools/elftobin/romHeader.bin -o bin/ARM9-TEG/Release/
main.bin%

- 4) Start Ensata. Select [Open NITRO file] from the right click menu. Specify bin/ARM9-TEG/Release/main.srl in the work directory.
- 5) Select [Debug Output Console] (indicated with the red circle in the figure below) from the right click menu.



6) When the execution button is pressed, the debug output window displays the following.

Hello World of NITROid.

7) Press the STOP button to stop the .bin file emulation.

7. Using Build Switch

SDK has several build settings. The IS-NITRO-EMULATOR (or TS board) Release-version library is linked by default, but the Debug version build can occur by changing the settings of the macro at build. This procedure is called a Build Switch.

See \$NitroSDK/docs/SDKRules/Rules-Defines.html for details about a Build Switch.

NTR-06-0018-002-A Released: April 22, 2005