AVR ASM INTRODUCTION

Search this site

AVR ASSEMBLER TUTOR

1. AVR ASM BIT MANIPULATION

2a. BASIC ARITHMETIC

2b. BASIC MATH

2c. LOGARITHMS

2z. INTEGER RATIOS for FASTER CODE

3a. USING THE ADC

3b. BUTTERFLY ADC

4a. USING THE EEPROM

4b. BUTTERFLY EEPROM

5. TIMER
COUNTERS & PWM

6. BUTTERFLY LCD & JOYSTICK

7. BUTTERFLY SPI & AT45 DATAFLASH

Sitemap

AVR ASSEMBLER TUTOR >

2c. LOGARITHMS

BASIC AVR MATH III v1.2 LOGARITHMS & e by RetroDan@GMail.Com

CONTENTS:

- 1. LOG BASE TWO OF A SINGLE-BYTE NUMBER
- 2. LOG BASE TWO OF A SIXTEEN-BIT NUMBER
- 3. MULTIPLYING A SINGLE-BYTE NUMBER BY e
- 4. MULTIPLYING A SIXTEEN-BIT NUMBER BY e
- 5. MULTIPLYING A SINGLE-BYTE NUMBER BY 1/e
- 6. MULTIPLYING A SIXTEEN-BIT NUMBER BY 1/e
- 7. NATURAL LOGARITHM OF A SINGLE-BYTE NUMBER
- 8. NATURAL LOGARITHM OF A SIXTEEN-BIT NUMBER
- 9. LOG BASE 10 OF A SINGLE-BYTE NUMBER
- 10. LOG BASE 10 OF A SIXTEEN-BIT NUMBER

The advantage of using integer math is the speed as versus the much slower speed and large size of floating-point math, however answers can be subject to larger rounding errors with integer math.

1. LOG BASE 2 OF A SINGLE-BYTE NUMBER

The integer value of logarithm base two of a number is useful in determining the number of bits required to store the number. The routine works by shifting the number left until a one falls out. The routine yields an error of about 1% and uses 10 to 40 clock cycles.

.DEF ANSF = R0 ;Fractional Part of Answ .DEF ANS = R1 ;Integer Part of Answer

1 of 11 03/12/2017 11:45 AM

```
.DEF
         A = R16
                              ;Original Value
.DEF
         N = R20
                              ;Counter/Index
        LDI A,100
                             ;Load Original Value
        LDI N,7
                             ;Initial log2 Value
        PUSH A
                              ;Store Original Value
                              ;Shift Left until a one
LOOP:
       LSL A
         BRCS FINI
SKIP:
        DEC N
         BRNE LOOP
FINI:
        MOV ANS, N
                              ;Store the Integer Part
        MOV ANSF, A
                              ;Store Fractional Part
        POP A
                              ;Restore Original Value
```

2. LOG BASE TWO OF A SIXTEEN-BIT NUMBER

We can expand the previous routine to handle 16-bit numbers. The routine uses 20 to 100 clock cycles and should have an error of about 0.1%.

```
.DEF ANSF = R0
                             ;Fractional Part of Answ
.DEF
     ANS = R1
                             ;Integer Part of Answer
.DEF
      AL = R16
                             ;Original Value
.DEF
      AH = R17
.DEF
        N = R20
                             ;Counter/Index
       LDI AL,LOW(10000)
                             ;Load Original Value
        LDI AH, HIGH(10000)
        LDI N,15
                             ;Initial log2 Value
        PUSH AL
                             ;Store Original Value
        PUSH AH
LOOP:
       LSL AL
                             ;Shift Left until a one
        ROL AH
        BRCS FINI
SKIP:
        DEC N
        BRNE LOOP
FINI:
       MOV ANS, N
                             ;Store the Integer Part
       MOV ANSF,AH
                             ;Store Fractional Part
```

POP AH

;Restore Original Value

POP AL ;

3. MULTIPLYING A SINGLE-BYTE NUMBER BY e

The value of e is 2.718281828. To estimate this with integer math we use the ratio 87/32 which is 2.71875 yielding an error of 0.017%. We first multiply our number by 87 then shift the result five times to the right for a division of 32. The routine is about 16 bytes long and takes about 28 clock cycles.

```
.DEF ANSL = R0
                             ;Answer Low Byte
.DEF ANSH = R1
                             ;Answer High Byte
        A = R16
.DEF
                             ;Original Value
.DEF
         B = R18
                             ;Workspace
.DEF
        N = R20
                             ;Counter
       LDI A,100
                             ;Load Multiplier into A
                             ;Load Est of e = 87/32
       LDI B,87
       MUL A,B
       LDI N,5
                             ;32 = 2^5
LOOP:
       LSR ANSH
                             ;Divide result by 32
        ROR ANSL
        DEC N
         BRNE LOOP
```

4. MULTIPLYING A SIXTEEN-BIT NUMBER BY e

To estimate the value of e = 2.718281828 we use the ratio 5567/2048 = 2.71826 which yields an error of 0.001%. The routine is about 40 bytes long and takes about 24 clock cycles.

```
.DEF ANS1 = R0
                            ;Two Byte Answer
.DEF ANS2 = R1
                            ;
.DEF ZER0 = R10
                            ;To hold Zero
.DEF AL = R16
                            ;To hold multiplicand
.DEF AH = R17
.DEF
      BL = R18
                            ;To hold multiplier
.DEF
      BH = R19
.DEF WRK1 = R20
                            ;Workspace
```

```
.DEF WRK2 = R21
                              ;
.DEF WRK3 = R22
.DEF WRK4 = R23
        LDI AL,LOW(1000)
                              ;Load Original Value int
        LDI AH, HIGH(1000)
        LDI BL,LOW(5567)
                              ;Load multiplier into BH
        LDI BH, HIGH (5567)
MUL16x16:
        CLR ZERO
                              ;Set Zero
        MUL AH, BH
                              ;Multiply AH:AL by 5567
        MOVW WRK4:WRK3,R1:R0 ;
        MUL AL, BL
        MOVW WRK2:WRK1,R1:R0 ;
        MUL AH, BL
        ADD WRK2,R0
        ADC WRK3,R1
        ADC WRK4, ZERO
        MUL BH, AL
        ADD WRK2,R0
        ADC WRK3,R1
        ADC WRK4, ZERO
        LSR WRK4
                              ; Ignore lower two bytes
                              ;by 1024 and a shift make
        ROR WRK3
        MOV ANS2, WRK4
                              ;Store Answer
        MOV ANS1, WRK3
                              ;By ignoring the lower t
                              ;get a division by 65536
```

5. MULTIPLYING A SINGLE-BYTE NUMBER BY 1/e

The number 1/e = 0.367879441 can be estimated with the ratio 94/256 which is 0.36719 with an error of 0.19%. The routine is about 6 bytes long and takes about 2 clock cycles.

LDI	A,100	;Original	Value
LDI	B,94	;Load Est	of $e = 94/256$
MUL	A,B	;Multiply	Original Value

6. MULTIPLYING A SIXTEEN-BIT NUMBER BY 1/e

The constant 1/e = 0.367879441 can be estimated by the ratio 24109/65536 = 0.36787 with an error of 0.001%. The routine is about 36 bytes long and takes about 20 clock cycles.

```
.DEF ANS1 = R0
                             ;Two Byte Answer
.DEF ANS2 = R1
.DEF ZER0 = R10
                             ;To hold Zero
.DEF AL = R16
                             ;Original Value
.DEF AH = R17
.DEF BL = R18
                             ;To hold multiplier
.DEF BH = R19
.DEF WRK1 = R20
                             ;Workspace
.DEF WRK2 = R21
                             ;
.DEF WRK3 = R22
.DEF WRK4 = R23
        LDI AL,LOW(1000)
                             ;Load Original Value int
        LDI AH, HIGH(1000)
        LDI BL,LOW(24109)
                             ;Load multiplier into BH
        LDI BH, HIGH(24109)
MUL16x16:
        CLR ZERO
                             ;Set Zero
                             ;Multiply Original Value
        MUL AH, BH
        MOVW WRK4:WRK3,R1:R0 ;
        MUL AL, BL
        MOVW WRK2:WRK1,R1:R0 ;
        MUL AH, BL
        ADD WRK2,R0
        ADC WRK3,R1
        ADC WRK4, ZERO
        MUL BH,AL
```

5 of 11

```
ADD WRK2,R0 ;
ADC WRK3,R1 ;
ADC WRK4,ZER0 ;
MOV ANS2,WRK4 ;Store Answer
MOV ANS1,WRK3 ;By ignoring the lower to get a division by 65536
```

7. NATURAL LOGARITHM OF A SINGLE-BYTE NUMBER

Previously we created routines to calculate the log base two of a number. From the equations below we see that by multiplying the log2 of a number by 0.6931472 we can calculate the natural logarithm.

```
ln(x) = log2(x)/log2(e)
= log2(x) * 1/1.442695
= log2(x) * 0.6931472
= C * Log2(x) ; where C = 0.6931472
```

We will use the following ratios to estimate the constant above.

```
C = 177/256 = 0.69141 Error 0.24%
```

The routine is about 40 bytes long and uses about 50 to 80 clock cycles the error should be less than 1%.

```
.DEF ANSF = R2
                             ;Fractional Part of Answ
     ANS = R3
.DEF
                             ;Integer Part of Answer
.DEF
        A = R16
                             ;Original Value
.DEF
        N = R20
                             ;Counter/Index
       LDI A,250
                             ;Load Original Value
       LDI N,7
                             ;Initial log2 Value
        PUSH A
                             ;Store Original Value
LOOP:
       LSL A
                             ;Shift Left until a one
        BRCS FINI
SKIP:
        DEC N
                             ;
        BRNE LOOP
FINI:
       MOV ANS, N
                             ;Store the Integer Part
       MOV ANSF, A
                             ;Store Fractional Part
        LDI A,177
                             ;Multiply by 177 then
```

```
MUL16x8:MUL ANSF,A ;divide by 256 by ignori
MOV ANSF,R1 ;lowest byte of the resu
MUL ANS,A ;
CLR ANS ;
ADD ANSF,R0 ;
ADC ANS,R1 ;
POP A ;Restore Original Value
```

8. NATURAL LOGARITHM OF A SIXTEEN-BIT NUMBER

Previously we created routines to calculate the log base two of a number. From the equations below we see that by multiplying the log2 of a number by 0.6931472 we can calculate the natural logarithm.

```
ln(x) = log2(x)/log2(e)
= log2(x) * 1/1.442695
= log2(x) * 0.6931472
= C * Log2(x) ; where C = 0.6931472
```

We will use the following ratio to estimate the constant above.

```
C = 45426/65536 = 0.69315 Error = 0.0004%
```

The routine is about 70 bytes long and takes about 40 to 120 clock cycles.

```
.DEF ANSF = R2
                            ;Fractional Part of Answ
     ANS = R3
.DEF
                            ;Integer Part of Answer
.DEF TMP1 = R4
                            ;Temporary Workspace
.DEF TMP2 = R5
.DEF TMP3 = R6
                            ;
.DEF TMP4 = R7
.DEF ZER0 = R10
                            ;Hold Zero
.DEF
      AL = R16
                            ;Original Value
.DEF
      AH = R17
.DEF
      N = R20
                            ;Counter/Index
       LDI AL,LOW(65000)
                            ;Load Original Value
       LDI AH, HIGH (65000)
       LDI N,15
                            ;Initial log2 Value
```

7 of 11 03/12/2017 11:45 AM

```
PUSH AL
                              ;Store Original Value
        PUSH AH
LOOP:
        LSL AL
                              ;Shift Left until a one
        ROL AH
         BRCS FINI
                              ;
SKIP:
        DEC N
         BRNE LOOP
        MOV ANS, N
                              ;Store the Integer Part
FINI:
                              ;Store Fractional Part
        MOV ANSF,AH
        LDI AL,LOW(45426)
                              ;Multiply by 45426
        LDI AH, HIGH (45426)
                              ;Then divide by 65536 by
MUL16x16:
                              ;the lowest two bytes
        CLR ZER0
        MUL ANS, AH
        MOVW TMP4:TMP3,R1:R0 ;
        MUL ANSF, AL
        MOVW TMP2:TMP1,R1:R0 ;
        MUL ANS, AL
        ADD TMP2,R0
        ADC TMP3,R1
        ADC TMP4, ZERO
        MUL ANSF, AH
        ADD TMP2,R0
        ADC TMP3,R1
        ADC TMP4, ZERO
        MOVW ANS:ANSF, TMP4:TMP3 ; Store Answer
        POP AH
                              ;Restore Original Value
        POP AL
                              ;
```

9. LOG BASE 10 OF A SINGLE-BYTE NUMBER

Previously we created routines to calculate the log base two of a number. From the equations below we see that by multiplying the log2 of a number by 0.301030004 we can calculate the logarithm base 10.

```
log10(x) = log2(x)/log2(10)
= log2(x) * 1/3.321928
= log2(x) * 0.301030004
= C * Log2(x) ; where C = 0.0.301030004
```

We will use the following ratio to estimate the constant above.

```
C = 77/256 = 0.30078 Error = 0.08%
```

The routine is about 40 bytes long and takes about 20 to 50 clock cycles.

```
.DEF ANSF = R2
                              ;Fractional Part of Answ
.DEF
      ANS = R3
                              ;Integer Part of Answer
.DEF
         A = R16
                              ;Original Value
.DEF
         N = R20
                              ;Counter/Index
        LDI A,250
                             ;Load Original Value
        LDI N,7
                              ;Initial log2 Value
        PUSH A
                              ;Store Original Value
LOOP:
       LSL A
                              ;Shift Left until a one
         BRCS FINI
SKIP:
        DEC N
                              ;
         BRNE LOOP
FINI:
        MOV ANS, N
                              ;Store the Integer Part
        MOV ANSF, A
                              ;Store Fractional Part
        LDI A,77
                             ;Multiply by 77 then
                              ; divide by 256 by ignori
MUL16x8:MUL ANSF,A
        MOV ANSF,R1
                              ;lowest byte of the resu
        MUL ANS, A
        CLR ANS
        ADD ANSF, RO
        ADC ANS,R1
        POP A
                              ;Restore Original Value
```

10. LOG BASE 10 OF A SIXTEEN-BIT NUMBER

Previously we created routines to calculate the log base two of a number. From the equations below we see that by multiplying the log2 of a number by 0.301030004 we can calculate the logarithm base 10.

```
log10(x) = log2(x)/log2(10)
= log2(x) * 1/3.321928
= log2(x) * 0.301030004
= C * Log2(x) ; where C = 0.0.301030004
```

We will use the following ratio to estimate the constant above.

```
C = 19728/65536 = 0.30103 Error = 0.00000
```

The routine is about 70 bytes long and takes about 40 to 125 clock cycles.

```
.DEF ANSF = R2
                            ;Fractional Part of Answ
.DEF ANS = R3
                            ;Integer Part of Answer
.DEF TMP1 = R4
                            ;Workspace
.DEF TMP2 = R5
.DEF TMP3 = R6
                            ;
.DEF TMP4 = R7
.DEF ZER0 = R10
                            ;Hold Zero
.DEF
     AL = R16
                            ;Original Value
.DEF
      AH = R17
.DEF
       N = R20
                            ;Counter/Index
       LDI AL, LOW(65000)
                            ;Load Original Value
       LDI AH, HIGH (65000)
       LDI N,15
                            ;Initial log2 Value
       PUSH AL
                            ;Store Original Value
       PUSH AH
       LSL AL
LOOP:
                            ;Shift Left until a one
       ROL AH
        BRCS FINI
SKIP:
       DEC N
        BRNE LOOP
       MOV ANS, N
                           ;Store the Integer Part
FINI:
                            ;Store Fractional Part
       MOV ANSF, AH
       LDI AL,LOW(19728)
                           ;Multiply by 19728
       LDI AH, HIGH (19728)
                            ;Then divide by 65536 by
MUL16x16:
                            ;the two lowest bytes
       CLR ZER0
       MUL ANS, AH
       MOVW TMP4:TMP3,R1:R0 ;
       MUL ANSF, AL
       MOVW TMP2:TMP1,R1:R0 ;
       MUL ANS, AL
       ADD TMP2,R0
       ADC TMP3,R1
       ADC TMP4, ZERO
       MUL ANSF,AH
```

```
ADD TMP2,R0 ;
ADC TMP3,R1 ;
ADC TMP4,ZER0 ;
MOVW ANS:ANSF,TMP4:TMP3 ;Store Answer
POP AH ;Restore Original Value
POP AL ;
```

Comments

You do not have permission to add comments.

Sign in | Recent Site Activity | Report Abuse | Print Page | Powered By Google Sites

11 of 11 03/12/2017 11:45 AM