

FTP Tool – Auto FTP Tool with DRtrig explains

12 AUG 2024



Content

IEC61850_FTPAuto_DRtrig

- Project Name: IEC61850_FTPAuto_DRtrig
- Add-in Name: FTP Tool with Rcd Made
- Add-in Description: DR being collected when DR triggered
- Runtime Service
 - ProjectServiceExtension.cs

IEC61850_FTOAuto_DRtrig_Editor

- Project Name: IEC61850_FTOAuto_DRtrig_Editor
- Add-in Name: FTP Tool Editor Content for DRmade (with address selection)
- Add-in Description: FTP Tool Editor Content for DRmade
- Add-in Editor Folder Name: IEC61850 FTP Tool
- Editor Wizard
 - EngineeringStudioWizardExtension.cs
 - Creator.cs
 - Form1.cs



Steps

Step 1 - Run Editor Tool


- ☐ IEC61850_FTOAuto_DRtrig_Editor.scadaAddIn
- 1. Select IED and input logic node for RCD Made Timestamp variable
 - ABB: BayName!BayNameDR/RDRE1/RcdMade/t[ST]
 - ZIV: BayName!BayNamePROT/RDRE1/RcdMade/t[ST]
- 2. Create variables for each driver
 - *!Command
 - *!Directory
 - *!RcdMadeT

Step 2 – Create variable for network

Create system variable

[Network] Current Primary Server

[Network] Current Standby Server



Step 3 - Run Runtime Service


- ☐ IEC61850_FTPAuto_DRtrig.scadaAddIn
- When the value of *!RcdMadeT is changed, the new DR files in IED will be downloaded to local computer
- Only primary server will be operating



IEC61850_FTOAuto_DRtrig_Editor


IEC61850_FTOAuto_DRtrig_Editor

Form 1



Enter specific address if not in selection







IEC61850_FTPAuto_DRtrig

Online containers

Container A

- Name: Primary_Server
- Container for confirming primary / secondary server
- Variable "[Network] Current Primary Server" added to the container
- Only when "Network active" is activated, this container will be created

Container B

- Name: RcdMadeT_var
- Container for all variables ended with "RcdMadeT"
- The value of *!RcdMadeT will only changed when new DR files are created in the relay
- When this container detected the changes of *!RcdMadeT, command "DIR" is set to the *!Command variable

Container C

- Name: Directory_var
- Container for all variables ended in "Directory"
- The value of variable
 *!Directory will be changed
 when variable *!Command
 is set "DIR"
- When this container detected the changes of *!Directory, program collect the file names of the DR files, and try to download with conditions

Container D

- Name: Dr_Timeset
- Container for variable "DR TimeSetting"
- If the value is changed, the duration filter for downloading DR file will be changed according to the value of "DR_TimeSetting"



