


3D CLOUD FRAME

Quick Start Guide

Serial Model NO: DIGITAL PICTURE FRAME X.X"/DIGITAL PICTURE FRAME XX.X"(X=0~9, XX=00~32)
3D DIGITAL PICTURE FRAME X.X" /3D DIGITAL PICTURE FRAME XX.X"(X=0~9, XX=00~32), XX:The screen size

What In The Box


Please check all items before first use.



Frame



Manual



Plug




Frame stand




Screw x2

Hardware Overview

Familiarize yourself with the frame before setup.



- **Power Button**




- **Touch Screen**



- **Type-C/DC**

How to Send Photos to Your 3D Frame

Step 1 (ON FRAME) Plug In




How to Send Photos to Your 3D Frame

Step 1

(ON FRAME)

Connect WIFI (1st) - LocalTransmission (every time) to display the QR code



How to Send Photos to Your 3D Frame



Step 2

(ON CELLPHONE)
Download & Open App

For iPhone: App Store → search "3D
Flash Camera"

For Android: Google Play → search "3D
Cam"

 or  **Download**




How to Send Photos to Your 3D Frame

Step 3

(ON CELLPHONE)

Take or Select Photo in App



How to Send Photos to Your 3D Frame

Step 4

(ON CELLPHONE and FRAME)

In App, Tap “Scan Code Connection” to Scan Frame QR




How to Send Photos to Your 3D Frame

Step 5

(ON CELLPHONE)

Tap "Send Photo" in APP



How to Send Photos to Your 3D Frame

Step 5

(ON FRAME)

Enjoy 3D Magic



Managing Photos

Other


Delete Photos

Tap the screen to bring up the menu-"Settings" - "Delete Photos


Show/Hide Photos

Tap the screen to bring up the menu-"Settings" - "Show/Hide photos"

Delete Photos



Show/Hide Photos



Managing Photos

Other


Photo Display Order

Tap the screen to bring up the menu-"Settings" -"Slideshow"- "Photo Display Order"


Brightness

Tap the screen to bring up the menu-"Settings"- "Display" -"Brightness"

Photo Display Order




Brightness



Managing Photos

Other Sleep Mode

Tap the screen to bring up the menu-Tap the sleep icon.
-Press the power button on the back to wake up



FAQs

Q1: Do my phone and frame need to be on the same WiFi?

A: Yes. Both devices must be connected to the same WiFi network for the first-time setup. The frame will remember your WiFi after that.

Q2: Why are my photos not showing a 3D effect?

A: For best results, use photos with a clear subject and a blurred or simple background – for example, portraits, pet close-ups, or landscapes with a foreground (flowers, tree) and background (mountains, sky). Solid-color background or group shots may show less depth.

Q3: Is there a monthly fee or subscription?

A: No. The frame uses local WiFi to transfer photos directly from your phone. There are no monthly fees, no cloud storage costs, and no hidden charges.

Q4: Does the frame support video playback?

A: No. This frame is designed specifically to display photos in 3D. It does not play videos.

Q5: The photo transferred successfully but looks flat. What's wrong?

The 3D effect works best on images with depth in the original photo – e.g., a person standing away from the background, a pet's face close to the camera. Try sending a different photo with more foreground/background separation.

FAQs

Q6: How do I wake the frame from sleep mode?

A: Tap the screen to wake it.
If the screen stays off, press the power button on the back of the frame briefly.

Q7: How do I delete or hide photos on the frame?

A: Go to Settings > Delete Photos to remove photos,
or Settings > Show/Hide Photos to hide them without deleting.

Q8: Can I use a USB cable to transfer photos?

A: No. This frame only supports photo transfer via the local WiFi connection using the companion app.

Q9: I changed my home WiFi. How do I reconnect the frame?

A: Go to Settings > WiFi on the frame, select your new network,
and enter the password. Then follow the same steps to reconnect your phone.