

3D Hologram Fan User Manual

1. Unpacking and Installation

1.1 Check the Box Contents


Open the package and verify all items are present:

- 3D Hologram Fan (main body) – includes motor, control board, LED board, and housing
- 4 x Fan blades – two marked A, two marked B
- Wall mount bracket + screws + wall anchors
- Power adapter (UL-certified)
- Phillips screwdriver
- Remote control (battery included)
- User manual



1.2 Install the Fan Blades


① On the motor hub, locate the pre-marked A and B slots (two each).



② On the fan blades, find the matching A or B markings (two blades marked A, two marked B).



③ Insert the two A blades into the A slots, and the two B blades into the B slots, with the LED side facing UP (the A/B marking will face DOWN). Push until they click into




place.

④ Secure each blade using the provided screws – 3 screws per blade. Tighten firmly with the included screwdriver.

1.3 Mount the Fan on the Wall

- ① Use the wall mount bracket as a template. Mark drill holes with a level to ensure horizontal installation.
- ② Drill holes at the marked positions and insert the matching wall anchors.
- ③ Secure the bracket firmly to the wall with the provided screws.



- ④ Hang the assembled fan steadily onto the fixed bracket.



1.4 Connect Power

- ① Plug the power adapter into the fan.
- ② Plug the adapter into a wall outlet.
- ③ Check the blue LED on the fan blades: it will blink once and then turn off. This means the fan is in standby mode and ready to connect via the app.



2. Download the App

Two optional methods to download the Holoscope app (support iOS and Android systems)

Option 1 – Search and Download

On your iPhone or Android device, open the App Store or Google Play Store.



Search for "Holoscope" and download the official app.

Option 2 – Scan QR Code to Download

Scan the exclusive QR code below with your phone camera to open the official

download page directly.



Android



iOS

Note: The Holoscope app is completely free and compatible with all mainstream iOS and Android devices.

3. App Operation Instructions


3.1 App Language Setup

Step 1: Open the Holoscope app. Tap the avatar icon in the top-left corner of the home page.

Step 2: On the personal avatar page, find and tap the "Language" option.

Step 3: Select "English" from the language list.

The app interface will switch to English immediately. You only need to do this once..



3.2 Connect Your Phone to the Fan's WiFi

Step 1: Open your phone's Settings, then enter the Wi-Fi (Wireless LAN) page.


Step 2: Search for a wireless network starting with "3D-P" (e.g., 3D-P45-2000*1064).

Step 3: Tap the target network and enter the default password: 12345678 to connect.

Note: It is normal that the fan's WiFi has no external internet access. This dedicated WiFi is only for the connection between your mobile phone and the hologram fan to realize content transmission and device control.




Once connected, your phone will show "Connected" (Note: No internet access is normal – the fan's WiFi is only for connecting your phone to the fan.).





After successful connection, you can use the Holoscope app to upload and play content on the fan.


3.3 Play Images / Videos from Your Phone




① Tap Power to turn on the fan.

② Tap Transfer → Video/Image/Local





③ Select your video/Image



④ Tap OK to upload.

3.4 Manage Playlist


All uploaded content is saved in the




playlist.

Play Order: The fan plays all files in list order and automatically loops from the beginning.

Loop a single file: Tap the pin icon next to any video/image – the fan will play only that item repeatedly.




Rename & Delete Content: Tap the "EDIT" button to modify the name of the saved content; tap the "Delete" button to remove unwanted content from the playlist.




3.5 Adjust Brightness, Angle, and Volume


① On the app home screen, tap the settings icon to enter the device parameter setting page.




② Brightness adjustment: Drag the brightness slider up and down to increase or decrease the brightness of the hologram display image.



③ Angle adjustment: Use the angle adjustment function to calibrate and rotate the display image to solve the tilt problem.



④ Volume adjustment: Adjust the playback volume (this function is only valid when the fan is connected to a Bluetooth speaker).



4. Advanced Functions


Important Note: All advanced functions require a valid internet connection. Please disconnect your phone from the fan's dedicated WiFi and connect to home/office WiFi or enable mobile data before operation.

4.1 Edit Templates (Cube, 3D Sphere, Rotated Text, Artistic Text)

- ① Ensure your mobile phone is connected to the internet (not the fan's WiFi).
- ② Tap the "Design" button on the app home screen to enter the template editing



page.



③Select a template (e.g., Cube)

④Edit your content (text, color, speed,




etc.).

⑤ Tap "Save" to store the edited content. The saved content will be automatically synchronized to the Local library, and you can upload it to the fan for playback.




4.2 Download Free Material from Cloud

- ① Ensure your mobile phone is connected to the internet via home WiFi or mobile data.
- ② Tap the "Cloud" (Material Library) button on the app home



page.

- ③ Browse free videos/images.
- ④ Select favorite materials and tap the "Download" button to save them to the app



library.

⑤ All downloaded cloud materials will be stored in the Local library, which can be selected and uploaded to the fan for playback at any time.

