

Arm[®] GPU Bug Bounty Device Configuration Guidelines

Public

Copyright © 2025 Arm Limited (or its affiliates). All rights reserved.

Document Version: 20250623-1.0

- [Supported OS Versions](#)
- [Supported Kernel Config Options](#)
- [Proprietary notice](#)

This document is Non-Confidential.

Copyright © 2025 Arm Limited or its affiliates. All rights reserved.

This document is protected by copyright and other intellectual property rights. Arm only permits use of this document if you have reviewed and accepted [Arm's Proprietary notice](#) found at the end of this document.

These materials and information are provided as part of Arm's Bug Bounty program to assist security researchers in their vulnerability research related to this program. These documents do not constitute official Arm documentation, and no warranties or guarantees are provided regarding their accuracy, completeness, or suitability for any purpose outside of the Bug Bounty context. Arm reserves the right to modify or withdraw any materials at its discretion without prior notice.

To be eligible for Arm's bug bounty program, GPU vulnerability submissions must be reproducible on a device that conforms to the configuration guidelines outlined in this document.

Supported OS Versions

Each version of the Arm[®] Mali[™] Kernel Driver is compatible with specific Kernel versions. As these versions are not publicly documented and will change over time, Arm provides the following guidance:

- If you are configuring a new virtual environment for testing, we recommend you always use the latest Android Common Kernel or the latest Linux Kernel stable or longterm release before testing.
- If using a hardware device with an in-scope GPU, you should ensure it is supported by the OEM and has all the latest updates installed.

In addition to releasing new versions of the Arm Mali Kernel Driver, Arm also supports its partners in backporting fixes to older versions. Vulnerabilities due to missing backports/

patches or vendor-specific customizations are not in scope for Arm's bug bounty program. Arm strongly recommends you report these to the relevant OEM instead.

Supported Kernel Config Options

Where possible, the default Kernel configuration should be used. Only the following Kernel Build KConfig options may be changed, providing it still results in a valid kernel config and the options are compatible with each other:

- `CONFIG_COMPAT`
- One of the following may be chosen to set to `y`, with the others set to `n`:
 - `CONFIG_ARM64_4K_PAGES`
 - `CONFIG_ARM64_16K_PAGES`
- Any of the `CONFIG_KASAN*` options may be set to `y` or `n`, except for the following:
 - `CONFIG_KASAN_*_TEST`, must be set to `n`
- Any of the `CONFIG_UBSAN*` options may be set to `y` or `n`, except for the following:
 - `CONFIG_TEST_UBSAN`, must be set to `n`

Please note that the Arm Mali Kernel Driver only supports 64-bit kernels. Please do not attempt to test on a 32-bit kernels or use any 32-bit kernel config settings, other than `CONFIG_COMPAT`.

Proprietary notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm Limited ("Arm"). **No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.**

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether the subject matter of the document infringes any third party patents.

The content of this document is informational only. Any solutions presented herein are subject to changing conditions, information, scope, and data. This document was produced using reasonable efforts based on information available as of the date of issue of this document. The scope of information in this document may exceed that which Arm is required to provide, and such additional information is merely intended to further assist the recipient and does not represent Arm's view of the scope of its obligations. You acknowledge and agree that you possess the necessary expertise in system security and functional safety and that you shall be solely responsible for compliance with all legal, regulatory, safety and security related requirements concerning your products, notwithstanding any information or support that may be provided by Arm herein. In addition, you are responsible for any applications which are used in conjunction with any Arm technology described in this document, and to minimize risks, adequate design and operating safeguards should be provided for by you.

This document may include technical inaccuracies or typographical errors. THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, any patents, copyrights, trade secrets, trademarks, or other rights.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Reference by Arm to any third party's products or services within this document is not an express or implied approval or endorsement of the use thereof.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word "partner" in reference to Arm's customers is not intended to create or refer to any partnership

relationship with any other company. Arm may make changes to this document at any time and without notice.

This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of this document shall prevail.

The validity, construction and performance of this notice shall be governed by English Law.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its affiliates) in the US and/or elsewhere. All rights reserved. Please follow Arm's trademark usage guidelines at <https://www.arm.com/company/policies/trademarks>. Other brands and names mentioned in this document may be the trademarks of their respective owners.

Arm Limited. Company 02557590 registered in England.
110 Fulbourn Road, Cambridge, England CB1 9NJ.
(PRE-1121-V1.0)