

TOKENRING MESSAGES



TABLE DES MATIERES

1	FROM PH_RECEIVER	.1
1.1	To MAC receiver	.1
1.2	To PHY sender	.1
2	FROM MAC_RECEIVER	.1
2.1	To Applications receivers	. 1
2.2	To MAC sender	.1
2.3	To PHY sender	.2
3	FROM TIME_RECEIVER TO LCD	.2
4	FROM CHAT_RECEIVER TO LCD	.2
5	FROM TOUCH TO MAC_SENDER	.2
6	FROM CHAT_SENDER	.3
6.1	To LCD	.3
6.2	To MAC sender	.3
7	FROM TIME_SENDER TO MAC_SENDER	.3
8	FROM MAC_SENDER	.3
8.1	To LCD	
8.2	To PHY sender	



TOKENRING MESSAGES

1 FROM PH_RECEIVER

1.1 To MAC receiver

FROM_PHY	
DATA frame pointer	SRC DST CS
-	
-	

1.2 To PHY sender

FROM_PHY	
DATA frame pointer	SRC DST CS
-	
-	

2 FROM MAC_RECEIVER

2.1 To Applications receivers

DATA_IND	
STRING frame pointer	\0
Src address	
Src SAPI	

2.2 To MAC sender

TOKEN	
TOKEN frame pointer	0xff
-	
-	

sap - v1.1 XXX - 1/4



DATABACK	
DATA frame pointer	SRC DST CS
Src address	
Src SAPI	

2.3 To PHY sender

TO_PHY	
DATA frame pointer	SRC DST CS
-	
-	

3 FROM TIME_RECEIVER TO LCD

TIME_MSG	
STRING frame pointer	\0
Src address	
Src SAPI	

4 FROM CHAT_RECEIVER TO LCD

CHAT_MSG	
STRING frame pointer	\0
Src address	
Src SAPI	

5 FROM TOUCH TO MAC_SENDER

NEW_TOKEN	
-	
-	
-	

START	
-	
-	
-	



STOP	
-	
-	
-	

6 FROM CHAT_SENDER ...

6.1 To LCD

CHAR_MSG	
Char (x)	
-	
-	

6.2 To MAC sender

DATA_IND	
STRING frame pointer	\0
Dest Addr	
Src SAPI	

7 FROM TIME_SENDER TO MAC_SENDER

DATA_IND	
STRING frame pointer	\0
Broadcast (0x0F)	
Src SAPI	

8 FROM MAC_SENDER ...

8.1 To LCD

TOKEN_LIST	
-	
-	
-	

TOKENRING MESSAGES



MAC_ERROR	
STRING frame pointer	\0
Src address	
-	

8.2 To PHY sender

TO_PHY	
DATA frame pointer	SRC DST CS
-	
-	