

?

Sources

C:/Users/yodak/Multichannel_fir_filter/Multichannel_fir_filter.runs/impl_1/fir_multichannel_axis_utilization_placed.rpt

Q [Icons] Read-only [Settings]

98
99
100 3. Memory
101 -----
102
103 +-----+-----+-----+-----+-----+-----+
104 | Site Type | Used | Fixed | Prohibited | Available | Util% |
105 +-----+-----+-----+-----+-----+-----+
106 | Block RAM Tile | 0 | 0 | 0 | 1030 | 0.00 |
107 | RAMB36/FIFO* | 0 | 0 | 0 | 1030 | 0.00 |
108 | RAMB18 | 0 | 0 | 0 | 2060 | 0.00 |
109 +-----+-----+-----+-----+-----+-----+
110 * Note: Each Block RAM Tile only has one FIFO logic available and therefore can accommodate only one FIFO36E1 or one FIFO18E1. !
111
112
113 4. DSP
114 -----
115
116 +-----+-----+-----+-----+-----+-----+
117 | Site Type | Used | Fixed | Prohibited | Available | Util% |
118 +-----+-----+-----+-----+-----+-----+
119 | DSPs | 2 | 0 | 0 | 2800 | 0.07 |
120 | DSP48E1 only | 2 | | | | |
121 +-----+-----+-----+-----+-----+-----+
122
123

Utilization

Post-Synthesis

Post-Implementation

Graph

Table

