










Getting Start ESP32: ESP32 GPIO + ESP32 Interface

Mission 3/12 – ESP32 with Single Digit 7_Segment

1. Read https://www.9engineer.com/index.php?m=article&a=print&article_id=2605

	<table border="0"> <tr><td></td><td>abcdef</td></tr> <tr><td></td><td>bcfg</td></tr> <tr><td></td><td>abcdefg</td></tr> <tr><td></td><td>deg</td></tr> <tr><td></td><td>bc</td></tr> <tr><td></td><td>acdfg</td></tr> <tr><td></td><td>abcdg</td></tr> <tr><td></td><td>abdeg</td></tr> <tr><td></td><td>acdefg</td></tr> <tr><td></td><td>abcef</td></tr> <tr><td></td><td>abc</td></tr> <tr><td></td><td>cdefg</td></tr> <tr><td></td><td>aefg</td></tr> </table>		abcdef		bcfg		abcdefg		deg		bc		acdfg		abcdg		abdeg		acdefg		abcef		abc		cdefg		aefg
	abcdef																										
	bcfg																										
	abcdefg																										
	deg																										
	bc																										
	acdfg																										
	abcdg																										
	abdeg																										
	acdefg																										
	abcef																										
	abc																										
	cdefg																										
	aefg																										
Common Cathode	Common Anode																										
Comm Pin = GND	Comm Pin = Vcc																										
a, b, c, d... Pin = Active High	a, b, c, d... Pin = Active Low																										
Common Cathode Display 	 Common Anode Display																										


2. Read <https://www.cybertice.com/b/58>
3. Read <https://linuxhint.com/digital-dice-seven-segment-esp32-arduino-ide/>
4. Test Code “Test0301-Test 7 Segment” with esp32 board

```
#define minData 0
#define maxData 9
int SegmentPort[] = {16, 17, 5, 18, 19, 21, 22, 23}; // tgfe dcba
int SegmentTable[] = {0x3F, 0x06, 0x5B, 0x4F, 0x66,
                      0x6D, 0x7D, 0x07, 0x7F, 0x6F
                    }; // tgfe dcba
int nCounter = 0;

void Display_1Digit_7Segment(int iData) {
    int SegDecode = SegmentTable[iData]; // CK 7-Segment – GND
    Common
    // int SegDecode = ~SegmentTable[iData]; // CA-Segment – Vcc
    Common
    for (int i = 0; i < 8; i++) {
        digitalWrite(SegmentPort[7-i], SegDecode & 1);
        SegDecode = SegDecode >> 1;
    }
}



void setup() {
    for (int i = 0; i < 8; i++)
        pinMode(SegmentPort[i], OUTPUT);
    Serial.begin(115200);
}

void loop() {
    Display_1Digit_7Segment(nCounter);
    Serial.println(nCounter);
    nCounter++;
    nCounter = nCounter < minData ? maxData : nCounter;
    nCounter = nCounter > maxData ? minData : nCounter;
    delay(1000);
}
```




Common

tgfe -- dcba = 16, 17, 5, 18 -- 19, 21, 22, 23



- How to display 0-F

Last Minute
ENGINEERS.co.in



5. Simulator On <https://wokwi.com/>
6. Read https://youtu.be/j2yh_sxCbgo?list=PLuCK22HcVLB1AtX6f9ODpgjxeTIQpBCIT
7. Read <https://www.youtube.com/watch?v=T0mveNCbmbU>
8. Create New ESP32 Project <https://wokwi.com/projects/new/esp32>
9. Edit diagram_json →
10. Edit Arduino C Code →



11. Online Wokwi by Wichai Srisuruk >> <https://wokwi.com/projects/388873810912894977>




diagram.json	Code7Seg.ino
<pre>{ "version": 1, "author": "Wichai Srisuruk", "editor": "wokwi", "parts": [{ "type": "wokwi-esp32-devkit-v1", "id": "esp", "top": 52.1, "left": -27.4, "rotate": 90, "attrs": {} }, { "type": "wokwi-7segment", "id": "segseg1", "top": 177.78, "left": -71.72, "rotate": 0, "attrs": { "common": "cathode", "color": "red" } }, { "type": "wokwi-resistor", "id": "r1", "top": 235.2, "left": -173.35, "rotate": 90, "attrs": { "value": "560" } }, { "type": "wokwi-resistor", "id": "r2", "top": 235.2, "left": -182.95, "rotate": 90, "attrs": { "value": "560" } }, { "type": "wokwi-resistor", "id": "r3", "top": 235.2, "left": -211.75, "rotate": 90, "attrs": { "value": "560" } }, { "type": "wokwi-resistor", "id": "r4", "top": 235.2, "left": -211.75, "rotate": 90, "attrs": { "value": "560" } }, { "type": "wokwi-resistor", "id": "r5", "top": 235.2, "left": -240.55, "rotate": 90, "attrs": { "value": "560" } }, { "type": "wokwi-resistor", "id": "r6", "top": 235.2, "left": -230.95, "rotate": 90, "attrs": { "value": "560" } }, { "type": "wokwi-resistor", "id": "r7", "top": 235.2, "left": -259.75, "rotate": 90, "attrs": { "value": "560" } }, { "type": "wokwi-resistor", "id": "r8", "top": 235.2, "left": -250.15, "rotate": 90, "attrs": { "value": "560" } }, { "type": "esp:RX0", "connections": ["esp:TX0", "serialMonitor:RX"], "dependencies": {} }, { "type": "esp:RX0", "connections": ["esp:TX0", "serialMonitor:TX"], "dependencies": {} }, { "type": "segseg1:D3", "connections": ["segseg1:R1", "segseg1:R2", "segseg1:R3", "segseg1:R4", "segseg1:R5", "segseg1:R6", "segseg1:R7", "segseg1:R8"], "dependencies": {} }, { "type": "segseg1:D2", "connections": ["segseg1:R1", "segseg1:R2", "segseg1:R3", "segseg1:R4", "segseg1:R5", "segseg1:R6", "segseg1:R7", "segseg1:R8"], "dependencies": {} }, { "type": "segseg1:D1", "connections": ["segseg1:R1", "segseg1:R2", "segseg1:R3", "segseg1:R4", "segseg1:R5", "segseg1:R6", "segseg1:R7", "segseg1:R8"], "dependencies": {} }, { "type": "segseg1:D0", "connections": ["segseg1:R1", "segseg1:R2", "segseg1:R3", "segseg1:R4", "segseg1:R5", "segseg1:R6", "segseg1:R7", "segseg1:R8"], "dependencies": {} }, { "type": "segseg1:DP", "connections": ["segseg1:R1", "segseg1:R2", "segseg1:R3", "segseg1:R4", "segseg1:R5", "segseg1:R6", "segseg1:R7", "segseg1:R8"], "dependencies": {} }, { "type": "GND:D", "connections": ["GND:COM"], "dependencies": {} }], "connections": [["esp:RX0", "serialMonitor:RX"], ["esp:RX0", "serialMonitor:TX"], ["r1:1", "segseg1:D3"], ["r2:1", "segseg1:D2"], ["r3:1", "segseg1:D1"], ["r4:1", "segseg1:D0"], ["r5:1", "segseg1:DP"], ["r6:1", "segseg1:D3"], ["r7:1", "segseg1:D2"], ["r8:1", "segseg1:D1"], ["r9:1", "segseg1:D0"], ["r10:1", "segseg1:DP"], ["segseg1:D3", "segseg1:E"], ["segseg1:D2", "segseg1:E"], ["segseg1:D1", "segseg1:E"], ["segseg1:D0", "segseg1:E"], ["segseg1:DP", "segseg1:E"], ["segseg1:D3", "segseg1:B"], ["segseg1:D2", "segseg1:B"], ["segseg1:D1", "segseg1:B"], ["segseg1:D0", "segseg1:B"], ["segseg1:DP", "segseg1:B"], ["segseg1:D3", "segseg1:A"], ["segseg1:D2", "segseg1:A"], ["segseg1:D1", "segseg1:A"], ["segseg1:D0", "segseg1:A"], ["segseg1:DP", "segseg1:A"], ["segseg1:D3", "segseg1:C"], ["segseg1:D2", "segseg1:C"], ["segseg1:D1", "segseg1:C"], ["segseg1:D0", "segseg1:C"], ["segseg1:DP", "segseg1:C"], ["segseg1:D3", "segseg1:D"], ["segseg1:D2", "segseg1:D"], ["segseg1:D1", "segseg1:D"], ["segseg1:D0", "segseg1:D"], ["segseg1:DP", "segseg1:D"], ["segseg1:D3", "segseg1:GND"], ["segseg1:D2", "segseg1:GND"], ["segseg1:D1", "segseg1:GND"], ["segseg1:D0", "segseg1:GND"], ["segseg1:DP", "segseg1:GND"]], "dependencies": {} }]</pre>	<pre>#define minData 0 #define maxData 9 int SegmentPort[] = {16, 17, 5, 18, 19, 21, 22, 23}; // tgfe dcba int SegmentTable[] = {0xAF, 0x06, 0x5B, 0x4F, 0x6B, 0xD, 0x7D, 0x07, 0xF, 0x6F }; // tgfe dcba int nCounter = 0; void Display_1Digit_7Segment(int iData) { int SegDecode = SegmentTable[iData]; // CK 7-Segment - GND Common // int SegDecode = ~SegmentTable[iData]; // CA-Segment - Vcc Common for (int i = 0; i < 8; i++) { digitalWrite(SegmentPort[7-i], SegDecode & 1); SegDecode = SegDecode >> 1; } } void setup() { for (int i = 0; i < 8; i++) pinMode(SegmentPort[i], OUTPUT); Serial.begin(115200); } void loop() { Display_1Digit_7Segment(nCounter); Serial.println(nCounter); nCounter++; nCounter = nCounter < minData ? maxData : nCounter; nCounter = nCounter > maxData ? minData : nCounter; delay(1000); }</pre>