

Observed limitation	Preferred network	Main mechanism
low-frequency gain is too small	raise low-frequency gain first	reduce steady-state error while preserving the existing mid/high band if possible
ω_c and phase margin are both too small	lead compensation	add phase lead and raise the useful mid-band gain
ω_c is too high but phase margin is too small	lag compensation	attenuate high frequency, move the crossover left, use the plant's own phase reserve
steady-state and transient requirements both fail	combined compensation	coordinate low / mid / high frequency changes together