Welcome

After antenna you need power , Psw/Pleak, grid IR, EM limits, markers

The idea

- Toy tiny_power: Psw n1=1.0, chip Ptot=5.55, ir_drop_sink=0.4, 4 markers

Two tracks

- Implement track uses common/ solvers; browser lab track uses platform tools

Toy design

- Tiny_power: Psw n1=1.0, chip Ptot=5.55, ir_drop_sink=0.4, 4 markers

Path

- Switching → leakage → total → activity → grid → IR → EM → markers → engine

Begin

- Next: switching power per net