Why apply ECOs

Applying ECOs flips fixed checks from fail to pass

The idea


- GOLDEN: fail_count→0 after apply_ecos

Flip fails

APPLY FIXES

Flip fails

Step 1 / 5 · apply · module03-03-apply-ecos



Explanation

Apply ECOs — flip sta and antenna to pass.

- apply

```
0 fail
```


Flip fails

STA fixed

APPLY FIXES

STA fixed

Step 2 / 5 · sta · module03-03-apply-ecos



Explanation

STA slack becomes +0.02 after buffer.

- sta

```
pass
```


STA fixed

Antenna fixed

APPLY FIXES

Antenna fixed

Step 3 / 5 · ant · module03-03-apply-ecos



Explanation

Antenna count zero after jumper.

- antenna

```
pass
```


Antenna fixed

Others hold

APPLY FIXES

Others hold

Step 4 / 5 · rest · module03-03-apply-ecos



Explanation

DRC/LVS/ERC/IR remain pass.

- pass

```
4
```


Others hold

Golden

APPLY FIXES

Golden

Step 5 / 5 · golden · module03-03-apply-ecos



Explanation


GOLDEN: fail_count → 0 after ECO.

- GOLDEN

```
0
```

Golden

Browser lab track



Browser lab starter

Implement track

- Call apply_ecos(); assert fail_count==0

Pitfalls

- Applying ECO without updating check status
- Partial apply

Your turn

- Next: tapeout checklist