
How to use Serial Controller

Shunsuke Yoshimoto


Device architecture




Typical setup

- Microcontroller: STM32F407G, STMicroelectronic
- Driver & Linear Actuator: EAC4W-D15-AZAA-1-G, Orientalmotor
- Power Supply: AD8735D, AND

Microcontroller: STM32F407G



Pin assignment



Software install

- Download program
 https://github.com/yoshimoto56/tools/tree/master/LinearActuator/bin
- 2. Connect microcontroller
- Confirm COM port
 Device Manager>Ports>STMicroelectronics Virtual COM Port (COM#)
- Rewrite batch file
 SerialCommunication.exe COM#

Command

sign+speed+stroke
 ex) p100050: positive, 100 mm/s, 50 mm
 000<=speed<=100, 000<=stroke<=150

q:stop