
AquaControl PCB Series



- 1-Power Input 1
- 2-Power Input 2
- 3- Switch for port 1
- 4-Buzzer/Speaker
- 5-power Button for port 1
- 6- Power Regulator
- 7- Extra Supply Pins for ESP32 (gng, 3.3v,5v)
- 8-Microcontroller (ESP32)
- 9-MCU Power Switch
- 10-i2c module
- 11-Sensor Terminal
- **12-Sensor Terminal**
- 13-Debugging LEds
- 14- Sensor Switch



Installation Guide: How to Connect and Configure the AQUA1 PCB System