

TIA_DRV
DRV3
DRV1
R5
COL
SENSE0
SENSE1

[illegible] TEXT

[illegible] RESET

U12_SENSE
U11_SENSE
U10
U9_