


Labview GUI-Install a BLE USB Driver

USB Driver install – BLE dongle (BLED112)

This document is property of IM-Tech and Orthosensor.

Unauthorized reproduction or copying can be criminal charges.


- 1. Connect the BLED112 USB dongle via USB to your PC
- 2. Windows will recognize the device and prompt for a driver software, use the driver located in the windrv folder
 - ✓ If Windows does not prompt for the driver, go to **Device manager**, select the unknown device and click **Update** driver software
- 3. If Windows security gives a waring about the driver installation, choose *Install this driver software anyway*
- 4. After driver installation a device called *Bluegiga Bluetooth Low Energy* should be visible under **Ports** in Windows **Device manager**
- 5. If you see this, the driver installation is complete






Labview GUI-User guide

- BLE Device connection
 - ① Select a Com port of a BLE dongle
 - ② Connect a GEN4 module via BLE scan popup







[Device selection]