



LDB Series Quick Start Manual

Products: LDB-100, LDB-160, LDB-200, LDB-300, LDB-310

Copy the software from the attached DVD etc. to an arbitrary folder on the PC.
Copy LDControllerXX.exe and tmHIDLd.dll to the same folder.





When LDControllerXX is executed, the operation application software is displayed and tmLDController.txt is created in the same folder.




Connecting cables and turning on power

Connect the + 5V power supply, USB cable, interlock connector (LDB - 200 only), turn on the LD and TEC switch.



When turning on the power, the operation application software LDControllerXX can be operated.

Operation of application software



TEC and LD ON

When outputting laser light, please take safety measures such as protective goggles.

