Pick by location, not by material name.

Three questions decide nine out of ten harness protection choices.

1 How hot does the surface get?

Below 105 °C continuous	→	**PVC tape** — lowest cost, flame retardant
105 – 150 °C	→	**PET cloth or fleece** — check adhesion at temperature
Above 150 °C or radiant heat	→	**Foil-laminated sleeve** — reflective layer required

2 Will it rub against metal or a bracket?

Yes — grommets, edges, brackets	→	**Woven PET (cloth)** — defined abrasion class, not just thickness
No — behind trim or headliner	→	**Fleece** — noise damping, low residue

3 Does it need re-openable access?

Yes — service, retrofit, wiring changes	→	**Self-wrapping sleeve** — opens without cutting the tape
No — fixed at assembly	→	**Tape wrap** — fastest, lowest cost per metre