Charge amplifier

A **charge amplifier** is an electronic **current integrator** that produces a voltage output proportional to the integrated value of the input current. This is **efectively** a measurement of the electrical input charge; hence the naming of the device.

The amplifier offsets the input charge using a feedback reference capacitor, and produces an output voltage inversely proportional to the value of the reference capacitor but proportional to the total input charge flowing during the specified time period; hence the circuit acts as a charge-to-voltage converter. The gain of the circuit depends on the values of the feedback capacitor and the feed-in resistor.

Contents

Design

Ideal circuit
Practical circuit

Applications

Other uses

See also

References

External links

Design

Charge amplifiers are usually constructed using an <u>operational amplifier</u> or other high gain semiconductor circuit with a <u>negative</u> <u>feedback</u> capacitor. The input current is offset by a negative feedback current flowing in the capacitor, which is generated by an increase in output voltage of the amplifier. The output voltage is therefore dependent on the value of input current it has to offset and the inverse of the value of the feedback capacitor. The greater the capacitor value, the less output voltage has to be generated to produce a particular feedback current flow

The input impedance of the circuit is almost zero because of the <u>Miller effect</u>. Hence all the stray capacitances (the cable capacitance, the amplifier input capacitance, etc.) are virtually grounded and they have no influence on the output signal.

Ideal circuit

An "ideal circuit" for analysing chage amplifier operation is shown below:

The circuit operates by passing a current that charges or discharges the <u>capacitor</u> C_f during the time under consideration, which strives to retain the <u>virtual ground</u> condition at the input by off-setting the effect of the input current. Referring to the above diagram, if the op-amp is assumed to be <u>ideal</u>, nodes v_1 and v_2 are held equal, and so v_2 is a virtual ground. The input voltage passes a current $\frac{v_{in}}{R_1}$ through the <u>resistor</u> producing a compensating current flow through the series capacitor to maintain the virtual ground. This charges or discharges the capacitor over time. Because the resistor and capacitor are connected to a virtual ground, the input current does not vary with capacitor chage and a linear integration of output is achieved.

The circuit can be analyzed by applyingKirchhoff's current law at the node v_2 , keeping ideal op-amp behaviour in mind.




 $I_{
m B}=0$ in an ideal op-amp, so:

$$i_1=i_{
m F}$$

Furthermore, the capacitor has a voltage-current relationship governed by the equation:

$$I_{
m C} = C rac{dV_{
m c}}{dt}$$

Substituting the appropriate variables:



$$rac{v_{
m in}-v_2}{R_1}=C_{
m F}rac{d(v_2-v_{
m o})}{dt}$$

 $v_2 = v_1 = 0$ in an ideal op-amp, resulting in:

$$rac{v_{
m in}}{R_1} = -C_{
m F} rac{dv_{
m o}}{dt}$$

Integrating both sides with respect to time:

$$\int_0^t rac{v_{
m in}}{R_1} \; dt \; = - \int_0^t C_{
m F} rac{dv_{
m o}}{dt} \, dt$$

If the initial value of v_o is assumed to be 0 V, this results in a DC error of [2]

$$v_{
m o} = -rac{1}{R_1 C_{
m F}} \int_0^t v_{
m in} \, dt$$

Moreover, the relationship between electric chage and current is governed by:

$$Q=\int_0^t i(t)dt$$

Therefore, the input-output equation of the chage amplifier is:

$$v_0 = -rac{1}{C_{
m F}}Q$$

Practical circuit

The ideal circuit is not a practical integrator design for a number of reasons. Practical op-amps have a finite open-loop gain, an input offset voltage and input bias currents (I_B). This can cause several issues for the ideal design; most importantly, if $v_{in} = 0$, both the output offset voltage and the input bias current I_B can cause current to pass through the capacitor, causing the output voltage to drift

over time until the op-amp saturates. Similarly, if v_{in} were a signal centered about zero volts (i.e. without a \overline{DC} component), no drift would be expected in an ideal circuit, but may occur in a real circuit. To negate the effect of the input bias current, it is necessary to set:


$$R_{\mathrm{on}} = R_1 || R_F$$

The error voltage then becomes:

$$V_{
m E} = \left(rac{R_{
m F}}{R_1} + 1
ight) V_{IOS}$$

The input bias current thus causes the same voltage drops at both the positive and negative terminals. A practical circuit is shown below.

Also, in a DC steady state, the capacitor acts as an open circuit. The DC gain of the ideal circuit is therefore infinite (or in practice, the open-loop gain of a non-ideal opamp). To counter this, a large resistor R_F is inserted in parallel with the <u>feedback</u> capacitor, as shown in the figure above. This limits the DC gain of the circuit to a finite value, and hence changes the output drift into a finite, preferably small, DC error. Referring to the above diagram:



$$V_{\mathrm{E}} = \left(rac{R_{\mathrm{F}}}{R_{1}} + 1
ight) \left(V_{IOS} + I_{BI}\left(R_{\mathrm{F}} \parallel R_{1}
ight)
ight)$$

where V_{IOS} is the input offset voltage and I_{BI} is the input bias current on the inverting terminal. $R_F \parallel R_1$ indicates two resistance values in parallel.

In practice, the gain of the circuit is expressed in chage input required to obtain a voltage output, such as picocoulomb per volt.

Applications

Common applications include amplification of signals from devices such as <u>piezoelectric sensors</u> and <u>photodiodes</u>, in which the charge output from the device is converted into avoltage.

Charge amplifiers are also used extensively in instruments measuring <u>ionizing radiation</u>, such as the <u>proportional counter</u> or the <u>scintillation counter</u>, where the energy of each pulse of detected radiation due to an ionising event must be measured. Integrating the charge pulses from the detector gives a translation of input pulse energy to a peak voltage output, which can then be measured for each pulse. Normally this then goes to discrimination circuits or **a**multi channel analyzer.

Charge amplifiers are also used in the readout circuitry of <u>CCD</u> imagers and flat-panel <u>X-ray</u> detector arrays. The amplifier is able to convert the very small charge stored within an in-pixel capacitor to a voltage level that can be easily processed.

Advantages of charge amplifiers include:

- Enables quasi-static measurements in certain situations, such as constant pressures on a piezo lasting several
 minutes^[3]
- Piezo element transducer can be used in much hotter environments than those with internal electronics
- Gain is dependent only on the feedback capacitorunlike voltage amplifiers, which are affected greatly by the input capacitance of the amplifier and the parallel capacitance of the cab[all4]

Other uses

- Accelerometer signal conditioning
- Guitar pickup amplifiers
- Vibration transducers

See also

- Obtaining virtual zero impedance by applying Miller theorem
- Charge Transfer Amplifier

References

- 1. Transducers with Charge Output(http://www.mmf.de/instrumentation.htm)
- "AN1177 Op Amp Precision Design: DC Errors'(http://ww1.microchip.com/downloads/en/AppNotes/01177a.pdf)
 (PDF). Microchip. 2 January 2008. Archived (https://www.webcitation.org/6Db011SaW?ul=http://ww1.microchip.com/downloads/en/AppNotes/01177a.pdf)(PDF) from the original on 2013-01-11 Retrieved 26 December 2012.
- 3. "Piezoelectric Measurement System Comparison: Charge Mode vs. Low Impedanceol/tage Mode (LIVM)"(https://web.archive.org/web/20071217145656/http://www.dytran.com/go.cfm/en-us/content/tech-education-a1/x)Dytran Instruments. Archived from the original (http://www.dytran.com/go.cfm/en-us/content/tech-education-a1/x)on 2007-12-17. Retrieved 2007-10-26.
- 4. "Maximum cable length for charge-mode piezoelectric accelerometers(https://web.archive.org/web/2007121721121 8/http://www.hightech-pr.com/endevco/2007_01/f4.php) Endevco. Jan. Archived from the original (http://www.hightech-pr.com/endevco/2007_01/f4.php) a 2007-12-17. Retrieved 2007-10-26. Check date values in: | date= (help)

External links

- Interface Circuits for Polyvinylidene fluoridefilm
- Schematic diagram

Retrieved from 'https://en.wikipedia.org/w/index.php?title=Charge_amplifier&oldid=841714174

This page was last edited on 17 May 2018, at 15:41(UTC).

Text is available under the <u>Creative Commons Attribution-ShareAlike Licenseadditional terms may apply By using this site, you agree to the Terms of Use and Privacy Policy.</u> Wikipedia® is a registered trademark of the <u>Wikimedia</u>



Foundation, Inc., a non-profit organization.