# Magnetic Resonant Imaging (MRI)

BME/EECS 516 Lecture #7 – Spin-echoes, Noise, Parallel Imaging Notes on MRI, Parts 3 & 4

#### Announcements

- HW #4 due Tuesday, 10/31 (Today!)
- i HW #5 due Tuesday, 11/7
- MRI Project due Tuesday 11/21

- Tuesday, 11/14 guest lectures from local medical imaging industry
  - David Sarment from Xoran Technologies
  - John Seamans (UM) formerly with Delphinus Medical and GE Healthcare

#### Last Lecture

- The 3<sup>rd</sup> Dimension Z
  - Extend 2D Spin-Warp Imaging to 3D
- Slice Selective Excitation common approach for dealing with the 3<sup>rd</sup> (z) dimension
  - Small Tip Angle Approximation
  - Putting Slice Selection with the Signal Equation
  - Larger Flip Angles
  - Multi-slice Imaging

#### Review on Slice Selective Excitation

Step 1: Apply a z-gradient so that the resonance frequency varies in the z-direction. Within a slice of thickness  $\Delta z$ :

$$B_{z} = B_{0} + G_{z} \cdot z$$

$$\omega(z) = \gamma(B_{0} + G_{z} \cdot z)$$

$$\omega_{eff}(z) = \gamma G_{z} \cdot z$$

#### Slice Selective Excitation

- Step 2: Apply a bandpass RF pulse  $(B_1)$  with bandwidth (BW in Hz)
- RF pulse excite only the those spins whose resonant frequency lies within the band.
  - $[\omega_{RF} BW * 2\pi/2, \omega_{RF} + BW * 2\pi/2]$   $= [\gamma(B_0 + Gzz_1), \gamma(B_0 + Gzz_2)] \text{ to excite spins}$ only within slice  $[z_1, z_2]$

## **Small Tip Angle Approximation**

With small tip angle approximation:

$$m_{xy,rot}(z,t) = ign_0 e^{-igG_z zt/2} F^{-1} \{B_1(s+t/2)\}_{s=\frac{g}{2\rho}G_z z}$$

apply a negative  $G_z$  for a period  $\tau/2$  – often called a slice rephasing pulse – to remove  $e^{-igG_zzt/2}$ 

$$m_{xy,rot}(z,3t/2) = igm_0 F\{B_1(s+t/2)\}_{s=\frac{g}{2\rho}G_z z}$$

## Putting Slice Selection with the Signal Equation

Go back to 3D distribution of magnetization by substituting  $im_0 = m(x,y,z)$  and putting it into the signal equation (again the RF coil integrates across the object):

$$s(t) = in(x,y,z)p(z) \exp(-i2p(xk_x(t) + yk_y(t)))dxdydz$$

Here we are performing 2D imaging while integrating across the slice profile


## Larger Flip Angles

Analysis using small flip angle (e.g.  $\alpha < \pi/6$ ) approximation turns out perform well for large flip angles (e.g.  $\pi/2$ ) as well.

Here, a better approximation for the transverse component of the magnetization is:

$$m_{xy,rot}(z,3t/2) = im_0 \sin(p(z))$$

## Mutli-slice Imaging



#### True or False

The selection of the time between RF excitation pulses of the same slice affects T1 contrast.

The selection of the time between RF excitation pulses of two adjacent slices affects T1 contrast.

#### True or False

- The selection of the time between RF excitation pulses of the same slice affects T1 contrast.
  - True TR is the excitation-excitation time within a slice

$$m_z(TR) = \left(1 - e^{-\frac{TR}{T_1}}\right)$$

- The selection of the time between RF excitation pulses of two adjacent slices affects T1 contrast.
  - False neighboring slices do not affectT1 recovery

#### Question

- Slice-selective, 2D spin-warp acquisition overall acquisition time is:
- $_{i}$  A)  $N_{y}*N_{y}*TR$
- $_{i}$  B)  $N_{y}^{*}TR$
- $C) N_z * TR$

#### Question

- Slice-selective, 2D spin-warp acquisition overall acquisition time is:
- $_{i}$  A)  $N_{y}^{*}N_{z}^{*}TR$
- $_{i}$  **B)**  $N_{y}^{*}TR$
- $C) N_z *TR$
- Within TR, we will collected kx for all slices along z direction (sketch).

## Mutli-slice Imaging

- Slice-selective, 2D spin-warp acquisition overall acquisition time:  $N_y *TR$
- For example, acquire a T1-weighted image
  - Nz 20 slices
  - TR 500 ms
  - 1 128 phase encoding lines in k-space
  - Total acquisition time  $N_y *TR = \sim 1$  minute

#### Questions?

Selective Slice Excitation 3D Spin-Warp Imaging


#### This Lecture

- ¡ Spin Echo Pulses
- Spin-echo Spin-warp Pulse Sequence
- Why do spin-echo pulses?
- Noise in MRI
- Signal to Noise Ratio
- Array coils and parallel imaging

refocusing of precessing nuclear spin magnetisation by a 180 ° pulse Very commonly used in MRI

Earlier we described 180 degree RF pulses for purposes of inverting the  $m_z$  magnetization.

Consider a 180 degree B1 pulse applied to the x' axis in the rotating frame



Spins are flip wowner

X' axis like a

"pancuke flipper"

- 1 180 degree B1 pulse applied to the x' axis in the rotating frame
  - $t_{180-}$  time just before the 180 degree pulse
  - $t_{180+}$  time after the 180 degree pulse

$$m_{x,rot}(t_{180+}) = m_{x,rot}(t_{180-})$$

$$m_{y,rot}(t_{180+}) = -m_{y,rot}(t_{180-})$$

$$m_{z,rot}(t_{180+}) = -m_{z,rot}(t_{180-})$$

#### Question

- What is the duration of the 180 degree pulse.
- $_{i}$  A)  $\pi/2\gamma B_{1}$
- $_{\rm i}$  B)  $\pi/\gamma B_{1}$
- $_{i}$  C)  $2\pi/\gamma B_{1}$


#### Question


- What is the duration of the 180 degree pulse.
- $_{i}$  A)  $\pi/2\gamma B_{1}$
- $_{\rm i}$  B)  $\pi/\gamma B_{1}$
- $_{i}$  C)  $2\pi/\gamma B_{1}$


(angle/rotation rate)

Suppose the vector is lying in the transverse plane ( $m_z = 0$ ). Assume positioned on the x' axis and rotation phase  $\Phi(\mathbf{r}, t)$  has accumulated due to  $\Delta B$  terms.

$$\Phi(\mathbf{r}, t_{180+}) = -\Phi(\mathbf{r}, t_{180-})$$
  
or  $m_{xy,rot}(t_{180+}) = m_{xy,rot}(t_{180-})^*$ 









Ignoring the k-space term (  $\delta G(t) \times rdt$  ), the phase accumulation at the time of 180 degree pulse  $t_{180}$   $\Phi$  ( $\mathbf{r}$ ,  $t_{180}$ ) =  $\Delta \omega(\mathbf{r}) t_{180}$ 


Apply 180 degree pulse to flip the spins



Before 180 degree pulse  $\Phi(r, t180+) = -\Delta\omega(r)t_{180}$ 


Just after 180 degree pulse  $\Phi$  (r, t180-) =  $\Delta\omega$ (r)  $t_{180}$ 






- When imaging, the phase term results from gradients and can be written as:  $\phi(\mathbf{r}, t) = 2\pi(\mathbf{k}(t).\mathbf{r})$  à  $\mathbf{k}(t_{180+}) = -\mathbf{k}(t_{180-})$
- A 180 degree pulse will invert the location in k-space.
- Spin-echo 180 degree pulses are at times known as "phase reversal" or "time reversal" pulses.

## Spin-echo Spin-warp Pulse Sequence



## Spin-echo Spin-warp Pulse Sequence

180 degree pulse inverts the position in k-space:



### Questions?

Spin Echo Pulses Spin-echo Spin-warp Pulse Sequence

- Magnetic field inhomogeneity can results in intra-voxel signal dephasing.
  - Due to many reasons various chemical or magnetic filed distribution (e.g., deoxygenated homoglobin variation)

Consider a magnetic field inhomogeneity function  $\Delta B(\mathbf{r})$ . Effective magnetic field (rotating frame):

$$B_{z,eff} = \mathbf{G}(t).\mathbf{r} + \Delta B(\mathbf{r})$$

Corresponding phase function:

$$\Phi(\mathbf{r}, t) = 2\pi(\mathbf{k}(t).\mathbf{r}) + \Delta\omega(\mathbf{r})t$$

when integrating Δω(r)t across a voxel some signal may be lost. The spin-echo pulse brings this phase back together again.

## Spin Echo Pulses in Spin Warp sequences


https://www.youtube.com/watch?v=
GDEIT6Tz7\_Q

Phase continues to accumulate

If we look at time 2  $t_{180}$ , we will have a total phase accumulation of:

$$\Phi(\mathbf{r}, 2 t_{180}) = \Phi(\mathbf{r}, t_{180+}) + \Delta \omega(\mathbf{r}) t_{180}$$
  
=  $-\Delta \omega(\mathbf{r}) t_{180} + \Delta \omega(\mathbf{r}) t_{180} = 0$ 


The signal in the transverse plane  $(|m_{xy}|)$  will look like this:



## T2 vs. T2\* weighted images

- T2\* is shorter than T2 because the decay induced by the signal dephasing from the inhomogenity effect, when integrated by the coil, result in reduced signal.
- When all dephasing from inhomogenity in a volume tissue is cancelled by the spinecho, T2 decay still remains.
- i If use T2\* instead of T2 may lose detailed info.

## T2- vs. T2\*-weighted images




Symms, M & Jäger, H.R. & Schmierer, Klaus & Yousry, T.A.. (2004). A Review of Structural Magnetic Resonance Neuroimaging. Journal of neurology, neurosurgery, and psychiatry. 75. 1235-44. 10.1136/jnnp.2003.032714.

## T2\* weighted scans

- No spin echo is used so it is subject to additional losses above the normal *T*2 decay.
- More prone to susceptibility losses at air/tissue boundaries, but can increase contrast for certain types of tissue, such as venous blood deoxygenated homoglobin (substantial magnetic field inhomogenity).

## T2\* weighted scans

- Used in fMRI to detect
  - Change in blood oxygenation level
  - Neural activity in brain through BOLD (blood-oxygen-level dependent)



## Questions?

Why do spin-echo pulses?

# Noise and Signal to Noise Ratio in MRI

#### Noise in MRI

#### Sources of noise in MRI

- Thermal noise from body thermal vibration of ions, electrons, etc.
   (Dominant source of noise in most MRI systems)
- Quantization noise in the A/D devices
- Preamp/electronic noise
- Thermal noise in RF coil

#### Thermal noise

- Not related to the NMR
  - $\perp$  Present with or without B<sub>0</sub>, RF, Gradients
- Uniform spectral density (near  $\omega_0$ ) white noise
- Comes from the whole body amount of noise depends on the amount of the body to which the receive coil is sensitive


Both MR signal (FT of the image) and) 2D image reconstructed by a  $N_x$  by  $N_y$  inverse 2D DFT of the MR signal - Resultant noise will be zeromean, additive, independent, bivariate Gaussian noise.

#### Noise in MRI


## Noise in Spin-warp imaging

- frequency encoding gradient Gx
- field of view FOVx
- bandwidth of the receiver will be:

$$BW = \frac{g}{2\rho}G_x FOV_x = \frac{1}{Dt}$$



Noise variance  $(\sigma_n^2)$  for each sample is proportional to the presampling bandwidth:



## Signal to Noise Ratio

Noise/pixel in a 2D image will be

$$\frac{s_n^2}{N_x N_y} \mu \frac{BW}{N_x N_y} = \frac{1}{N_x N_y Dt} = \frac{1}{T_{A/D}}$$

where  $T_{A/D}$  is the total time the A/D is sampling

## Signal to Noise Ratio

The **signal**  $(x_{i,j})$  represents the total amount of magnetization in a particular voxel

$$\mathbf{\mathring{a}} \ \mathbf{\mathring{a}} \ x_{i,j} = X_{0,0} = M(0,0)$$

- i The signal is proportional to  $m_oV$ 
  - $V = \Delta x \Delta y \Delta z$  -"voxel" volume
  - $\Delta z$  slice thickness

## Signal to Noise Ratio

Signal to noise ratio:

$$SNR \mu \frac{signal}{s_n} = m_0 V \sqrt{T_{A/D}}$$

 $m_0$  is proportional to  $\rho$  - the concentration the nucleus of interest,  $B_0$ , and  $\gamma$ .

- An image is too noisy, so we average together neighboring pixels to achieve  $\Delta y'$  =  $\Delta y^*2$  (all other dimensions remain the same and  $\Delta t$  hasn't changed either)
- Question: How does the SNR change. i.e. SNR' = ?? SNR<sub>orig</sub>?

- An image is too noisy, so we average together neighboring pixels to achieve  $\Delta y' = \Delta y^* 2$  (all other dimensions remain the same and  $\Delta t$  hasn't changed either)
- Answer: By averaging in image domain, we effectively are discarding samples in k-space  $(N_{y'} = N_{y}/2)$ :  $T_{A/D}' = T_{A/D}/2$

$$SNR' = 2DxDy\sqrt{\frac{T_{A/D}}{2}} = \sqrt{2}SNR_{orig}$$

The SNR is improved by sqrt(2).

- SNR of an image was too noisy. We compensated by acquiring a lower resolution  $\Delta y' = \Delta y^* 2$  (all other dimensions remain the same) but we've compensated so as to preserve the original acquisition time  $T_{A/D}' = T_{A/D}$  (e.g., by changing  $\Delta t$ )
- Question: How does the SNR change. i.e. SNR' = ?? SNR<sub>orig</sub>?

SNR of an image was too noisy. We compensated by acquiring a lower resolution  $\Delta y' = \Delta y^* 2$  (all other dimensions remain the same) but we've compensated so as to preserve the original acquisition time  $T_{A/D}' = T_{A/D}$  (e.g., by changing  $\Delta t$ )

#### Answer:

$$SNR' = 2DxDy\sqrt{T_{A/D}} = 2SNR_{orig}$$

The SNR is improved by 2 times.

#### **Lessons learned**

It is preferable to anticipate the SNR that is necessary for a given image and set the acquisition accordingly. We don't achieve as good of an SNR by smoothing the image after it is acquired than if we had acquired at the appropriate resolution originally.

- Suppose we increase our image acquisition time by a factor of 2. The resolution is the same (i.e.,  $\Delta x$  and  $\Delta y$  remain the same) and  $T_{A/D}$ ' = 2  $T_{A/D}$ . The new SNR change is changed to:
- i A) 2 SNR<sub>orig</sub>
- <sub>i</sub> B)  $\sqrt{2}$  SNR<sub>orig</sub>
- i C) SNR<sub>orig</sub>
- <sub>i</sub> D)  $SNR_{orig}/\sqrt{2}$

Suppose we increase our image acquisition time by a factor of 2. The resolution is the same (i.e.,  $\Delta x$  and  $\Delta y$  remain the same) and  $T_{A/D}$ ' = 2  $T_{A/D}$ 

#### Answer:

$$SNR' = DxDy\sqrt{2T_{A/D}} = \sqrt{2}SNR_{orig}$$

Averaging increases the SNR by sqrt(*N*) where *N* is the number of averages

- Suppose we increased the field strength by a factor of 2,  $B_0' = 2 B_0$ . Everything else remain the same. The new SNR change is changed to:
- i A) 2 SNR<sub>orig</sub>
- <sub>i</sub> B) sqrt(2) SNR<sub>orig</sub>
- i C) SNR<sub>orig</sub>
- D) SNR<sub>orig</sub>/sqrt(2)

- Suppose we increased the field strength by a factor of 2,  $B_0' = 2 B_0$ .
- i Answer:

$$SNR' = 2SNR_{orig}$$

this additional SNR to reduce the number of averages (and thus overall imaging time) by a factor of 4! – time is money in imaging!

- Suppose we wanted to halve all 3 voxel dimensions  $(\Delta x, \Delta y, \Delta z)$  but keep the SNR the same. How much longer will the acquisition time need to be?
- i A) 2
- $_{\rm i}$  B)  $\sqrt{8}$
- <sub>i</sub> C) 8
- D)  $8^2 = 64$

Suppose we wanted to halve all 3 voxel dimensions  $(\Delta x, \Delta y, \Delta z)$  but keep the SNR the same. How much longer will the acquisition time need to be?

D) 
$$8^2 = 64$$
 (unfortunately)

In  $SNR \propto V \sqrt{T_{A/D}}$ ,  $V \downarrow 8$ , so  $T_{A/D} \uparrow 64$ 

## How to increase Signal to Noise Ratio?

- Averaging in image domain
  - SNR improved by sqrt(N)
  - Can be compensated by increasing acquisition time to further increase SNR

- i Increase acquisition time by N times
  - SNR improved by sqrt(N)
- i Increased the field strength B<sub>o</sub>
  - SNR improved by N times

## Questions?

Signal to Noise Ratio

Zero-mean and additive

$$s(t) = M(k_x(t), k_y(t)) + n$$

- Samples are independent (due to the whiteness of the spectrum)
- Gaussian distributed (it results from large numbers of vibrating particles
  - Law of Large Numbers)

Bi-variate - independent noise in real + imaginary (the channels of the complex demodulator are orthogonal)  $(n = n_i + i n_q)$ 

A 1D image is reconstructed by an N point DFT:

$$x_n = \frac{1}{N} \sum_{m=0}^{N-1} X_m \exp \frac{2p}{N} \frac{nm}{N} \frac{\ddot{o}}{\dot{e}}$$

- $X_m$  independent noise having variance .
- Noise in image pixels  $x_n$  will also be zeromean, additive, independent, bi-variate Gaussian noise, but with variance


Derivation of the variance is:


$$\begin{aligned} \text{var}(x_n) &= E \Big[ x_n x_n^* \Big] = E \, \hat{\mathbf{e}} \, \frac{1}{N} \, \hat{\mathbf{e}}^{N-1} \, X_m e^{i2\rho \frac{nm}{N}} \, \frac{1}{N} \, \hat{\mathbf{e}}^{N-1} \, X_l e^{-i2\rho \frac{nl}{N}} \, \hat{\mathbf{u}} \, \hat{\mathbf{$$

# Array Coils and Parallel Imaging

### Signals Weighted by Coil Sensitivity

 $s_l(t) = \iint C_l(x, y) m(x, y) \exp(-i2\pi (k_x(t)x + k_y(t)y) dx dy$  $m_l(x, y) = C_l(x, y) m(x, y) \text{ for coil } \# l$ 





Siemens Healthineers

## **SNR** Advantages

#### SNR:

- I Small coils are sensitive to the signal of interest but only receive noise from the volume directly in front of a coil.
- Better SNR, poor coverage
- Combining signals from array of coils, one achieve the benefit of a large region of coverage but the SNR advantage of small coils.

#### **Coil Combination**

For coils with independent, equal variance noise:

$$\widehat{m}(x,y) = \frac{\sum_{l} C_{l}^{*}(x,y) m_{l}(x,y)}{\sum_{l} |C_{l}(x,y)|^{2}}$$

Pretty good and easy method (don't need to know  $C_l$ :

$$\widehat{m}(x,y) = \sqrt{\sum_{l} |C_{l}(x,y)m(x,y)|^{2}}$$

## Parallel Imaging

- Use coils coarse coil patterns to reduce aliaising
- Speed acquisition/increase spatial resolution
- Basic idea: by sampling multiple coils, one can use the additional measurements to eliminate aliasing


## SENSE Imaging – An Example


Full Fourier Encoding Volume Coil

Pixel A Pixel B

Unknown Pixel Values A & B

Full Fourier Encoding
Array Coil






Known Sensitivity Info S<sub>1A</sub>, S<sub>1B</sub>,...


## SENSE Imaging – An Example

Reduced Fourier – Speed-Up R=2 Volume Coil

Insufficient Data
To Determine A & B



Reduced Fourier – Speed-Up R=2 Array Coil Extra Coil
Measurements
Allow Determination
of A & B






Reduced Fourier + Coil 2






## SENSE Imaging – An Example



$$\begin{bmatrix} y_1 \\ y_2 \\ y_3 \\ y_4 \end{bmatrix} = \begin{bmatrix} C_{1A} & C_{1B} \\ C_{2A} & C_{2B} \\ C_{3A} & C_{3B} \\ C_{AA} & C_{AB} \end{bmatrix} \begin{bmatrix} A \\ B \end{bmatrix}$$

$$\begin{bmatrix} A \\ B \end{bmatrix} = \mathbf{C}^+ \begin{bmatrix} y_1 \\ y_2 \\ y_3 \\ y_4 \end{bmatrix}$$

Solving this matrix equation leads to A & B and the unaliased image



## Parallel Imaging

#### Pros:

- Much faster acquisition
- Higher spatial resolution
- Some reduction of distortions

#### Cons:

 Lower SNR (partially compensated by SNR improvement from coil arrays)