





DO NOT USE these pins for anithing other than attaching an I2C ID EEPROM. Leave unconnected if ID EEPROM not required.

Legend

Serial Pin

PCM Audio

Physical Pin

Port Name

Power

GND

PWM

√ PWM Pin

These pins are reserved for ID EEPROM

At boot time this I2C interface will be interrogated to look for an EEPROM that identifies the attached board and allow automagic setup of the GPIOs (and optionally, linux drivers).

] IO Pin



