



El Dorado Easy Reader 2.0 Cloud

Features and Sending / Receiving files to the tablet



New features in version 2.0 Cloud

1. Enhanced Note taking
2. Take picture – you can now take a picture and store the photo on the tablet and email the photo to someone else. The photo is stored in a folder unique to each customer in the internal storage -> Easy Reader -> accounts folder.
3. Directions to meter address – uses Google offline maps if you don't have cellular connectivity
4. Geo tagging – now you can tag an address or meter location saved as latitude / longitude
5. Service Orders – ability to send and receive electronic service orders to and from El Dorado
6. Automated meter change out – Ability to record meter change outs from service orders



Add note


Take photo

Get directions


Geo tag location

Overview: Step 1 Export File to the cloud

1. From the drop down under File select option to Import / Export select → Meter Readings




2. A window will appear with the various types of meter readings devices supported, select:
 - a. Easy Reader Cloud
 - b. Name the file and select Export
 Optional – you can filter the range of accounts or route you would like to export




The export function will create a readings file and send it to the cloud. You will receive confirmation that the file was uploaded.

Opening / Saving files on the device


1. Step 1 – Open the Easy Reader go to File Manager



2. You are now ready to set your preferences and begin entering readings. To Configure your software, select **Settings**




3. Once you have completed entering your readings you can send the completed file back to the The system will keep all reading files, its good practice to run a backup on your current file and delete old files on a regular basis.






Importing the readings back into El Dorado

Repeat the same process as the as you did for the export



Select Filepath for “Import” and choose your current readings file



Select Load Files, the active files will appear in the dropdown. Pick the file you would like to import from the list. Next select POST NEW READINGS button.



Once the file is imported your readings, and meter updates and Latitude / Longitude will be updated in the database

Readings

Geotagged location

Post Readings Allocation Usage Options Meter Info Conversions Compound Utility RUBS

Add 0 zeros to the end of all readings - Maximum of 3

Comments

Post Reading

Last Reading: 3/3/2020 Days: 29 New Reading: 3/26/2020

Reading: 43661

Previous: 43502

kWh: 159

+/- Variance %:

Avg Usage: 140

Seas Avg Usgr: 0

Changeout: 0

ELEC

FAC

Meter Type: M

Meter Brand:

Meter Size:

Num. Dials: 5 Read Type:

Radio Freq: 0

Latitude: 5.3646220872

Longitude: 162.98073294

MXU/ERT#:

MXU Type: Test Circle:

Misc:

Special Text:

Installation Date: 2/24/1995

Last Service Date:

Service Codes:

BackFlow Device Installed

Updating Service Orders

Service	7/ 8/2020	All	Not export	3	Refresh	File Sync
Orders	8/ 7/2020	All	All			
Account Number	Name	Date	SO Number	Status		
0001.1	New Customer	8/5/2020	1304	COMPLETED		
0004	LIFE TIME FITNESS	7/30/2020	1303	OPEN		
0015	STUART, RICK & DEBBIE	7/29/2020	1302	COMPLETED		

Click the File Sync to upload New or Download new service orders