

CA4K™ "Workstation" Installation Guide

(V1.1.5x)

Revision: Rev E

Date: 1/13/2022



DISCLAIMER

Continental Instruments LLC makes no representations or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose. Further, Continental Instruments LLC reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Continental Instruments LLC to notify any person of such revision or changes.

Copyright © **2016 by Continental Instruments LLC.** All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, or stored in a retrieval system, without the prior written permission of Continental Instruments LLC, 355 Bayview Avenue, Amityville, NY 11701. Telephone: 631-842-9400 • FAX: 631-842-9135

This document contains proprietary information of NAPCO Security Technologies. Unauthorized reproduction of any portion of this manual without the written authorization of NAPCO Security Technologies is prohibited. The information in this manual is for informational purposes only. It is subject to change without notice. Companies, names and data used in examples herein are fictitious unless otherwise noted. NAPCO Security Technologies assumes no responsibility for incorrect information this manual may contain.

A NAPCO SECURITY TECHNOLOGIES COMPANY
Publicly traded on NASDAQ Symbol: NSSC

Visit our websites: http://www.cicaccess.com/ http://www.napcosecurity.com/ http://www.alarmlock.com/

Table of Contents

DISCLAIMER	1
Must Read before you begin installation	3
Overview	4
System Requirements Ensure Recommended Server Requirements are met Verify Full Administrator Permissions	4
Related Documents	5
Prerequisites	5
CA4K TM Workstation Installation	6
NOTES:	16

Must Read before you begin installation

- Prior to starting the CA4KTM installation, you must make certain you have Full Administrator privileges without any restrictions. This includes lowering the UAC settings to "Never Notify" and verifying there are no domain restrictions. Failure to do so will result in installation failures.
- Verify the CA4KTM Software license on the CA4K Server (host) supports at least 5 workstations.
- The CA4K Workstation should point to the CA4K Server (Host).
- If the EPI Badging has been purchased, it is highly recommended to install it on a CA4KTM workstation. If EPI Badging is installed on the CA4KTM host, the performance might be degraded.

Overview

This document provides a step by step procedure of a CA4KTM **Workstation** installation. Prior to starting the installation, you must verify the computer meets the recommended computer specifications. By default, a CA4KTM Workstation points to the CA4KTM Server. During the installation of a Workstation, you will be prompted to enter in the IP address of the CA4KTM Server (Messaging Server).

System Requirements

Ensure Recommended Server Requirements are met

Make sure the server meets the specifications that are documented in the CA4KTM System Requirements document.

Verify Full Administrator Permissions

Continental Access requires Full Administrator permissions to install the CA4KTM software. Failure to provide these permissions will result in installation failures.

Related Documents

CA4K™ Complete Install Installation Guide - A step by step guide on installing a "Complete Server" installation.

CA4K™ Database Only Installation Guide - A step by step guide on installing a "Database Server" installation.

CA4KTM Hardware Communication Server (HCS) Installation Guide - A step by step guide on installing an HCS Installation.

CA4K™ Report Station Installation Guide - A step by step guide on installing a "Report Station" installation.

CA4KTM Server Only Installation Guide - A step by step guide on installing a "Server Only" installation.

CA4KTM Data Migration Guide - A step by step guide on migrating a CardAccess 3000 database to a CA4KTM database.

CA4K[™] Quick Start Programming Guide - A step by step guide on programming a basic CA4K[™] system.

CA4KTM TCP/IP Ports Reference Guide – TCP/IP Ports Reference Guide.

CA4KTM **System Requirements** – Computer Specifications.

Prerequisites


The following prerequisites are required prior to installing CA4KTM. If they are not detected, they will be installed automatically:

- Net Framework 4.72
- Microsoft Visual C++ Redistributable Packages
- SAP Crystal Reports


CA4KTM Workstation Installation

1. Insert the CA4KTM Installation DVD into the DVD drive. If **Auto-Play** is enabled on the computer, the software will launch automatically. On some operating systems, the following screen will display. If the screen below displays, click **Run Launch.exe** to start the installation. **Note:** a different screen might display where it is required to **Tap** the screen to launch the installation.

Note: The version on the following screens might not be the latest version, but the screens will be the same.




2. If **Auto-Start** is not enabled on the computer, you must manually launch the CA4KTM installation. Simply click the Windows Start button, then click *Run*. In the Run window, browse to the DVD and select **launch.exe** from the DVD drive. Alternatively, you can navigate to the DVD manually and run **launch.exe**. For our demonstration, the DVD drive letter is D:.




3. If the installation launches automatically, the $CA4K^{TM}$ main menu will display. Click **Install CA4K^{TM}** on the Main menu.



4. The **Requirements** screen displays all the required software components which must be installed before the installation begins. Click **Install**.




5. A progress bar will display as the **required software components** are being installed.



6. After the required software components are installed, the **Welcome to CA4KTM Setup program** screen will display. Click **Next**.




7. The Setup Type screen displays. Select Workstation. Click Next.



8. The **Select Destination Folder** screen displays. If you wish to change the Destination Folder, click Browse and select the new destination folder. Click **Next.**



9. The **Select CardAccess Components** screen displays. For our demonstration, we will not select to install EPI Badging. Click **Next**.






10. The Current Settings screen will display. Click Next.




11. A Progress Bar will display during the installation of the CA4KTM.




12. The Welcome to the SAP Crystal Reports runtime engine for .NET Framework 4 (32 bit) Installation Wizard screen will display. Click Next. (Note: If Crystal Reports is already installed, please skip to page 14).



13. The SAP Crystal Reports License Agreement screen displays. Select I accept the License Agreement. Click Next.




14. The SAP Crystal Reports Start Installation screen will display. Click Next.



15. A progress bar will display while the SAP Crystal Reports is installing.




16. After the installation is complete, the SAP Crystal Reports runtime engine for.NET Framework 4 (32 bit) has been successfully installed screen displays. Click Finish.




NOTE: Prior to the connection screen displaying, a few screens will quickly flash.


17. The **CardAccess Connection Settings** screen displays. You must type in the IP Address of the CA4K Server (Host) Computer. Click **Next**.



18. Failure to type in the IP Address of the Host Server computer will cause the following screen to display. You must type in the IP Address of the CA4K Server (Host) Computer. If this screen displays, click **OK** to proceed.



19. If the correct IP Address was entered in, a **Connection Settings Saved Successfully** screen displays. Click **OK**.



20. After the Connection is saved, the **CardAccess Installation completed successfully** screen displays. Click **Yes** to restart the computer.



21. If the CA4KTM Main Menu displays. Click Exit.



NOTES: