

CA4K™ "Server Only" Installation Guide

(Version 1.1.5x or later)

Revision: Rev E

Date: 1/13/2022



DISCLAIMER

Continental Instruments LLC makes no representations or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose. Further, Continental Instruments LLC reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Continental Instruments LLC to notify any person of such revision or changes.

Copyright © **2016 by Continental Instruments LLC.** All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, or stored in a retrieval system, without the prior written permission of Continental Instruments LLC, 355 Bayview Avenue, Amityville, NY 11701. Telephone: 631-842-9400 • FAX: 631-842-9135

This document contains proprietary information of NAPCO Security Technologies. Unauthorized reproduction of any portion of this manual without the written authorization of NAPCO Security Technologies is prohibited. The information in this manual is for informational purposes only. It is subject to change without notice. Companies, names and data used in examples herein are fictitious unless otherwise noted. NAPCO Security Technologies assumes no responsibility for incorrect information this manual may contain.

A NAPCO SECURITY TECHNOLOGIES COMPANY
Publicly traded on NASDAQ Symbol: NSSC

Visit our websites: http://www.cicaccess.com/ http://www.napcosecurity.com/ http://www.alarmlock.com/

Table of Contents

DISCLAIMER	
Must Read before you begin installation	3
Overview	4
System Requirements	
Ensure Recommended Server Requirements are met	
Verify Full Administrator Permissions	4
Related Documents	5
Prerequisites	5
CA4K TM (Server Only) Installation	6
Software License Information	17
CardAccess Software license (Import, Activate and Register)	
Hardware USB Security Key Information	18
NOTE: In most cases a software license should be used.	
Configuring the Hardware USB Security Key (Dongle)	
NOTES:	19

Must Read before you begin installation

- If you are performing an upgrade on CA4KTM Version 1.1.3x or later, the installation will automatically remove the previous version of CA4KTM and the setup must be launched again.
- The screenshots in this document might not reflect the latest version of the CA4K.
- The Version 1.1.5x of CA4K[™] requires a Version 1.1.x software license. Software licenses for Version 1.0.x will not work with a CA4K Version 1.1.x.
- The software license must be installed on the **Server Only** (CA4K host) computer.
- The Server Only installation must be used for a CA4KTM Server (host) when a **Database Server** is used. The Server Only computer points to the two Configuration and two Events databases on the **Database Server**. SQL Server Express will be installed on the Server Only computer and only one database will be created. The one database created on the Server Only is called caComdb, and is used for communications. The four Configuration and Events databases will be on the **Database Server**.
- Prior to starting the CA4KTM Server Only installation, you must make certain you have Full
 Administrator privileges without any restrictions. This includes lowering the UAC settings to "Never
 Notify" and verifying there are no domain restrictions. Failure to do so will result in installation
 failures.
- If the EPI Badging has been purchased, it is highly recommended to install it on a CA4KTM workstation. If EPI Badging is installed on the CA4KTM Complete Server, the performance might be degraded.

Overview

This document provides a step by step procedure of a CA4KTM **Server Only** installation. Prior to starting the installation, you must verify the computer meets the recommended computer specifications and you have the CA4KTM DVD and software license for the CA4KTM.

System Requirements

Ensure Recommended Server Requirements are met

Make sure the server meets the computer specifications that are documented in the "CA4K™ System Requirements document.

Verify Full Administrator Permissions

Continental Access requires Full Administrator permissions to install the CA4KTM software. Failure to provide these permissions will result in installation failures.

Related Documents

CA4K™ Complete Install Installation Guide - A step by step guide on installing a "Complete Server" installation.

CA4K™ Database Only Installation Guide - A step by step guide on installing a "Database Server" installation.

CA4KTM Hardware Communication Server (HCS) Installation Guide - A step by step guide on installing an HCS Installation.

CA4K™ Report Station Installation Guide - A step by step guide on installing a "Report Station" installation.

CA4KTM Workstation Installation Guide - A step by step guide on installing a "Workstation" installation.

CA4K[™] Data Migration Guide - A step by step guide on migrating a CardAccess 3000 database to a CA4K[™] database.

CA4K™ Quick Start Programming Guide - A step by step guide on programming a basic CA4K™ system.

CA4KTM TCP/IP Ports Reference Guide – TCP/IP Ports Reference Guide.

CA4KTM **System Requirements** – Computer Specifications.

Prerequisites

The following prerequisites are required prior to installing CA4KTM. If they are not detected, they will be installed automatically:

- Microsoft Visual C++ Redistributable Packages
- SAP Crystal Reports

CA4KTM (Server Only) Installation


Note: The versions in the screenshots might not display the latest version of CA4K.

1. Insert the CA4KTM Installation DVD into the DVD drive. If **Auto-Play** is enabled on the computer, the software will launch automatically. On some operating systems, the following screen will display. If the screen below displays, click **Run Launch.exe** to start the installation. **Note:** a different screen might display where it is required to **Tap** the screen to launch the installation.

Note: The DVD version displaying on your screen might be later.



2. If **Auto-Start** is not enabled on the computer, you must manually launch the CA4K™ installation. Simply click the Windows Start button, then click *Run*. In the Run window, browse to the DVD and select **launch.exe** from the DVD drive. Alternatively, you can navigate to the DVD manually and run **launch.exe**. For our demonstration, the DVD drive letter is D:.




3. If the installation launches automatically, the CA4KTM main menu will display. Click **Install CA4KTM** on the Main menu.




4. The Requirements screen displays all the required software components which must be installed before the installation begins. Click **Install**.


Note: The following two screens might vary between different operating systems and if any of these prerequisites are already installed.




5. A progress bar will display as the **required software components** are being installed.



6. After the required software components are installed, the **Welcome to CA4KTM Setup program** screen will display. Click **Next**.



7. Select CardAccess Server Only Installation. Click Next.




8. The Select CardAccess Destination Folder screen displays. Click Next.




9. The **Select CardAccess Components** screen displays. For our demonstration, we will not select any options. Click **Next**.



10. The Current Information screen displays. Click Next.




11. The **Setup Status** screen displays a progress bar during the installation of the CA4KTM.







13. The License Agreement screen displays. Select I accept the License Agreement. Click Next.




14. The SAP Crystal Reports Start Installation screen displays. Click Next.



15. A progress bar will display while the SAP Crystal Reports is installing.



16. After the installation is complete, the SAP Crystal Reports runtime engine for.NET Framework 4 (32 bit) has been successfully installed screen displays. Click Finish.




NOTE: For CA4K V1.1.5x, SQL 2019 Express will install.

17. If an instance of SQL Server is not detected, the **Installing SQL Server 2019**, **please wait** screen will display a few times during the installation of SQL Server 2019.




18. The **Please wait while Microsoft SQL Server 2019 Setup processes the current operation** screen displays a few times during the installation of SQL Server 2019.



19. An Installation Progress bar will display while Microsoft SQL Server 2019 is installing.

Note: On a Server Only Installation, only a limited amount of SQL components are installed for the necessary tools.




20. The Please wait while Microsoft SQL Server 2019 Setup processes the current operation screen displays.


SQL Server 2019

Please wait while Microsoft SQL Server 2019 Setup processes the current operation.

21. An Installation Progress bar will display while SQL Server 2019 is installing.



22. On a Server Only installation, only the one caComdb database will be created.



23. The CardAccess Installation completed screen displays. Click Yes to restart the computer.



24. If the Main menu displays after the Installation, click Exit.



Software License Information

CardAccess Software license (Import, Activate and Register)

The CA4KTM software license is required to launch the CA4KTM software. The name of the license file is "CardAccess.lic". The license file will be emailed to you from Continental Access. The software license only needs to be installed on the CA4KTM "Complete Server" or "Server Only" computer. After the software license is Imported, Activated and Registered, information regarding your software license, can be found in the *Help > About* section of the CA4KTM application and also in the **CardAccess 4K Client License Manager** screen.

Below are to steps required to license the CA4KTM application.

Copy the License file to the desktop

- 1. After receiving the CardAccess.lic file via an email, save the file to the desktop of the $CA4K^{TM}$ server.
- 2. In addition to step 1, save a copy of the license off the computer in a safe location. Be sure that you know where the license file is saved, in case you need the original file in the future.

Import a New License

- 1. Start the CardAccess 4K Client License Manager application.
- 2. Click System>Import License.
- 3. Navigate to the **CardAccess.lic** file on the desktop.
- 4. Click Import.

NOTE: With only the license Imported, you will be provided a grace period that allows the software to function. You must Activate and Register the software license prior to the Grace Period expiring. Failure to do so will result in the software not launching. In most cases the Grace Period is approximately 60 days or less. It is recommended to have an internet connection for Online Activation and Registration.

Activate and Register Software License (Both Mandatory)

Reminder: You must activate and register the software license prior to the Grace Period ending. If the Grace Period is still active, the amount of time left will display in the **CardAccess 4K Client License Manager screen** under "Days Left".

- Using the CardAccess 4K Client License Manager screen, view the license that you have imported and verify it is the correct version.
- 2. From the main menu, click Activate and Register.
- 3. Choose an activation method:
 - Online (Recommended) select this option to activate the license over the Internet. You may be prompted to provide proxy information to connect to the activation server.

NOTE: If you are unable to obtain internet access, please contact Continental Sales Licensing department to perform a phone activation.

Hardware USB Security Key Information

NOTE: In most cases a software license should be used.

Configuring the Hardware USB Security Key (Dongle)

Important: In almost all cases, it is recommended to use a software license. A hardware USB key will only be available as a custom order and for an additional fee. If you are using a software license, you do not need to use a hardware USB key. For information on importing, activating and registering a software license, refer to the Software License Information on the previous page.

Configure a USB Hardware Key

If you are using a hardware key that attaches to the USB port, then you must install a driver in order for Windows to recognize the device.

Important: You must install the driver for the USB hardware key BEFORE attaching the key to the computer.

To configure a USB hardware key:

- 1. Install the Hasp USB hardware key driver by doing the following:
 - **a.** On the DVD, navigate to the Drivers>Hasp folder. While in the Drivers>Hasp folder, double-click the **haspinst.exe**.
 - b. The InstallShield Wizard starts. Click Next.
 - c. The wizard continues, and the License Agreement window opens. Select the **I accept the terms in the license agreement** radio button, and then click Next.
 - d. The wizard continues, and the Setup Type window opens. Click Install.
 - e. After the installation is complete, insert the Hardware USB key into a USB port.

NOTES: