## Magic 8 Ball

```
# Magic 8 Ball
from microbit import *
from random import randint
# Rows of the LED display. The numbers indicate LED brightness
ball = Image("09990:90999:99999:09990")
while True:
  if accelerometer.was_gesture("shake"):
     display.clear()
    sleep(300)
     rando = randint(0,4)
     if rando == 0:
       display.scroll("Outcome uncertain")
     elif rando == 1:
       display.scroll("It is certain")
     elif rando == 2:
       display.scroll("Ask again later")
     elif rando == 3:
       display.scroll("Very doubtful")
     elif rando == 4:
       display.scroll("Run!")
     sleep(2000)
     display.show(ball)
    # clear the gesture history in case it was shaken while
    # the message was scrolling
     accelerometer.get_gestures()
  else:
     display.show(ball)
```